

[manuals.plus](#) /

› [Consciot](#) /

› [Consciot LED Camping Lantern Flashlight \(Model AOL007-US\) User Manual](#)

## Consciot AOL007-US

# Consciot LED Camping Lantern Flashlight User Manual

Model: AOL007-US

## 1. INTRODUCTION

Thank you for choosing the Consciot LED Camping Lantern Flashlight. This versatile device combines a powerful flashlight, a wide-area lantern, and a portable power bank, designed for various outdoor activities and emergency situations. Its robust, waterproof construction ensures reliable performance in diverse environments.



Image: The Consciot LED Camping Lantern Flashlight in both its lantern and flashlight configurations, demonstrating its dual functionality and power bank feature charging a smartphone.

## 2. SAFETY INSTRUCTIONS

- Do not look directly into the LED light when it is on, as this may cause temporary vision impairment.
- Keep the device away from extreme temperatures and direct sunlight.
- Do not disassemble or attempt to repair the device. Contact customer support for assistance.
- Ensure the USB port cover is securely closed when not in use to maintain IPX4 water resistance.
- Keep out of reach of children.

## 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Consciot Camping Lantern Flashlight (with built-in rechargeable battery)
- 1 x USB-C Charging Cable
- 1 x User Manual (this document)

## 4. SETUP AND CHARGING

### Initial Charge

Before first use, fully charge the lantern flashlight. The device features a built-in 3600mAh lithium-ion battery.

1. Locate the USB-C input port, typically protected by a rubber cover.
2. Connect the provided USB-C cable to the input port on the device.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer USB port.
4. The charging indicator light will illuminate. A full charge typically takes approximately 5 hours.
5. Once fully charged, disconnect the cable and ensure the rubber cover is sealed to maintain water resistance.




Image: Close-up view of the USB-C input and USB-A output ports on the lantern, illustrating how to charge the device and use it as a power bank.

### Using as a Power Bank

The lantern flashlight can also serve as a 3600mAh power bank to charge your mobile devices.

1. Open the rubber cover to access the USB-A output port.
2. Connect your device's charging cable to the USB-A output port on the lantern.
3. Connect the other end of your cable to your mobile device.
4. Charging will begin automatically.

## 5. OPERATING INSTRUCTIONS

---

The Consciott LED Camping Lantern Flashlight features 6 distinct lighting modes, accessible via a single power button.

### Power Button Operation

Press the power button repeatedly to cycle through the lighting modes in the following order:

1. **Front Flashlight - High Light Mode:** Provides a focused beam at 350 lumens.
2. **Front Flashlight - Low Light Mode:** Provides a focused beam at 120 lumens.
3. **Side Lantern - High Light Mode:** Illuminates a wide area.
4. **Side Lantern - Low Light Mode:** Provides softer, ambient lighting.
5. **Side Lantern - Red Light (Steady):** Useful for preserving night vision or as a warning light.
6. **Side Lantern - Strobe Red Light (SOS):** Flashing red light for emergency signaling.
7. **Off:** After the strobe red light, the next press will turn the device off.

To turn off the device from any mode, press and hold the power button for approximately 2 seconds.

### Light Mode Illustrations

## Front Flashlight



High Mode



Low Mode

## Side Lantern



High Mode



Low Mode

Image: Demonstrates the front flashlight in both high and low brightness settings.



## Stable Red Light

Repairing Car



### Emergency Warning

## Strobe Red Light

Image: Shows the side lantern illuminating an area in both high and low brightness settings.

# USB-C Rechargeable & Power Bank



Image: Illustrates the stable red light for car repair and the strobe red light for emergency signaling.

## Portability and Versatility

The lantern flashlight is designed for ease of use and portability:

- Carry Handle:** Use the integrated handle for handheld flashlight operation or easy transport.
- Two-Way Hook:** The built-in hook allows you to hang the lantern inside a tent, on a backpack, or from branches for overhead lighting.



## **IPX4** **Water Resistant**

Suitable for Outdoor Use

Image: The lantern flashlight highlighting its lightweight nature (0.76 lbs), comfortable handle for carrying, and a convenient hook for hanging in various scenarios.

## **6. MAINTENANCE**

- **Cleaning:** Wipe the device with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the lantern flashlight in a cool, dry place when not in use. For prolonged storage, charge the battery every 3-6 months to maintain its lifespan.
- **Water Resistance:** The device is IPX4 water-resistant, meaning it is protected against splashing water from any direction. Do not submerge the device in water. Ensure all port covers are sealed when exposed to moisture.



Image: The lantern flashlight hanging outdoors amidst wet foliage, demonstrating its IPX4 water-resistant capability suitable for outdoor use.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	Battery is depleted.	Charge the device fully using the provided USB-C cable.
Device not charging	Charging cable or adapter is faulty. USB-C cable not properly connected.	Ensure the USB-C cable is securely connected. Try a different USB-C cable or power adapter.
Mobile device not charging from power bank	Mobile device cable is faulty. Power bank battery is low.	Ensure the lantern flashlight is sufficiently charged. Try a different charging cable for your mobile device.

Problem	Possible Cause	Solution
Water ingress after exposure to moisture	USB port cover was not properly sealed.	Ensure the rubber cover for the USB ports is always securely closed when not in use, especially in wet conditions. Allow the device to dry completely before attempting to use or charge.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	AOL007-US
Dimensions	3.15" L x 3.15" W x 6.5" H
Item Weight	0.76 Pounds (approx. 347g)
Brightness (Flashlight High)	350 lumens
Brightness (Flashlight Low)	120 lumens
Battery Capacity	3600mAh
Battery Type	Lithium Ion (built-in)
Input Voltage	5V DC (USB-C)
Output Voltage	5V 1A (USB-A)
Water Resistance	IPX4
Material	Acrylonitrile Butadiene Styrene (ABS)

## 9. WARRANTY AND SUPPORT

### Warranty Information

This Consciot product is covered by a **2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

### Customer Support

Should you encounter any issues or have questions regarding your Consciot LED Camping Lantern Flashlight, please do not hesitate to contact our customer service team. We are committed to providing quality products and support.

For assistance, please refer to the contact information provided on the Consciot official website or your purchase platform.

## Related Documents - AOL007-US

<p>Consciōt LED LANTERN</p> <p>Operation Guide For your safety, read before operating</p>  <p>Every purchase comes with an extended one-year return policy and friendly customer service provided by Consciōt.</p>	<p><a href="#"><u>Consciōt LED Lantern Operation Guide - Model ZY-CL503R</u></a></p> <p>Comprehensive operation guide for the Consciōt LED Lantern (Model ZY-CL503R), detailing package contents, specifications, operating modes, charging instructions, and warranty information.</p>
	<p><a href="#"><u>Consciōt C10 Rechargeable Disassembly Free Lantern User Manual</u></a></p> <p>User manual for the Consciōt C10 rechargeable lantern, detailing specifications, operation modes (floodlight, spotlight, red light), maintenance, and charging instructions for this disassembly-free LED light.</p>
<p>Consciōt LED LANTERN</p> <p>Operation Guide For your safety, read before operating</p>  <p>Every purchase comes with an extended one-year return policy and friendly customer service provided by Consciōt.</p>	<p><a href="#"><u>Consciōt LED Lantern (ZY-CL503) Operation Guide &amp; Specifications</u></a></p> <p>Official operation guide and specifications for the Consciōt LED Lantern (Model ZY-CL503, AOL001-US-2-V1). Learn how to install batteries, operate modes, and understand its features. Includes warranty and contact information.</p>
<p>Consciōt</p> <p>User Manual Solar Landscape Light</p> 	<p><a href="#"><u>Consciōt Solar Landscape Light User Manual - Installation &amp; Operation Guide</u></a></p> <p>Comprehensive user manual for the Consciōt Solar Landscape Light. Learn about specifications, installation, operation modes, warm tips, and troubleshooting for your outdoor solar lighting.</p>
<p>Consciōt</p> <p>User Manual Solar Landscape Light</p> 	<p><a href="#"><u>Consciōt Solar Landscape Light User Manual</u></a></p> <p>Comprehensive user manual for the Consciōt Solar Landscape Light (Model CL28001-SW001-US-6). Includes detailed specifications, step-by-step installation guides, operation instructions, lighting mode descriptions, essential warm tips, and troubleshooting advice for outdoor garden and pathway lighting.</p>
	<p><a href="#"><u>Ceiling Fan Remote Control General Information and Operation</u></a></p> <p>This document provides general information, installation instructions, and operating procedures for a ceiling fan remote control system. It covers safety precautions, wiring diagrams, transmitter operation, and code setting between the remote and receiver.</p>

**Multi-Function Camping Lantern**

**Technical Details**

Model: AOL007-US-V1  
LED type: P7B White LED+2\*2835 White LED+2\*20 LED  
Material: ABS+PC+Aluminum  
Product Size (L\*W\*H): 34\*12\*13  
Battery type: 2\*18650 Li-ion rechargeable Battery  
Output: 5V/2A  
Operating time: 6-10 Hours  
Charging time: 8-10 Hours  
(Red indicator on during charging, blue on when fully charged)  
USB port: 5V/2A

**Functions**

1. 6 lighting modes:  
Front lighting modes: Side beam high (260 degrees) / low (160 degrees) modes; Red warning/strobe light (SOS mode)  
- High / Low modes for front beam height (170° LED)  
- High / Low modes for side beam height (2835 LED)  
- Red warning/strobe light (20 LED)  
Easy adjustment by pressing the button, meeting wide usage scenarios

2. Three power bank modes:  
USB port can be used as a power bank for smartphones or other devices charged by USB, free you from outdoor charging worries and bringing you as much convenience.

3. Three side light modes:  
A. 360° high light and 30% over than normal (2835 LED)

4. High power (Li-ion rechargeable) (3600mAh) battery supports a long run-time


**Package Included**

A. Camping lantern\*1  
B. USB Type-C Cable\*1  
C. Hook\*1  
D. Manual\*1  
\*Note: If 1 Pack, content A-C will double



















**After Sales Service Guarantee**

24-month warranty is provided for this device from the date of purchase. For any questions/technical support, please call the customer service or contact us by E-mail: support@conscioc.com

SPRING SUNSHINE TECHNOLOGY LTD.  
Address: 27 Hillier Street, Sheung Wan, Hong Kong  
Website: www.conscioc.com Tel: +852 6598 8217 (Mon-Fri 9 to 5 PST)

Made in China

## [pdf] User Manual Catalog

AOL007 US V1 20230711 v1 Conscient Collapsible Camping Lantern User Manual  
Conscient collapsible camping lantern user manual  
d258wsdn4alkbw cloudfont net media catalog product attachment  
c o conscient manual manual  
Conscient Rechargeable Manual  
d258wsdn4alkbw manual  
internal 2025 11 Manual ||| |||

...

lang: score:25 filesize: 3.69 M page\_count: 1 document date: 2023-09-20

**Multi-Function Camping Lantern**

**Technical Details**

Model: AOL007-US-V1  
LED type: P7B White LED+2\*2835 White LED+2\*20 LED  
Material: ABS+PC+Aluminum  
Product Size (L\*W\*H): 34\*12\*13  
Battery type: 2\*18650 Li-ion Rechargeable Battery  
Output: 5V/2A  
Operating time: 6-10 Hours  
Charging time: 8-10 Hours  
(Red indicator on during charging, blue on when fully charged)  
USB port: 5V/2A

**Functions**

1. 6 lighting modes:  
Front lighting modes: Side beam high (260 degrees) / low (160 degrees) modes; Red warning/strobe light (SOS mode)  
- High / Low modes for front beam height (170° LED)  
- High / Low modes for side beam height (2835 LED)  
- Red warning/strobe light (20 LED)  
Easy adjustment by pressing the button, meeting wide usage scenarios

2. Three power bank modes:  
USB port can be used as a power bank for smartphones or other devices charged by USB, free you from outdoor charging worries and bringing you as much convenience.

3. Three side light modes:  
A. 360° high light and 30% over than normal (2835 LED)

4. High power (Li-ion rechargeable) (3600mAh) battery supports a long run-time


**Package Included**

A. Camping lantern\*1  
B. USB Type-C Cable\*1  
C. Hook\*1  
D. Manual\*1  
\*Note: If 1 Pack, content A-C will double





















**After Sales Service Guarantee**

24-month warranty is provided for this device from the date of purchase. For any questions/technical support, please call the customer service or contact us by E-mail: support@conscioc.com

SPRING SUNSHINE TECHNOLOGY LTD.  
Address: 27 Hillier Street, Sheung Wan, Hong Kong  
Website: www.conscioc.com Tel: +852 6598 8217 (Mon-Fri 9 to 5 PST)

Made in China

## [pdf] User Manual

AOL007 US V1 20230711 v1 0 User Manual LED Camping Lantern Flashlight Rechargeable Pack of 1  
Conscient Portable Torch with 6 Light Modes 3600mAh Power Bank IPX4 Waterproof USB C Lights for Hurricane Emergency Survival Kits Sports Outdoors B1RZYMLI5L m media amazon images |||

...

lang: score:18 filesize: 3.69 M page\_count: 1 document date: 2023-09-20