

DOLPHIN PLAYGROUND T Dolphin Playground Wooden Swing Sets

Dolphin Playground Wooden Swing Set Instruction Manual

Model: Dolphin Playground Wooden Swing Sets

Brand: DOLPHIN PLAYGROUND T

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Dolphin Playground Wooden Swing Set. Designed for children aged 2-6, this playset offers a variety of activities including a slide, swings, climbing wall, and sandbox. Please read all instructions carefully before assembly and use to ensure maximum safety and enjoyment.

Important Safety Note:

- Adult supervision is required at all times.
- Ensure the playset is installed on level ground and securely anchored.
- Regularly inspect all components for wear and tear.

2. PRODUCT FEATURES

The Dolphin Playground Wooden Swing Set is crafted from premium cedar and designed for durability and fun. Key features include:

- **6 ft Slide:** A smooth, wave-design slide for exciting descents.
- **2 Belt Swings:** Comfortable and durable belt swings for classic fun.
- **Fort with Canopy:** An elevated fort area with a protective canopy for imaginative play.
- **Geometric Climbing Wall:** A uniquely designed climbing wall to challenge and engage children.

- **Sandbox:** A dedicated space under the fort for sand play.
- **Orderly Packaging:** Hardware is packed according to building steps, with 10% extra spare parts.
- **Detailed 3D Building Plan:** Simplifies the assembly process.
- **Safety Features:** Safe ropes to prevent finger injury/hair entanglement, heavy-duty swing hangers (440 lbs capacity), and crack-resistance bolts on A-frame legs.



Image: Children enjoying the various features of the playset.

3. SETUP AND ASSEMBLY

Assembly of your Dolphin Playground Wooden Swing Set is designed to be straightforward with our orderly packaging and detailed 3D building plan. We recommend two adults for assembly.

Preparation:

- Clear a level area in your backyard, ensuring sufficient space around the playset (refer to specifications for dimensions).
- Unpack all hardware, which is organized by building steps to prevent confusion.
- Gather necessary tools (e.g., screwdriver, wrench, drill).

Assembly Steps:

1. Follow the step-by-step instructions provided in the 3D building plan.
2. Assemble the main fort structure first, ensuring all connections are secure.

3. Attach the slide, climbing wall, and sandbox components.
4. Install the swing beam and attach the belt swings using the heavy-duty hangers.
5. Secure the playset to the ground using the provided ground anchors.



Image: Organized hardware packaging for simplified assembly.

Your browser does not support the video tag.

Video: Overview of the Dolphin Playground Wooden Swing Set for Backyard, highlighting its features and suitability for children.

Your browser does not support the video tag.

Video: A detailed look at the Wooden Swing Sets for Backyard, showcasing various play elements and design.

4. OPERATING INSTRUCTIONS

This playset offers multiple activities for children to enjoy. Ensure children understand how to use each component safely.

Using the Swings:

- Children should sit centered on the belt swings.
- Encourage gentle swinging and avoid excessive height.
- Ensure the area around the swings is clear before use.

Using the Slide:

- Children should slide down feet first, one at a time.
- Ensure the landing area is clear.

Climbing Wall and Fort:

- Children should use the geometric climbing wall to access the fort.
- The fort provides a safe elevated space for imaginative play.



Image: The playset's wave slide.

Your browser does not support the video tag.

Video: Discover Endless Adventure with this Backyard Swing Set for Kids, showcasing various play activities.

5. SAFETY GUIDELINES

Your child's safety is our top priority. Adhere to the following guidelines:

- Always provide active adult supervision.
- Ensure the playset is installed on a soft, level surface (e.g., wood chips, sand, rubber mulch) at least 6 feet away from any structures or obstacles.
- The safe rope design helps avoid finger injury and prevents hair from getting entangled.
- Heavy-duty swing hangers are designed to provide a 440-pound load capacity per swing.
- Crack-resistance bolts on the A-frame legs enhance structural integrity.
- Do not allow children to climb on the playset when wet.
- Check for loose clothing or items that could get caught on playset components.

kids **SAFETY** Design



Image: Detailed view of safety features: swing hangers, ground anchors, and crack-resistance bolts.

Safety

Durable
Rope



- Avoid fingers injury
- Prevent the hair from entangled

Image: Safe rope design on swings for enhanced child safety.

6. MAINTENANCE

Regular maintenance will extend the life and safety of your Dolphin Playground Wooden Swing Set.

- **Material:** The playset is made of high-quality cedar, known for its waterproof, anti-corrosion, and anti-crack properties, making it suitable for various weather conditions.
- **Seasonal Checks:** At the beginning of each play season and monthly thereafter, check all nuts and bolts for tightness. Tighten as necessary.
- **Hardware Inspection:** Inspect all moving parts, including swing hangers and ropes, for wear, rust, or damage. Replace any worn or damaged parts immediately.
- **Wood Inspection:** Check wooden components for splinters, cracks, or rot. Sand down splinters and treat any significant cracks or rot.
- **Cleaning:** Clean the playset periodically with mild soap and water. Avoid harsh chemicals that could damage the wood or plastic.

7. TROUBLESHOOTING

If you encounter any issues with your playset, please refer to the following common solutions or contact customer service.

- **Playset Wobbles:** Ensure all ground anchors are securely fixed into the ground. Check all bolts and nuts for tightness and re-tighten if loose.
- **Squeaking Swings:** Apply a small amount of lubricant to the swing hangers.
- **Damaged Parts:** Do not use the playset if any part is damaged. Contact customer service for replacement parts.

8. SPECIFICATIONS

Attribute	Detail
Brand	DOLPHIN PLAYGROUND T
Model	Dolphin Playground Wooden Swing Sets
Product Dimensions (L x W x H)	105.9"D x 103"W x 90"H
Frame Material	Cedar, Wood
Item Weight	120 pounds
Recommended Age	2-6 years
Swing Hanger Load Capacity	440 pounds
Assembly Required	Yes



Image: Playset dimensions diagram.

9. WARRANTY & SUPPORT

DOLPHIN PLAYGROUND T is committed to providing high-quality products and excellent customer service. If you have any questions or require assistance with your swing set, please do not hesitate to contact us.

- Our customer service team is available 24 hours a day to assist you.
- Please refer to your purchase documentation for specific warranty details.

For support, please visit our official website or contact us via the platform where you purchased the product.