Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WANAI NB-100AFRIDGE

WANAI Mini Fridge with Freezer User Manual

Model: NB-100AFRIDGE

Brand: WANAI

Introduction

Thank you for choosing the WANAI Mini Fridge with Freezer. This appliance is designed to provide convenient and efficient cooling and freezing solutions for various spaces. With its compact design and dual-door functionality, it offers ample storage for your food and beverages while maintaining optimal temperatures. Please read this manual thoroughly before operation to ensure proper use, maintenance, and safety.





Figure 1: WANAI Mini Fridge with Freezer (Black)

Safety Information

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- Ensure the appliance is properly grounded.
- Unplug the appliance before cleaning or performing any maintenance.

Product Overview

The WANAI Mini Fridge with Freezer features a stylish double-door design, offering separate compartments for freezing and refrigeration. It is designed for efficiency and convenience in compact living spaces.

Key Features:

- **Stylish Double Door Design:** 1.0 Cu.ft freezer on top and 2.5 Cu.ft refrigerator below.
- **Adjustable Temperature Control:** Seven temperature settings from -0.4°F to 50°F.
- **Enough Capacity and Versatile Storage:** Includes two removable storage shelves and a crisper drawer.
- **Convenient Cooling Solution:** High cooling efficiency with low energy consumption (0.42 kWh per day).
- **Quiet Operation:** Operates at a low noise level of 38 dB.

Dimensions:

- Product Dimensions: 17.9"D x 17.5"W x 34.7"H (45.47 cm D x 44.45 cm W x 88.14 cm H)
- Item Weight: 45 Pounds



Figure 2: Product Dimensions

Components Included:

- 1 x WANAI Mini Fridge with Freezer
- 2 x Removable Shelves (Glass)
- 1 x Crisper Drawer
- 1 x User Manual (this document)



Figure 3: Dual Door Compact Fridge with Freezer Layout



Figure 4: Interior Capacity Breakdown

Setup

Proper setup is crucial for the optimal performance and longevity of your appliance.

1. Unpacking:

- Carefully remove all packaging materials, including foam and adhesive tape.
- Inspect the appliance for any shipping damage. Report any damage to your retailer immediately.

2. Placement:

- Place the refrigerator on a flat, stable surface away from direct sunlight and heat sources (e.g., stove, heater).
- Ensure adequate air circulation around the appliance. Leave at least 4 inches (10 cm) of space on the back and sides.
- **Important:** After transportation, the machine needs to be placed upright for at least 24 hours before you plug it in. This allows the refrigerant to settle.



Figure 5: Ideal Placement for the Mini Fridge

3. Power Connection:

- Plug the appliance into a dedicated 110V AC outlet. Do not use extension cords or adapter plugs.
- Ensure the power cord is not pinched or damaged.

4. Initial Cleaning:

- Before first use, wipe the interior and exterior surfaces with a soft cloth and mild detergent. Rinse thoroughly and dry.
- The removable shelves and crisper drawer can be washed with warm soapy water.

Operating Instructions

This section guides you through the daily operation of your WANAI Mini Fridge.

1. Temperature Control:

- The refrigerator features a 7-level adjustable thermostat. The temperature range is from -0.4°F to 50°F.
- Locate the temperature control knob inside the refrigerator compartment.
- Turn the knob to adjust the cooling intensity. Higher numbers typically indicate colder settings.
- Allow several hours for the temperature to stabilize after adjustment.



Figure 6: Temperature Control Knob



Figure 7: Temperature Settings Guide

2. Storage Optimization:

- The refrigerator compartment (2.5 Cu.ft) is ideal for fruits, vegetables, dairy, and beverages.
- The freezer compartment (1.0 Cu.ft) is suitable for frozen foods, ice cream, and meats.
- Utilize the two removable glass shelves to organize items and adjust space as needed.
- The crisper drawer is designed for fresh produce to maintain humidity.
- The door drink rack provides convenient storage for bottles and cans.



Figure 8: Removable Glass Shelves and Side Drink Holder



Figure 9: Optimized Food Storage Examples

3. Energy Efficiency and Quiet Operation:

- The appliance is designed for high cooling efficiency with low energy consumption, using only 0.42 kWh per day.
- Its advanced refrigerant system ensures quiet operation, with a noise level of approximately 38 dB, making it suitable for bedrooms and offices.



Figure 10: Quiet Cooling Operation

4. Product Video:

Your browser does not support the video tag.

Video 1: Mini Fridge with Freezer for Daily Use. This video demonstrates the compact size, dual compartments, and interior features of the WANAI Mini Fridge, including the freezer and refrigerator sections, and the temperature control dial.

Maintenance

Regular maintenance ensures your appliance remains in optimal condition.

1. Cleaning:

- Always unplug the refrigerator before cleaning.
- Clean the interior with a solution of mild detergent and warm water. Use a soft cloth or sponge.
- For stubborn stains, use a baking soda solution (2 tablespoons baking soda to 1 quart water).
- Wipe the exterior with a soft cloth and mild detergent.

- Clean the door gaskets regularly to ensure a proper seal.
- Avoid using abrasive cleaners, sharp objects, or flammable fluids.

2. Defrosting:

- This appliance features manual defrost.
- When frost accumulates to about 0.2 inches (5 mm) thick in the freezer compartment, it should be defrosted.
- To defrost, unplug the appliance and remove all food items. Place towels or a shallow pan to catch melting ice.
- Do not use sharp objects or heating devices to speed up the defrosting process.
- Once defrosted, wipe the interior dry and plug the appliance back in.

Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; Circuit breaker tripped; Temperature control set to "OFF".	Ensure plug is secure; Reset circuit breaker; Turn temperature control to desired setting.
Temperature is too warm.	Door opened too frequently; Large amount of warm food added; Poor air circulation; Temperature control set too high.	Minimize door openings; Allow warm food to cool before storing; Ensure adequate space around appliance; Adjust temperature control to a colder setting.
Temperature is too cold.	Temperature control set too low.	Adjust temperature control to a warmer setting.
Excessive noise.	Appliance not level; Contacting wall or other objects; Normal operating sounds.	Adjust leveling feet; Move appliance away from contact points; Gurgling, popping, or humming sounds are normal.
Door does not close properly.	Appliance not level; Gasket dirty or damaged; Food packages blocking door.	Adjust leveling feet; Clean or replace gasket; Rearrange food items.

Specifications

Detailed technical specifications for your WANAI Mini Fridge with Freezer.

Specification	Value
Brand Name	WANAI
Model Info	NB-100AFRIDGE
Item Weight	45 pounds
Product Dimensions	17.9 x 17.5 x 34.7 inches
Item model number	NB-100AFRIDGE
Capacity	3.5 Cubic Feet

Specification	Value
Annual Energy Consumption	153.3 Kilowatt Hours Per Year
Refrigerator Fresh Food Capacity	2.5 Cubic Feet
Freezer Capacity	1 Cubic Feet
Noise	38 dB
Installation Type	Freestanding
Part Number	BCD-100A
Special Features	Adjustable Shoe, Removable Storage Basket, Quiet, Removable Storage Shelves
Drawer Type	storage
Color	Black
Voltage	110 Volts
Crispers/Drawers	1
Defrost	Manual
Door Hinges	Right
Shelf Type	Glass
Shelves	2
Number Of Doors	2

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact WANAI customer service directly. Please have your model number (NB-100AFRIDGE) and purchase date ready when contacting support.
For further assistance, visit the official WANAI store:WANAI Store on Amazon

© 2025 WANAI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9M1S4Z6

More documents and user manuals: **https://manuals.plus/**