

SoundPEATS RunFree Headphones

SoundPEATS RunFree Open Ear Headphones Instruction Manual

Model: RunFree Headphones

Brand: SoundPEATS

1. PRODUCT OVERVIEW

The SoundPEATS RunFree Open Ear Headphones are designed for comfort and situational awareness, utilizing air conduction technology. They feature Bluetooth 5.3, 16.2mm dynamic drivers, and IPX4 water resistance, making them suitable for sports and daily use.




Image: SoundPEATS RunFree Open Ear Headphones.

2. SETUP

2.1 Wearing the Headphones

Proper placement ensures optimal sound quality and comfort. The headphones are designed to rest gently

over your ears, allowing you to remain aware of your surroundings.

Video: Demonstrates how to correctly wear the SoundPEATS RunFree headphones for a comfortable and secure fit.

To wear:

1. Hold the headset with both hands, separating the left and right chambers.
2. Place the headset over your ears, ensuring the speakers are positioned just outside your ear canals.
3. Adjust the headset to a comfortable angle, making sure the neckband rests gently on the back of your neck.




Image: Visual guide for wearing the RunFree headphones.

2.2 Power On/Off

To power on or off the headphones:

- **Power On:** When the headset is powered off, press and hold the power button for 3 seconds.
- **Power Off:** When the headset is powered on, press and hold the power button for 3 seconds.

2.3 Pairing

Follow these steps to pair your SoundPEATS RunFree headphones with a device:

1. Press and hold the power button for 3 seconds to turn on the headset. It will automatically enter pairing mode, and the indicator light will flash red and white.
2. Enable Bluetooth on your device (e.g., smartphone, tablet).
3. Select 'SOUNDPEATS RunFree' from the Bluetooth device list.
4. Once connected, the indicator light will stay white.

Video: Guide on how to pair the SoundPEATS RunFree headphones with a device.

| |  Air Conduction |  Bone Conduction |
|-----------------------------|---|---|
| Principle | Transmission of sound through air | Transmission of sound through bone |
| Listening Experience | Comfortable/Natural | Loud/Noisy |
| Water Resistance | Weak | Strong |
| Sound Leakage | Slight | Slight |
| Vibration Sensation | None | Present |
| Sound Quality | Good | Average |
| Low Frequency | Full | Average |

Image: Multi-point connection setup.

2.4 Multi-Point Pairing

The SoundPEATS RunFree headphones support multi-point connection, allowing you to connect to two devices simultaneously.

1. Turn on the headset and put it in pairing mode.
2. Connect the headset to your first device (Device A).
3. Disconnect the headset from Device A. The headset will re-enter pairing mode.
4. Connect the headset to your second device (Device B).
5. Manually reconnect the headset to Device A from its Bluetooth settings.
6. The headset is now connected to both Device A and Device B.

Video: Instructions for activating voice assistant and game mode on RunFree headphones.

3. OPERATING INSTRUCTIONS

3.1 Music Control

Control your audio playback using the physical buttons on the headset:

- **Increase Volume:** Press the '+' button.
- **Decrease Volume:** Press the '-' button.
- **Play/Pause:** Press the power button once.
- **Next Song:** Press and hold the '+' button.
- **Previous Song:** Press and hold the '-' button.

Video: Demonstrates how to control music playback using the headphone buttons.

3.2 Call Control

Manage your phone calls directly from the headphones:

- **Answer/End Call:** Press the power button once.
- **Reject Call:** Press and hold the power button for 1.5 seconds.

3.3 Voice Assistant and Game Mode

Access your device's voice assistant or switch to game mode for optimized audio latency:

- **Activate Voice Assistant:** Double-click the power button.
- **End Voice Assistant:** Double-click the power button.
- **Enter Game Mode:** Triple-click the power button.
- **Exit Game Mode:** Triple-click the power button.

| | | | | | | | |
|-------------------------------|---|-----------------------------|-------------------------------|-----------------------------------|-------------------------------|-------------------------|----------|
| Ordinary Headphones |  | Comfort of Wearing ★★★★★ | Safety of the Sports ★★★★★ | Accessible Communication ★★★★★ | Sports Sound Effects ★★★★★ | Way of Wearing ★★★★★ | In-ear |
| Open Wireless Headphones |  | Comfort of Wearing ★★★★★ | Safety of the Sports ★★★★★ | Accessible Communication ★★★★★ | Sports Sound Effects ★★★★★ | Way of Wearing ★★★★★ | Open-Ear |
| Traditional Sports Headphones |  | Comfort of Wearing ★★★★★ | Safety of the Sports ★★★★★ | Accessible Communication ★★★★★ | Sports Sound Effects ★★★★★ | Way of Wearing ★★★★★ | Over Ear |

Image: SoundPEATS App interface for managing headphone settings.

4. CHARGING

To charge your SoundPEATS RunFree headphones:

1. Insert the Type-C charging cable into the charging port located on the headset.
2. When charging, the indicator light will stay red.
3. When fully charged, the indicator light will turn white.

Video: Demonstrates how to charge the SoundPEATS RunFree headphones.



Image: Charging the RunFree headphones.

5. MAINTENANCE

To ensure the longevity and optimal performance of your SoundPEATS RunFree headphones, follow these

maintenance guidelines:

- **Cleaning:** Regularly wipe the headphones with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The headphones are IPX4 water-resistant, meaning they can withstand splashes and sweat. Do not submerge them in water. Ensure the charging port cover is securely closed when not charging to maintain water resistance.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Damage:** Do not drop, crush, or bend the headphones excessively.

6. TROUBLESHOOTING

If you encounter issues with your SoundPEATS RunFree headphones, try the following solutions:

6.1 Factory Reset

A factory reset can resolve many common issues, such as pairing problems or unresponsive controls.

1. While the headphones are in charging mode, press and hold the power button for 3 seconds.
2. The indicator light will flash red and white twice, indicating that the factory reset is complete.

Video: [Guide on how to perform a factory reset on the SoundPEATS RunFree headphones.](#)

6.2 Common Issues

- **No Sound:** Ensure the headphones are paired correctly and the volume is turned up on both the headphones and your device.
- **Cannot Pair:** Make sure the headphones are in pairing mode (flashing red and white light) and not connected to another device. Try turning Bluetooth off and on again on your device, or perform a factory reset.
- **Poor Sound Quality:** Check for interference from other wireless devices. Ensure the headphones are positioned correctly on your ears.
- **Charging Issues:** Verify the charging cable is securely connected and the power source is working. The indicator light should be red during charging.

7. SPECIFICATIONS

| Feature | Specification |
|-------------------------|--------------------------------|
| Model Name | RunFree Headphones |
| Bluetooth Version | 5.3 |
| Audio Driver Size | 16.2mm Dynamic Driver |
| Playtime | Up to 14 Hours |
| Water Resistance Level | IPX4 |
| Charging Port | Type C |
| Control Type | Physical Buttons |
| Connectivity Technology | Wireless |
| Ear Placement | Open Ear |
| Special Feature | Sports, Multi-Point Connection |

8. WARRANTY AND SUPPORT

SoundPEATS is committed to providing excellent customer service. Your SoundPEATS RunFree headphones come with a **12-month warranty**.

If you have any questions or require support, please contact SoundPEATS Customer Service. You can typically find contact information through your purchase platform:

- Navigate to "Account Service" > "Order History" > "Sold By" > "Ask Question" on your purchase platform.

Please do not hesitate to reach out for assistance with any product-related inquiries.