

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VEVOR](#) /

› [VEVOR Oversized Camping Folding Chair Instruction Manual](#)

VEVOR VEVOR Oversized Camping Folding Chair

VEVOR Oversized Camping Folding Chair Instruction Manual

MODEL: VEVOR OVERSIZED CAMPING FOLDING CHAIR

1. Introduction

Thank you for choosing the VEVOR Oversized Camping Folding Chair. This manual provides essential information for the safe and effective use, maintenance, and care of your new chair. Please read it thoroughly before first use and retain it for future reference.

Key Features:

- **600D Heat-resistant Oxford Cloth:** Constructed with durable 600D Oxford fabric, designed to withstand temperatures up to 200°C, offering tear and abrasion resistance for various outdoor conditions.
- **450lb Superior Load Capacity:** Features a thickened and reinforced steel pipe frame with an X-shaped bracket design, providing stable support for weights up to 450 pounds.
- **Soft & Comfortable Sitting Experience:** Lined with soft pearl cotton and a high backrest for neck support, ensuring comfort during extended use. Stable armrests and wide handles assist with standing.
- **Multiple Flexible Storage Bags:** Includes a cup holder, large side pockets for magazines or phones, and an insulated cooler bag for beverages.
- **Lightweight & Portable Design:** Weighing approximately 5.4kg (11.68 lbs), the chair folds quickly and comes with a waterproof PU carrying bag for easy transport and storage.

2. Setup

The VEVOR Oversized Camping Folding Chair requires no assembly. It is designed for quick and easy deployment.

Unfolding the Chair:

1. Remove the chair from its carrying bag.
2. Hold the chair by the top of the backrest and the armrests.
3. Pull the opposing sides of the chair outwards until the seat fabric is taut and the frame is fully extended. Ensure all four legs are firmly on the ground.

4. Verify that the chair is stable before sitting.



Image: The VEVOR Camping Chair set up in an outdoor environment, highlighting its readiness for use.

3. Operation

Your VEVOR camping chair is designed for comfort and convenience in various outdoor settings.

Using the Features:

- **Cup Holder:** Located on one armrest, the integrated cup holder is designed to securely hold your beverages.
- **Side Pockets:** Large side pockets are available for storing personal items such as mobile phones, books, or small accessories.
- **Insulated Cooler Bag:** An insulated bag is integrated into the other armrest, perfect for keeping drinks or snacks cool. Simply unzip, place items inside, and zip closed to maintain temperature.

Folding the Chair for Storage:

1. Ensure no items are left in the cup holder or storage pockets.
2. Grasp the fabric in the middle of the seat and pull upwards. The chair frame will begin to collapse inwards.
3. Continue to bring the sides of the chair together until it is fully folded into a compact shape.
4. Place the folded chair into its waterproof PU carrying bag for easy transport and protection.

Image: Detailed view of the chair's convenient storage features, including the cup holder and side pockets.

Image: The VEVOR Camping Chair folded and stored in its carrying bag, ready for transport.

4. Maintenance

Proper care will extend the life of your VEVOR Oversized Camping Folding Chair.

Cleaning Instructions:

- Always machine wash the chair fabric on a gentle cycle with cold water.
- Do not bleach.
- Allow the chair to air dry completely before folding or storing to prevent mildew and damage.

- For spot cleaning, use a mild soap solution and a soft cloth. Rinse thoroughly and air dry.

Storage:

- Store the chair in its carrying bag in a cool, dry place when not in use.
- Avoid prolonged exposure to direct sunlight or extreme weather conditions to prevent fabric degradation and frame corrosion.

5. Troubleshooting

If you encounter any issues with your VEVOR Oversized Camping Folding Chair, please refer to the following common solutions:

- **Difficulty Unfolding/Folding:** Ensure no fabric is caught in the frame joints. Apply gentle, even pressure when unfolding or folding. The mechanism should operate smoothly.
- **Instability:** Check that all four legs are fully extended and locked into place. Ensure the chair is on a flat, stable surface.
- **Damaged Fabric/Frame:** Discontinue use immediately if any part of the fabric is torn or the frame is bent or broken. Contact customer support for assistance.

6. Specifications

Feature	Detail
Brand	VEVOR
Model Name	VEVOR Oversized Camping Folding Chair
Color	Black
Product Dimensions (L x W x H)	24.8"D x 38.6"W x 38.9"H (980 x 630 x 990 mm)
Item Weight	11.68 pounds (5.4 kg)
Load-bearing Capacity	450 lbs (204 kg)
Material	Stainless Steel & Oxford Fabric & Mesh
Fabric Type	100% Oxford Cloth
Fill Material	Cotton (Pearl Cotton Lining)
Special Features	Cup Holders, Foldable, Insulated Cooler Bag, Side Pockets
Assembly Instructions	No assembly required
Recommended Uses	Camping, Beach, Lawn, Picnic, Fishing, Backpacking
UPC	840349924779



Material: Powder-coated Stainless Steel & Oxford Fabric & Mesh

Load-bearing Capacity: 204 kg / 450 Lbs

Net Weight (including all accessories): 5.9kg / 13 lbs

Gross Weight: 5.7kg / 12.6 lbs

Product Dimensions(LxWxG): 38.58" × 24.8" × 38.98" / 980× 630× 990 mm

Image: Technical drawing with key dimensions of the chair.

7. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact VEVOR customer service through their official website or the retailer where the product was purchased. Please have your model name and purchase date available when contacting support.