

## Sealy SL-HW-SN-109-BK

# Sealy Sound Machine & Bluetooth Speaker User Manual

Model: SL-HW-SN-109-BK

## INTRODUCTION

---

Thank you for choosing the Sealy Sound Machine & Bluetooth Speaker. This device is designed to help you relax and fall asleep with its soothing sounds and convenient night light. It also functions as a Bluetooth speaker for your audio needs. This manual provides important information on how to set up, operate, and maintain your device.

## SAFETY INFORMATION

---

**Please read all safety instructions carefully before use.**

- Use the correct type and age of batteries as specified.
- Avoid mixing old and new batteries, or different types of batteries.
- Be mindful of noise exposure limits, especially for prolonged use.
- Supervise use by children to ensure safe operation.
- Handle the device with care to prevent electric shock. Do not expose to water or excessive moisture.

## PACKAGE CONTENTS

---

Upon opening the package, please ensure all items are present:

- Sealy Sound Machine & Bluetooth Speaker Unit
- User Manual (this document)
- Power Cable (if applicable, not explicitly mentioned but implied by "Battery Powered" and typical devices)



Image: The Sealy Sound Machine shown in its retail packaging, highlighting key features and design.

## SETUP

---

1. **Unpacking:** Carefully remove the sound machine from its packaging.
2. **Placement:** Place the unit on a stable, flat surface away from direct sunlight, heat sources, and moisture. Ensure adequate ventilation around the device.
3. **Power Connection:** As the device is battery powered, ensure batteries are correctly inserted. If a power adapter is included (or for charging), connect it to the DC input port on the device and then to a standard wall outlet.

## OPERATING INSTRUCTIONS

---



Image: Front view of the Sealy Sound Machine, showcasing its speaker grille and the soft glow of the integrated night light.

1. **Power On/Off:** Locate the power button (usually on the top or side) and press it to turn the device on. Press again to turn off.
2. **Selecting Soothing Sounds:** Use the dedicated sound selection buttons or a dial to cycle through the 10 unique soothing sounds. Available sounds include Birds, Brown Noise, Gray Noise, Lullaby, Rain, Summer Night, Thunder, Twinkle, Waterfall, and White Noise.
3. **Adjusting Volume:** Use the volume up (+) and volume down (-) buttons to adjust the noise level to your preference.
4. **Night Light Function:** Press the night light button to activate the integrated night light. Press again to cycle through brightness levels or turn off the light. The adjustable intensity helps your eyes adapt to light changes.
5. **Bluetooth Pairing:**
  - Ensure the sound machine is powered on.
  - Activate Bluetooth mode on the sound machine (refer to specific button if available, otherwise it might be

automatic).

- On your mobile device or computer, go to Bluetooth settings and search for available devices.
- Select "Sealy Sound Machine" (or similar name) from the list to pair.
- Once paired, you can stream audio from your device to the Sealy Sound Machine.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the device. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place. If battery-powered, consider removing batteries to prevent leakage.
- **Battery Replacement:** Replace batteries when the device's performance diminishes. Ensure correct polarity when inserting new batteries.

## TROUBLESHOOTING

| Problem                    | Possible Cause                                                                     | Solution                                                                                                                  |
|----------------------------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| Device does not power on.  | Low or dead batteries; power cable not connected properly.                         | Replace batteries or ensure power cable is securely connected to both the device and the outlet.                          |
| No sound output.           | Volume too low; incorrect sound selected; Bluetooth not connected or source issue. | Increase volume; select a different sound; re-pair Bluetooth device or check audio source.                                |
| Night light not working.   | Night light function not activated; device power issue.                            | Press the night light button; ensure the device is powered on and has sufficient battery.                                 |
| Cannot pair via Bluetooth. | Device not in pairing mode; too far from source; interference.                     | Ensure device is in Bluetooth pairing mode; move closer to the source device; reduce interference from other electronics. |

## SPECIFICATIONS

**Model Number:** SL-HW-SN-109-BK

**Brand:** Sealy

**Color:** White

**Material:** Metal, Plastic

**Power Source:** Battery Powered

**Music Tracks:** Birds, Brown Noise, Gray Noise, Lullaby, Rain, Summer Night, Thunder, Twinkle, Waterfall, White Noise (10 unique sounds)

**Dimensions:** Approximately 6.61 x 6.3 x 2.52 inches (Package Dimensions)

**Weight:** Approximately 14.39 ounces (Package Weight)

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Sealy website. Keep your purchase receipt as proof of purchase for warranty claims.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question