

OTYSRH B0C9Q4DJS6

OTYSRH Wireless Bluetooth Keyboard and Mouse Set Instruction Manual

Model: B0C9Q4DJS6

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your OTYSRH Wireless Bluetooth Keyboard and Mouse Set. This ultra-slim, rechargeable combo is designed for compatibility with various devices, offering a quiet and efficient user experience.

PACKAGE CONTENTS

- 1 x Wireless Bluetooth Keyboard
- 1 x Wireless Bluetooth Mouse
- 1 x Charging Cable (Micro USB)
- 1 x User Guide (This document)

SETUP INSTRUCTIONS

1. Keyboard Bluetooth Connection

1. Ensure the keyboard is charged (refer to "Charging and Power Saving" section).
2. Locate the ON/OFF switch on the keyboard and slide it to the "ON" position.
3. Press the "Connect" button on the keyboard. The Bluetooth indicator light will start blinking, indicating it is in pairing mode.
4. On your device (tablet, smartphone, computer), go to Bluetooth settings and enable Bluetooth.
5. Search for available devices. You should see "Bluetooth Keyboard" or a similar name. Select it to pair.
6. If prompted, enter the pairing code displayed on your device using the keyboard and press Enter.
7. Once connected, the Bluetooth indicator light on the keyboard will stop blinking.



Image: Keyboard with power and connect buttons.

2. Mouse Bluetooth Connection

1. Insert 2 AAA batteries into the mouse (batteries not included). Ensure correct polarity.
2. Locate the ON/OFF switch on the bottom of the mouse and slide it to the "ON" position.
3. On your device, go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. You should see "Bluetooth Mouse" or a similar name. Select it to pair.
5. Once connected, the mouse will be ready for use.



Image: Mouse battery compartment and keyboard charging port. The mouse requires 2 AAA batteries.

OPERATING INSTRUCTIONS

Keyboard Functions

- **Multimedia Hotkeys:** The keyboard features dedicated multimedia hotkeys for volume control, play/pause, previous/next track, and other functions. These are typically accessed by pressing the **Fn** key in combination with the corresponding F-keys.
- **System Switching:** To optimize keyboard layout for different operating systems, press **Fn + Q** for Android, **Fn + W** for Windows, or **Fn + E** for iOS.



Image: Keyboard layout highlighting system switching keys (Fn+Q/W/E).

Mouse Functions

- **DPI Adjustment:** The mouse offers 3 adjustable DPI levels (800/1200/1600). Press the DPI button (usually located near the scroll wheel) to cycle through the sensitivity settings.
- **Silent Clicks:** The mouse is designed for quiet operation, suitable for environments requiring minimal noise.



Image: Mouse features, including 3 adjustable DPI settings and silent click functionality.

CHARGING AND POWER SAVING

Keyboard Charging

- Connect the provided Micro USB charging cable to the keyboard's charging port and to a USB power source.
- A full charge takes approximately 2 hours.
- The keyboard provides up to 150 hours of continuous use or 60 days of standby time on a single charge.

Automatic Sleep Mode

- To conserve power, both the keyboard and mouse will automatically enter sleep mode after 10 minutes of inactivity.
- To wake them up, simply press any key on the keyboard or click any button on the mouse.

SYSTEM COMPATIBILITY

The OTYSRH Wireless Bluetooth Keyboard and Mouse Set is compatible with a wide range of operating systems and devices:

- **Operating Systems:** Windows 7/8.1/10, Mac OS, iOS, Android, Chrome OS, Linux.
- **Compatible Devices:** Tablets (iPad, iPad Mini, iPad Pro, iPad Air), Smartphones (iPhone, Samsung, Android phones), Laptops, Personal Computers.

SUPPORTS TABLETS, SMARTPHONES AND COMPUTERS WITH BLUETOOTH CAPABILITY



Windows



Android



ios



Image: The keyboard and mouse are compatible with Windows, Android, and iOS devices.

SPECIFICATIONS

| Feature | Detail |
|---------------------------|--|
| Brand | OTYSRH |
| Model Number | B0C9Q4DJS6 |
| Color | Blue |
| Connectivity Technology | Bluetooth |
| Keyboard Layout | QWERTY |
| Number of Keys (Keyboard) | 78 |
| Keyboard Dimensions | 9.72 x 5.9 x 0.19 inches (247 x 150 x 5 mm) |
| Keyboard Weight | 189.2g (0.42 lbs) |
| Mouse Dimensions | 4.33 x 2.28 x 1.10 inches (110 x 58 x 28 mm) |

| Feature | Detail |
|--------------------------------|--|
| Mouse Weight | 44.8g (0.1 lbs) |
| Mouse DPI Levels | 800/1200/1600 |
| Keyboard Battery Life | Up to 150 hours continuous use, 60 days standby |
| Mouse Battery | 2 x AAA batteries (not included) |
| Operating System Compatibility | Windows 7/8.1/10, Mac OS, iOS, Android, Chrome OS, Linux |
| Special Features | Ergonomic, Rechargeable (keyboard), Ultra-slim, Portable, Silent Click (mouse) |



Image: Detailed dimensions of the keyboard and mouse, highlighting their thin and lightweight design.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the device.

- **Storage:** Store the keyboard and mouse in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care (Mouse):** Replace AAA batteries when performance degrades. Remove batteries if the mouse will not be used for an extended period to prevent leakage.
- **Charging (Keyboard):** Charge the keyboard regularly to maintain battery health. Avoid fully depleting the battery frequently.

TROUBLESHOOTING

| Problem | Solution |
|--|--|
| Keyboard/Mouse not connecting via Bluetooth. | <ul style="list-style-type: none"> ◦ Ensure both devices are turned ON. ◦ Make sure the keyboard's "Connect" button has been pressed to enter pairing mode. ◦ Check if Bluetooth is enabled on your host device. ◦ Ensure the devices are within the 10-meter operating range. ◦ Remove previous pairings from your device's Bluetooth list and try pairing again. ◦ Recharge the keyboard or replace mouse batteries. |
| Keyboard/Mouse frequently disconnects. | <ul style="list-style-type: none"> ◦ Ensure devices are fully charged/have fresh batteries. ◦ Reduce distance between the devices and remove any obstructions. ◦ Avoid interference from other wireless devices. |
| Keyboard keys not responding. | <ul style="list-style-type: none"> ◦ Check if the keyboard is powered on and connected. ◦ Ensure the keyboard is charged. ◦ Verify the correct system mode (Fn+Q/W/E) is selected for your device. |
| Mouse cursor erratic or not moving. | <ul style="list-style-type: none"> ◦ Replace the AAA batteries in the mouse. ◦ Ensure the mouse is on a clean, non-reflective surface. ◦ Check Bluetooth connection. |

WARRANTY AND SUPPORT

This OTYSRH product comes with a **12-month warranty** from the date of purchase. Additionally, a **30-day money-back guarantee** is offered.

For any questions, technical assistance, or warranty claims, please contact OTYSRH customer service. We aim to respond to inquiries within 24 hours.

Contact Information: Please refer to the contact details provided with your purchase documentation or visit the official OTYSRH store on Amazon: [OTYSRH Amazon Store](#).