

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COSTWAY](#) /

› [COSTWAY L-Shaped Reversible Corner Desk \(Model CB10122FR\) Instruction Manual](#)

COSTWAY CB10122FR

COSTWAY L-Shaped Reversible Corner Desk (Model CB10122FR) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your COSTWAY L-Shaped Reversible Corner Desk, Model CB10122FR. Please read carefully before beginning assembly and retain for future reference.

The desk features a versatile design, allowing it to be configured as an L-shaped corner desk or a long straight desk, providing ample workspace for one or two users. It includes a movable monitor stand for ergonomic comfort and a robust metal frame for stability.

SAFETY INFORMATION

- Assemble with care and verify stability on even surfaces.
- Do not exceed the total weight capacity of 115 kg (253 lbs).
- Ensure all screws and connections are tightened securely before use.
- Keep small parts away from children during assembly.

PACKAGE CONTENTS

Before starting assembly, please ensure all components listed below are present and undamaged:

- 1 x L-shaped computer desk (disassembled components)
- 1 x User Guide
- All necessary assembly hardware (screws, bolts, tools)

If any parts are missing or damaged, please contact customer support.

ASSEMBLY INSTRUCTIONS

For optimal assembly, it is recommended that two people work together. Please follow the steps carefully.

Dimensions



Image: All desk components and dimensions. The L-shaped configuration measures 150cm x 150cm x 74.5cm, and the straight configuration measures 240cm x 60cm x 74.5cm. The monitor stand is 40cm x 24cm x 10cm.

Step-by-Step Assembly Guide:

- 1. Prepare the Frames:** Attach the adjustable foot pads (part K) to the bottom of the main frame sections (parts 6, 9, 10, 14).
- 2. Assemble Corner Section:** Connect frame part 9 to frame part 10 using screws C and H. This forms the corner joint of the desk.
- 3. Connect Support Bars:** Attach support bar 11 to connector I using screw C. Then, connect support bar 12 to the assembled piece from the previous step using screw C.
- 4. Form the L-Shape Base:** Secure part 13 to the frame assembly from Step 2 using screw M. Then, attach frame part 14 to the assembled structure using screw E.
- 5. Add Diagonal Braces:** Fix diagonal brace 7 to the assembled frame using screw D. Similarly, fix diagonal brace 6 to the frame using screw E. These braces enhance stability.
- 6. Install Crossbars:** Attach crossbar 8 to the frame using screw G. Repeat for all necessary crossbars to ensure the frame is rigid.
- 7. Attach Desktop Panels:** Place desktop panel 2 onto the frame and secure it with screws F using the provided key. Connect desktop panels 3 and 2, and then 1 and 2, using wooden dowels (L) for alignment and screws F to secure them to the frame.

- Assemble Monitor Stand:** Connect parts 5 and 4 of the monitor stand using cam bolts A and cam locks B. Once assembled, place the monitor stand on the desktop. Cover any visible screw holes with stickers Q and R for a clean finish.
- Final Touches:** Insert the cable management grommets (part J) into the designated holes on the desktop. Cover any remaining exposed screw holes with stickers (part S).

Your browser does not support the video tag.

Video: Official assembly guide for the COSTWAY L-Shaped Reversible Corner Desk. This video demonstrates the step-by-step process of putting together the desk components, including attaching the frame, desktop panels, and monitor stand.

PRODUCT FEATURES

- Reversible Design (2 Forms):** The desk can be configured as a 150 x 150 x 74 cm L-shaped corner desk or a 240 x 60 x 74 cm long straight desk. This flexibility allows it to adapt to various room layouts and user needs, providing ample space for one or two people to work simultaneously.



Image: The desk shown in both its L-shaped and long straight configurations, highlighting its reversible design.

- Ergonomic Monitor Stand:** A 10 cm (4 inches) high movable stand is included, ideal for placing a laptop or monitor. This elevates your screen to a more ergonomic viewing height, reducing neck and eye strain. The stand can also be removed if more desktop space is desired.




Image: An illustration demonstrating the ergonomic benefits of using the monitor stand, promoting better posture.

- **Robust Metal Construction:** The desk features a reinforced metal structure, ensuring excellent stability and durability. It has a total weight capacity of 115 kg (253 lbs). Adjustable foot pads are included to maintain stability even on uneven flooring, protecting your floors from scratches.



Image: A detailed view of the desk's reinforced metal frame and adjustable foot pads, emphasizing stability and durability.

- **Integrated Cable Management:** Three cable holes are strategically placed on the desktop to help organize wires and maintain a tidy workspace. This feature is particularly useful for managing multiple electronic devices.

USAGE INSTRUCTIONS

- **Configuring the Desk:** The desk can be assembled in either an L-shape for corner placement or a long straight configuration. Refer to the assembly instructions for detailed steps on how to achieve your desired layout.
- **Using the Monitor Stand:** Place your laptop or monitor on the movable stand to elevate the screen to a comfortable viewing height. If you prefer more flat desktop space, the stand can be easily removed.
- **Cable Organization:** Utilize the three integrated cable holes to route and manage your device cables, keeping your workspace neat and free from clutter.
- **Adjusting Stability:** If the desk wobbles on an uneven floor, adjust the foot pads at the bottom of the legs until the desk is stable.

MAINTENANCE

- **Cleaning:** Wipe the desk regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the surface.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability and safety.
- **Weight Distribution:** Distribute weight evenly across the desktop to prevent stress on any single point.

TROUBLESHOOTING

- **Wobbling Desk:** If the desk is unstable, ensure all assembly screws are tightened. Adjust the leveling foot pads on the bottom of the legs to compensate for uneven flooring.
- **Difficulty Assembling:** Double-check the instruction manual to ensure all steps are followed correctly. Verify that all parts are oriented in the correct direction as shown in the diagrams. If issues persist, contact customer support.
- **Missing Parts:** If any parts are missing from the package, do not attempt to assemble the desk. Contact customer support immediately for assistance.

SPECIFICATIONS

Attribute	Value
Brand	COSTWAY
Model Number	CB10122FR
Color	Brown
Material	Engineered Wood, Metal
L-Shape Dimensions (L x W x H)	150P x 150I x 74H centimeters
Straight Desk Dimensions (L x W x H)	240 x 60 x 74 centimeters
Monitor Stand Dimensions (L x W x H)	40 x 24 x 10 centimeters
Item Weight	23.7 Kilograms
Recommended Max Load	115 Kilograms
Special Features	Reversible, Monitor Stand, Cable Management
Assembly Required	Yes
Recommended Assembly Persons	2

WARRANTY & SUPPORT

For warranty information, return policies, or to contact customer support for any product-related inquiries, please refer to the documentation included with your purchase or visit the official COSTWAY website. Ensure you have your model number (CB10122FR) and proof of purchase available when contacting support.

