

[Manuals.plus](#) /

› [DUKWIN](#) /

› DUKWIN Automatic Watch Winder Instruction Manual - Model DK184-LE (Wood Grain)

DUKWIN DK184-LE

DUKWIN Automatic Watch Winder Instruction Manual

Model: DK184-LE (Wood Grain)

1. INTRODUCTION

The DUKWIN Automatic Watch Winder is designed to keep your automatic watches wound and ready to wear. It simulates wrist movement to ensure your watches maintain accurate time and remain lubricated, extending their lifespan. This manual provides essential information for the safe and efficient operation of your watch winder.



Image: The DUKWIN Automatic Watch Winder, displaying its capacity for multiple watches and internal illumination.

2. SAFETY INFORMATION

- Read all instructions thoroughly before operating the device.
- Keep the watch winder away from water or any liquids to prevent electric shock.
- Use only the power adapter supplied with the unit. Using an incorrect adapter may damage the device or pose a fire hazard.
- Do not attempt to disassemble, repair, or modify the unit. Contact customer support for service.
- Place the winder on a stable, level surface to prevent it from falling.
- Avoid exposing the unit to direct sunlight, high temperatures, or high humidity.

3. PACKAGE CONTENTS

Please check the package for the following items:

- DUKWIN Automatic Watch Winder Unit
- AC Power Adapter
- Flexible Watch Pillows (pre-installed or separate)
- Security Key (for the lockable front door)
- Additional Black Ring (for longer watch straps)

4. PRODUCT FEATURES

4.1. Crafted Design and Security

The DUKWIN watch winder is constructed from high-quality materials, featuring a smooth finish and an elegant wood grain appearance. Its compact size allows for versatile placement. A transparent glass window provides a clear view of your watches while keeping them protected. The unit includes a security lock mechanism to prevent accidental opening and unauthorized access.

YOUR ENTIRE COLLECTION INSIDE



Automatic Watch Rotator



Unlock the front door with the key



Storage Compartment

Image: Detail of the lockable front door, highlighting the security feature.

4.2. Ultra-Quiet Motor and LED Illumination

Equipped with an imported Japanese Mabuchi motor, the winder operates at an ultra-low noise level of less than 5 dB, ensuring it does not disturb your sleep or daily activities. This high-efficiency motor minimizes power consumption. Integrated blue LED lighting illuminates your watch collection, making it easy to view even in low-light conditions and adding an aesthetic touch.

QUIET SLEEP SOUNDLY



Less Than 5 DB-SUPER Quiet Motor
Low noise, does not disturb your sleep



90db

Alarm Clock



50db

Conversation



20db

Night Sound



5db

Watch Winder

Image: The watch winder with its blue LED lights active, showcasing the illuminated watches.

4.3. Capacity and Flexible Watch Pillows

This watch winder provides 8 slots for automatic watch winding and an additional 4 slots for static watch storage, offering maximum flexibility for your collection. The flexible memory foam watch pillows are designed to accommodate watch dials up to 65mm and watch bands ranging from 130mm to 220mm, fitting over 99% of automatic mechanical watches for both men and women. An extra black ring is included to secure watches with longer straps.



Image: A detailed view of the flexible watch pillow, illustrating its design and how watches are placed.

5. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the watch winder and all accessories from its packaging.
2. **Placement:** Choose a stable, flat, and dry surface for the watch winder, away from direct sunlight or heat sources.
3. **Power Connection:** Locate the DC input port on the back of the unit. Insert the provided AC power adapter into this port.
4. **Power On:** Plug the AC power adapter into a suitable wall outlet. The unit is now ready for operation.

6. OPERATING INSTRUCTIONS



6.1. Placing Watches

1. Open the front door of the watch winder using the provided key.

2. Gently place your automatic watches onto the flexible watch pillows in the winding slots. Ensure each watch is securely fitted.
3. If your watch strap is particularly long, use the additional black ring to help secure the watch firmly on the pillow.
4. Close and lock the front door for security.

6.2. Selecting Rotation Modes

The DUKWIN watch winder features 4 distinct rotation modes to accommodate various automatic watch movements. Use the control knob, typically located on the back or side of the unit, to select your desired mode.



- Mode1** Rotate 2 minutes clockwise, rest for 6 minutes, cycle repeat
- Mode2** Rotate 2 minutes counter clockwise, rest for 6 minutes, cycle repeat
- Mode3** Rotate 2 minutes clockwise, rest for 6 minutes, Rotate 2 minutes counter clock-wise, rest for 6 minutes, cycle repeat
- Mode4** Rotate 5 minutes clockwise, rotate 5 minutes counter -clockwise, repeat above for 3 hours, rest for 9 hours, cycle repeat.

Image: Visual representation of the control knob and the four available rotation modes.

- **Mode 1:** Rotates for 2 minutes clockwise, then rests for 6 minutes. This cycle repeats.
- **Mode 2:** Rotates for 2 minutes counter-clockwise, then rests for 6 minutes. This cycle repeats.
- **Mode 3:** Rotates for 2 minutes clockwise, rests for 6 minutes, then rotates for 2 minutes counter-clockwise, rests for 6 minutes. This cycle repeats.

- **Mode 4:** Rotates for 5 minutes clockwise, then 5 minutes counter-clockwise. This sequence repeats for 3 hours, followed by a 9-hour rest period. This entire cycle then repeats.

Choose the mode that best suits the winding requirements of your specific automatic watch. Consult your watch's manufacturer guidelines if unsure.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the exterior surfaces of the watch winder.
- **Avoid Chemicals:** Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.
- **Dust Protection:** Keep the front door closed when not accessing watches to prevent dust accumulation inside the unit.
- **Pillow Care:** The watch pillows can be gently wiped with a damp cloth if necessary, then allowed to air dry completely before reuse.

8. TROUBLESHOOTING

- **Winder is not operating:**
 - Ensure the power adapter is securely plugged into both the winder and a working wall outlet.
 - Check if the power outlet is functional by plugging in another device.
- **Watches are not winding:**
 - Verify that the watches are correctly seated on the flexible pillows and are not obstructed.
 - Confirm that the selected rotation mode is appropriate for your specific automatic watch movement. Some watches require specific winding directions (clockwise, counter-clockwise, or bi-directional).
- **Excessive noise during operation:**
 - Ensure the watch winder is placed on a completely flat and stable surface.
 - Check that no watches or other objects are rubbing against the rotating parts.
 - If the noise persists and is significantly louder than the specified <5 dB, contact customer support.

9. SPECIFICATIONS

Feature	Detail
Model Number	DK184-LE
Dimensions (L x W x H)	28 cm x 17 cm x 38 cm (11.02 in x 6.72 in x 14.94 in)
Weight	6.44 kg
Watch Capacity	8 winding slots + 4 storage slots
Motor Type	Japanese Mabuchi Motor
Noise Level	< 5 dB
Rotation Modes	4 programmable modes

Illumination	Blue LED Light
Power Source	AC Adapter



Image: The watch winder with its physical dimensions clearly indicated.

10. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact the retailer where the DUKWIN Automatic Watch Winder was acquired. Keep your proof of purchase for warranty claims.

For technical support, troubleshooting assistance beyond this manual, or service inquiries, please contact DUKWIN customer service. Contact details can typically be found on the manufacturer's official website or through your point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question