

[Manuals.plus](#) /

› [Brightup](#) /

› Brightup Beard Trimmer YH-7282 User Manual

Brightup YH-7282

Brightup Stainless Steel All-in-One Groomer User Manual

Model: YH-7282

Brand: Brightup

IMPORTANT SAFETY INFORMATION

Do not use in shower or near water sources. Keep away from children.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

PRODUCT OVERVIEW

The Brightup Stainless Steel All-in-One Groomer (Model YH-7282) is a versatile 22-piece grooming kit designed for comprehensive hair removal and styling. It includes various attachments for beard, mustache, face, nose, ear, and body grooming, offering precision and convenience for all your personal care needs.

Package Contents

- Trimmer Handle
- Precision Trimmer Head
- Micro Foil Shaver Head
- Body Hair Trimmer Head
- Nose & Ear Trimmer Head
- Full-size Trimmer Head
- Design Trimmer Head
- Adjustable Beard & Stubble Guard
- Multiple Fixed Length Guide Combs (8 pieces)
- Cleaning Brush
- USB Charging Cable
- Storage Pouch



Quick Cleaning

Steel blades and guards easily detach for easy cleaning



Fully
washable



Easy
to clean



Detailed view of the trimmer handle, highlighting its metal material, power switch, and LED display for battery status.

Attachment Heads

- **Full-size Trimmer:** Ideal for general hair cutting and trimming on the head and face.
- **Precision Trimmer:** For detailed styling, sharp lines, and intricate designs.
- **Micro Foil Shaver:** Provides a close, smooth shave for a clean finish.
- **Body Hair Trimmer:** Designed for safe and efficient grooming of body hair.
- **Nose & Ear Trimmer:** Safely removes unwanted hair from nose and ears.
- **Design Trimmer:** For creating unique patterns and precise edges.

Premium All-In-One Trimmer

No blade oil needed



Design trimmer



Micro foil shaver



Nose / Ear trimmer



Precision trimmer



Body hair trimmer




8 Limited Comb Attachments



Full size trimmer



An overview of the premium all-in-one trimmer heads, including the design trimmer, micro foil shaver, nose/ear trimmer, precision trimmer, and body hair trimmer.



2200mA
Battery capacity

Rechargeable Lithium-Ion Battery

Usb charging multiple charging modes



Computer



USB Charger



Powerbank



Laptop

The 6-in-1 beard grooming kit, illustrating the main trimmer and its interchangeable heads for full-size trimming, body hair, design, nose/ear, and micro foil shaving.


Guide Combs

The kit includes a variety of guide combs for achieving different hair lengths, from short stubble to longer beard styles. An adjustable comb provides fine-tuned control over trimming length.

- **Adjustable Beard & Stubble Guard:** Allows for precise length settings for beard and stubble.
- **Fixed Length Guide Combs:** Eight combs ranging from 3mm to 12mm for consistent cutting lengths.

6 In 1 Beard Grooming Kit For Men

Perfect for plenty of options



A display of the eight limited comb attachments, including the adjustable precision trimmer comb and various fixed-length combs for the full-size trimmer.

SETUP

Charging the Trimmer

Before first use, fully charge the trimmer. Connect the USB charging cable to the trimmer's charging port and plug the other end into a compatible USB power source (e.g., computer, USB charger, power bank, laptop). The LED display will show the charging progress.

Long Standby Time

Up to 4 hours of cordless run time



The rechargeable Lithium-Ion battery can be charged via USB, offering multiple charging modes including computer, USB charger, power bank, and laptop.

Attaching/Detaching Heads

To attach a head, align the head with the trimmer body and press firmly until it clicks into place. To detach, gently push the head forward or backward (depending on the head type) until it releases from the main unit. Ensure the trimmer is turned off before changing heads.

OPERATION

General Trimming Tips

For best results, ensure your hair is clean and dry before trimming. Use slow, controlled movements. For longer hair, trim in stages to avoid pulling. Always use the appropriate attachment head and guide comb for the desired length and area.

Using Specific Attachments

- **Beard & Mustache:** Use the full-size or precision trimmer with an adjustable or fixed guide comb to achieve your desired beard length and shape.
- **Hair Clipping:** Attach the full-size trimmer with appropriate guide combs for haircuts. The kit includes specialized ear guards for precise trimming around the ears.
- **Body Grooming:** Use the body hair trimmer for sensitive areas. The micro foil shaver can be used for a closer, smoother finish.
- **Nose & Ear Hair:** Insert the nose & ear trimmer head and gently insert into nostrils or ear canals to trim unwanted hair.

Self-Sharpening Stainless Steel Technology

Made in metal,
maintenance-free blades



Metal material

Power switch

LED Display

The Brightup trimmer in use, demonstrating its cordless run time of up to 4 hours, ideal for extended grooming sessions.

MAINTENANCE

Cleaning the Trimmer

The Brightup Groomer is fully washable for easy cleaning. After each use, detach the blade head and rinse it under running water. Use the included cleaning brush to remove any trapped hairs from the blades and the trimmer body. Ensure the trimmer is completely dry before storage.



The trimmer is fully washable, allowing for quick and easy cleaning of its steel blades and guards by simply detaching them and rinsing under water.

Blade Care

The trimmer features self-sharpening stainless steel blades, designed for long-lasting sharpness and maintenance-free use. Regular cleaning helps maintain optimal performance.

TROUBLESHOOTING

Issue	Possible Cause / Solution
Trimmer not turning on	Battery is low or depleted. Fully charge the trimmer. Ensure the power button is pressed firmly.
Blades pulling hair	Blades may be clogged with hair. Clean the blades thoroughly. Ensure the correct attachment is securely in place.
Reduced performance / Weak motor	Battery is low. Fully charge the trimmer. Blades may be dirty or require lubrication (if applicable, refer to specific blade care instructions).
Trimmer not charging	Check the USB cable and power adapter for damage. Try a different USB port or power source. Ensure the charging cable is securely connected to the trimmer.

SPECIFICATIONS

Feature	Detail
Product Dimensions	9 x 6.5 x 2.1 inches; 1.19 Pounds
Item Model Number	YH-7282
Date First Available	July 16, 2023
Manufacturer	Brightup
Color	Silver
Hair Type	All
Power Source	Battery Powered, Corded Electric

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Brightup customer service directly. Keep your purchase receipt for any warranty claims.

You can also visit the official Brightup Store on Amazon for more information and support: [Brightup Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question