

MCombo 7111

MCombo Small Power Lift Recliner Chair 7111 Instruction Manual

Model: 7111 (6160-7222)

INTRODUCTION

Thank you for choosing the MCombo Small Power Lift Recliner Chair. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new recliner. Please read these instructions carefully before use and retain them for future reference. This chair is specifically designed for petite individuals, recommended for heights between 4'6" and 5'2".

SAFETY INFORMATION

WARNING: Always assemble the chair according to the provided instructions. Do not exceed the weight capacity of 320 lbs. Be cautious when using the power lift assistance feature. Keep the anti-falling ropes in good condition and do not tamper with them. Always supervise children around the chair.

- Ensure all connections are secure before operating the chair.
- Keep hands and feet clear of moving parts during operation.
- Do not allow pets to play near or under the chair.
- Unplug the chair from the power outlet before cleaning or maintenance.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Backrest
- Armrests (2)
- Accessories box
- Manual
- Base



Figure 1: Packaging and included components.

ASSEMBLY INSTRUCTIONS

The MCombo Power Lift Recliner is designed for easy assembly, typically taking a novice about 20 minutes with no tools required. Follow these steps:

1. Unpack all components from the two boxes.
2. Place the base of the chair on a flat, stable surface.
3. Carefully slide the backrest onto the base until it clicks securely into place.
4. Attach the armrests to the sides of the chair, ensuring they are firmly connected.
5. Connect the power cables located at the back of the chair. Ensure all connections are tight and wires are not pinched by moving parts.
6. Plug the power adapter into a wall outlet.

**Everything
is right at hand.**

- 2 Anti-falling Ropes**
- 2 USB Charge Ports**
- 2 Cup Holders**
- 2 Side & Front Pockets**
- Overstuffed Armrests**

MCombo

Figure 2: Visual guide for chair assembly.

OPERATING INSTRUCTIONS

Your MCombo recliner features multiple functions for enhanced comfort and convenience. Use the provided remote controls to operate the chair.

Power Lift Assistance

The counter-balanced lift mechanism, powered by a TUV certified motor, assists users in standing up easily without straining the back or knees. To activate:

- Press the 'Up' arrow button on the main remote control to gently lift the chair.
- Press the 'Down' arrow button to lower the chair back to a seated position.

Video 1: Demonstration of the power lift function, showing the chair smoothly raising and lowering.

Reclining Function

The chair can recline up to a maximum angle of 140°. To recline:

- Press the 'Recline' button on the main remote to extend the footrest and lean the backrest.

- Adjust to your preferred position.

Video 2: Overview of the MCombo Small Power Lift Recliner 7111, showcasing its various features including reclining.

Adjustable Power Headrest

The adjustable headrest allows for custom comfort, especially when reclined, enabling you to look forward without straining your head or neck.

- Use the dedicated headrest buttons on the main remote to adjust its angle.



Figure 3: Adjustable power headrest in use, providing neck support.

Lumbar & Seat Heating and Massage

The chair features dual-zone heating for the lumbar and seat areas, and a vibrating massage function. These functions operate independently.

- Use the secondary remote control for heating and massage functions.
- Press the 'HEAT' button to activate or deactivate heating.
- Select desired massage mode, intensity, and area (leg, thigh, lumbar, back) using the respective buttons.
- Set a timer for massage sessions if desired.

Massage & Dual-Zone Heating

Heating function works separately from vibration.

- **8 Vibration Nodes**
- 3 Massage Modes**
- 3 Intensity Levels**
- **Lumbar & Seat Heating**



Figure 4: Remote control for massage and dual-zone heating.

USB Charging Ports & Cup Holders

The chair includes dual USB ports for charging low-power devices and convenient cup holders.

- The USB ports are located on the side of the chair. They are suitable for charging devices like iPhones and iPads.
- Use the integrated cup holders for beverages.



Figure 5: USB and Type-C charging ports.

MAINTENANCE AND CARE

Proper care will extend the life of your MCombo recliner.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the faux leather upholstery.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Mechanism:** Periodically check all bolts and screws to ensure they are tight. Do not lubricate the lift mechanism unless specified by the manufacturer.
- **Cables:** Ensure all power cables are free from kinks, pinches, or damage. Keep them clear of moving parts.

TROUBLESHOOTING

If you encounter issues with your recliner, refer to the following common solutions:

- **Chair not responding:** Ensure the power cord is securely plugged into both the chair and a working wall outlet. Check for any tripped circuit breakers.
- **Motor noise:** A slight humming sound during operation is normal. If the noise is excessive or unusual, discontinue use and contact customer support.
- **Inconsistent movement:** Check all cable connections to ensure they are properly seated. Ensure no obstructions are hindering the chair's movement.
- **Heating/Massage not working:** Verify the remote control batteries (if applicable) and ensure the chair is powered on.

If problems persist after attempting these steps, please contact MCombo customer support.

SPECIFICATIONS

Feature	Detail
Brand	MCombo
Model Name	7111 (6160-7222)
Color	Cream White
Product Dimensions	36.2"D x 30.3"W x 41.3"H
Size	Small (Recommended Height: 4'6"-5'2")
Maximum Weight Recommendation	320 Pounds
Special Features	Power Lift Assistance, Adjustable Headrest, Lumbar & Seat Heating, USB Charging Ports, Cup Holders
Upholstery Material	Faux Leather (Acrylic)
Fill Material	Foam
Reclining Position Count	2 (Max 140° Recline)
Item Weight	144.4 pounds

Feature	Detail
Motor Type	Single Motor

WARRANTY AND SUPPORT

MCombo provides a 2-Year Limited Warranty covering the reclining and lift mechanism, electrical parts, upholstery material, cushions, and the wood and metal frame. For warranty claims or technical assistance, please contact MCombo customer support. You can find more information and contact details on the official MCombo website or through your purchase platform.