

FQWYNMZ 7L Portable Air Cooler

FQWYNMZ 7L Portable Air Cooler User Manual

Model: 7L Portable Air Cooler

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep the appliance out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the appliance on a stable, level surface to prevent tipping.
- Do not block air inlets or outlets.
- Only use clean water in the water tank.
- Do not use the appliance near flammable materials or gases.

PRODUCT OVERVIEW

The FQWYNMZ 7L Portable Air Cooler is a multi-functional appliance designed to cool, humidify, and circulate air. It features a 7-liter water tank, three operational modes, three fan speeds, a timer function, and remote control capability.

Components:

- Main Unit (with control panel and LED display)
- Water Tank (7L capacity)
- Remote Control
- Ice Boxes (5 included)
- Power Cord
- Caster Wheels (pre-installed or to be attached)



Figure 1: FQWYNMZ 7L Portable Air Cooler. A white, tower-style portable air cooler with a visible water level indicator on the front and control panel on top. The front grille shows blue internal lighting.

SETUP

1. **Unpacking:** Carefully remove the air cooler and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Position the air cooler on a firm, level surface. Ensure there is adequate space around the unit for proper airflow.
3. **Filling the Water Tank:**
 - Locate the upper water tank inlet.
 - Pour clean, cool water into the upper tank. The unit features a 7L large-capacity double water tank.
 - Monitor the water level through the visual water window on the lower tank to avoid overfilling. Do not exceed the "MAX" line.
4. **Adding Ice Boxes (Optional for Enhanced Cooling):**

- For faster and stronger cooling, place the provided ice boxes into the freezer until completely frozen.
- Once frozen, place the ice boxes into the water tank. The unit comes with 5 ice crystals for super cooling performance.

5. **Power Connection:** Insert the power plug into a suitable electrical outlet.

OPERATING INSTRUCTIONS

The air cooler can be operated using the control panel on the top of the unit or the wireless remote control.

Control Panel and LED Display:

The LED display shows current settings such as fan speed, mode, and timer. Buttons on the control panel allow direct access to all functions.

Remote Control:

The remote control allows operation from a distance of up to 6 meters. Ensure there are no obstructions between the remote and the unit's sensor.

Functions:

- **Power On/Off:** Press the power button to turn the unit on or off.
- **Fan Speed:** Select from three speed levels: **Low**, **Medium**, or **High**.
- **Operational Modes:** Choose between three modes:
 - **Natural Wind:** Simulates a natural breeze.
 - **Sleep Wind:** Provides a quieter, gentler airflow for nighttime use.
 - **Standard Wind:** Consistent airflow at the selected speed.
- **Timer Function:** Set the operating time from 1 to 12 hours. The unit will automatically turn off after the set duration.
- **Oscillation:** Activate the oscillation function to distribute airflow up to 60 degrees horizontally across the room. Press the oscillation button again to stop the movement.
- **Cooling/Humidifier Function:** This function is active when water is present in the tank. The unit will draw water from the tank to cool and humidify the air.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air cooler. Always unplug the unit before cleaning or performing any maintenance.

Cleaning the Water Tank:

1. Unplug the air cooler from the power outlet.
2. Drain any remaining water from the tank.
3. Clean the water tank with a soft cloth and mild detergent. Rinse thoroughly with clean water.
4. Allow the tank to air dry completely before refilling or storing.

Cleaning the Filter/Cooling Pad:

1. Refer to the product diagram to locate and carefully remove the filter/cooling pad assembly.
2. Rinse the filter/cooling pad under running water to remove dust and debris. For stubborn dirt, use a soft brush.
3. Ensure the filter/cooling pad is completely dry before reinserting it into the unit.

Exterior Cleaning:

Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Storage:

If storing the unit for an extended period, ensure the water tank and filter are clean and dry. Store the air cooler in a cool, dry place,

preferably in its original packaging.

TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Unit does not power on.	No power supply; Power cord not properly connected.	Check if the unit is plugged into a working outlet; Ensure the power cord is securely connected.
Weak or no airflow.	Air inlets/outlets blocked; Filter/cooling pad dirty.	Clear any obstructions; Clean the filter/cooling pad as per maintenance instructions.
No cooling effect.	Water tank empty; No ice boxes used; Cooling pad dry.	Fill the water tank; Add frozen ice boxes; Ensure the cooling pad is saturated with water.
Water leakage.	Water tank overfilled; Unit not on a level surface.	Do not exceed the "MAX" water level; Place the unit on a stable, level surface.
Remote control not working.	Batteries depleted; Obstruction between remote and unit.	Replace remote control batteries; Ensure clear line of sight to the unit's sensor.

SPECIFICATIONS

Feature	Detail
Brand	FQWYNMZ
Model	7L Portable Air Cooler
Voltage	220V
Power	60W
Water Tank Capacity	7 Liters
Fan Speeds	3 (Low, Medium, High)
Operational Modes	3 (Natural Wind, Sleep Wind, Standard Wind)
Timing Function	1-12 hours
Oscillation Angle	Up to 60 degrees
Noise Level	≤58dB
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	11.02 pounds
Included Components	Air cooler, 5 Ice boxes, Remote control

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

If you have any questions or require assistance, please contact FQWYNMZ customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question