

[Manuals.plus](#) /

› [WEEWAY](#) /

› WEEWAY 68-Inch Multi-Level Cat Tree Instruction Manual

WEEWAY MPJ-AK-002GR

WEEWAY 68-Inch Multi-Level Cat Tree Instruction Manual

Model: MPJ-AK-002GR

INTRODUCTION

Thank you for choosing the WEEWAY 68-Inch Multi-Level Cat Tree. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your cat tree. Please read these instructions carefully before assembly and retain them for future reference.

SAFETY INFORMATION

- Ensure all parts are securely fastened before allowing pets to use the cat tree.
- Place the cat tree on a flat, stable surface to prevent tipping.
- Utilize the included anti-toppling strap to secure the cat tree to a wall for enhanced stability, especially in households with active or multiple cats.
- Regularly inspect the cat tree for loose parts, damage, or wear and tear. Tighten screws and replace damaged components as needed.
- Keep the cat tree indoors and in a dry environment.

SETUP AND ASSEMBLY

The WEEWAY 68-Inch Multi-Level Cat Tree is designed for straightforward assembly. Detailed graphic instructions are included in the packaging to guide you through each step. Assembly typically takes approximately 41 minutes.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the separate instruction sheet.
2. Follow the numbered steps in the graphic instructions to connect the base, posts, platforms, and condos.
3. Ensure all screws are tightened firmly but do not overtighten.
4. Attach the anti-toppling strap to the designated point on the cat tree and secure it to a wall stud using appropriate hardware (not included).
5. Once assembled, gently test the stability of the cat tree before allowing your pets to use it.

PREVENT TIPPING



Attach to the wall to prevent wobbling or tipping over



Give your cat as much protection as possible

Image: Detail of the anti-toppling strap, illustrating how to secure the cat tree to a wall for enhanced stability.

PRODUCT DIMENSIONS





Image: Product dimensions diagram, indicating the overall height of 68 inches and various platform sizes.

OPERATING INSTRUCTIONS

The WEEWAY Multi-Level Cat Tree provides a comprehensive activity center for your feline companions, offering various features for play, rest, and exercise.

Features:

- **Multi-Level Platforms:** The tree features multiple platforms at varying heights, allowing cats to climb, observe their surroundings, and find individual spaces.
- **Cozy Condos:** Two enclosed condos offer private, comfortable retreats for cats to nap or hide.
- **Sisal Scratching Posts and Ramp:** Strategically placed sisal-wrapped posts and a scratching ramp provide durable surfaces for cats to sharpen their claws, helping to protect household furniture.
- **Plush Perches and Hammocks:** Soft, padded perches and comfortable hammocks offer elevated resting spots.
- **Dangling Toys:** Integrated dangling balls encourage playful interaction and exercise.



Image: The WEEWAY 68-Inch Multi-Level Cat Tree, showcasing its various platforms, condos, and scratching posts.



Image: Cats enjoying the cat tree, demonstrating the soft cushions and overall stability during use.

MAINTENANCE

Proper maintenance ensures the longevity and safety of your cat tree.

- **Cleaning:** For plush surfaces, use a lint roller or a vacuum cleaner with a brush attachment to remove pet hair and debris. Spot clean soiled areas with a mild pet-safe cleaner and a damp cloth. Avoid saturating the material.
- **Sisal Posts:** The natural sisal ropes are durable for scratching. If the ropes become frayed or loose, they can be re-secured or replaced if necessary.
- **Structural Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten any loose fasteners to maintain stability.
- **Environmental Care:** Keep the cat tree in a dry indoor environment to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your WEEWAY Cat Tree, consider the following:

- **Wobbling:** Ensure the cat tree is placed on a level surface. Verify that all assembly screws are tightened. Confirm the anti-toppling strap is securely attached to both the cat tree and a wall stud.
- **Cats Not Using Scratching Posts:** Encourage use by sprinkling catnip on the sisal posts or gently guiding your cat's paws to the scratching surface.
- **Damaged Components:** If any part of the cat tree becomes damaged or worn, discontinue use immediately to prevent injury to your pet. Contact customer support for potential replacement parts.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	24" x 20" x 68"
Model Number	MPJ-AK-002GR
Material	Engineered Wood, Sisal Rope, Plush Fabric
Brand	WEEWAY
UPC	749655393425
Pet Type	Cat
Mounting Type	Wall Mount (Anti-toppling strap included)
Number of Levels	3
Color	Grey

WARRANTY

This WEEWAY Cat Tree includes a 30-day replacement warranty. Please retain your proof of purchase for any warranty claims.

SUPPORT

For any questions, concerns, or assistance with your WEEWAY Cat Tree, please do not hesitate to contact WEEWAY customer support. Refer to the contact information provided with your purchase or visit the official WEEWAY website for support details.