
[Manuals.plus](#) /

› [About Vintage](#) /

› About Vintage 1960 Racing Chronograph Watch Instruction Manual

About Vintage 1960

About Vintage 1960 Racing Chronograph Watch Instruction Manual

Model: 1960

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your About Vintage 1960 Racing Chronograph Watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



Image: The About Vintage 1960 Racing Chronograph Watch featuring a midnight blue dial, silver-tone case, and a brown perforated leather

strap.

PRODUCT FEATURES

The About Vintage 1960 Racing Chronograph Watch combines classic design with robust construction. Key features include:

- **Case:** 40mm 316L high-precision stainless steel case with a screw-down caseback.
- **Movement:** Reliable Miyota 6S20 Quartz Chronograph movement.
- **Glass:** Domed sapphire crystal with anti-reflective coating for enhanced durability and clarity.
- **Water Resistance:** Tested for 10 ATM (100 meters / 330 feet), suitable for splashes, rain, and showering. Not recommended for diving.
- **Strap:** Premium Italian leather strap, 20mm wide, 19cm length (suitable for wrists with a circumference of approximately 15-20 cm).
- **Dial:** Midnight blue dial with chronograph sub-dials and tachymeter scale.



Image: A detailed diagram highlighting the watch's features, including water resistance, chronograph function, hands and hour markers, crown, movement, case material, glass, and watch strap details.

SETUP

Setting the Time

1. Pull the crown (B) out to position 2.
2. Turn the crown to set the hour and minute hands to the correct time.
3. Push the crown back to position 1.

Adjusting the Strap

The watch comes with a leather strap that can be adjusted using the buckle. Ensure the strap is snug but comfortable on your wrist. The strap length is 19 cm, suitable for wrists with a circumference of approximately 15-20 cm.




Image: A watch worn on a wrist, illustrating how the strap fits. The text indicates that the 19 cm leather strap is suitable for wrists with a circumference of approximately 15-20 cm.

OPERATING INSTRUCTIONS

Chronograph Function

The chronograph allows for precise measurement of elapsed time.

1. **Start:** Press button (A) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press button (A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping, press button (C) to reset the chronograph hands to their zero positions.

Note: Refer to the technical drawing in the Specifications section for button (A), (B), and (C) locations.

MAINTENANCE

Cleaning

Wipe the watch case and sapphire crystal with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. If the strap becomes wet, allow it to air dry naturally.

Water Resistance

Your watch is water-resistant to 10 ATM (100 meters / 330 feet). This means it is suitable for everyday use, including splashes, rain, and showering. However, it is not designed for diving or prolonged submersion. Ensure the crown is fully pushed in before any contact with water.



Image: A close-up of the watch on a wrist, with an overlay confirming its 10 ATM water resistance rating. It also advises against use when diving.

Battery Replacement


The Miyota 6S20 Quartz movement is powered by a battery. When the battery needs replacement, it is recommended to take your watch to a qualified watchmaker or an authorized service center to ensure proper sealing and maintain water resistance.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Chronograph Hands Not Resetting to Zero:** This can sometimes be recalibrated. Consult a professional watchmaker if the issue persists after attempting a reset.
- **Water Inside the Watch:** If you notice condensation or water inside the watch, immediately take it to a professional watchmaker for inspection and repair to prevent further damage.

SPECIFICATIONS

Feature	Detail
Model Number	1960
Case Material	316L High Precision Stainless Steel
Case Diameter	40 mm
Case Thickness	12 mm
Movement	Miyota 6S20 Quartz Chronograph
Glass	Domed Sapphire Crystal with Anti-reflective Coating
Water Resistance	10 ATM / 100 meters / 330 feet
Strap Material	Premium Italian Leather
Strap Width	20 mm
Strap Length	19 cm (suitable for 15-20 cm wrist circumference)
Clasp Type	Buckle
Product Dimensions	1.85 x 0.47 x 1.85 inches (watch head)
Item Weight	14.39 ounces

**CASE**

316L high precision stainless steel, individually numbered, screw down caseback

DIAL

Midnight blue dial and bezel

GLASS

Domed sapphire crystal with anti-reflective coating

MOVEMENT

Miyota 6S20 Chronograph (quartz)

SIZE

40 mm wide, 12 mm thick

STRAP

Brown special edition racing leather strap with quick release

Image: A technical drawing providing detailed measurements and component labels for the watch case, dial, glass, movement, size, and strap, including buttons A, B, and C.

WARRANTY AND SUPPORT

Warranty Information

Your About Vintage 1960 Racing Chronograph Watch is covered by a **2-year warranty** against manufacturing defects from the date of purchase. This warranty does not cover normal wear and tear, accidental damage, or damage resulting from improper use or unauthorized repairs.

Customer Support

For warranty claims, service, or any questions regarding your watch, please contact About Vintage customer support. Refer to the official About Vintage website for the most current contact information.

You can also visit the [About Vintage Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question