

[Manuals.plus](#) /

› [Armocity](#) /

› Armocity 47-inch L-Shaped Computer Desk with Power Outlets and LED Lights User Manual

Armocity L Shaped Computer Desk 47 inch

Armocity 47-inch L-Shaped Computer Desk with Power Outlets and LED Lights User Manual

Model: L Shaped Computer Desk 47 inch

1. INTRODUCTION

Thank you for purchasing the Armocity 47-inch L-Shaped Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the desk or shelves. Refer to the 'Specifications' section for weight limits.
- Keep liquids away from power outlets and electrical components.
- Children should not climb on or play with the desk.
- Use caution when moving the desk to prevent injury or damage.

3. PACKAGE CONTENTS

Verify that all components are present before assembly. If any parts are missing or damaged, please contact customer support.

- Desk panels (main desktop, L-extension, monitor stand shelves)
- Metal frame components (legs, X-shaped cross bars)
- Hardware pack (screws, bolts, Allen wrench)
- Power outlet unit with USB ports and power cord
- LED light strip with controller
- Side storage bag
- Hanger hooks
- Adjustable foot pads

- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. Two people are recommended for easier and safer assembly.

4.1 Unpacking and Preparation

1. Clear a spacious area for assembly.
2. Lay out all components and hardware, comparing them with the parts list.

4.2 Frame Assembly

1. Attach the adjustable foot pads to the bottom of each leg frame.
2. Connect the leg frames using the X-shaped cross bars. Ensure all connections are secure.



Corner Desk for Small Spaces with A Lot Of Tabletop Space

Image: Desk frame showing X-shaped cross bars for stability and adjustable foot pads for leveling.

4.3 Desktop Panel Installation

1. Carefully place the main desktop panel onto the assembled frame.
2. Secure the main desktop panel to the frame using the provided screws.
3. Determine your preferred L-shape configuration (left or right side). The desk is reversible.
4. Attach the L-extension desktop panel to the main desktop and frame, securing it with screws.



Create Your Home Office Space with Reversible Desks



Image: Two configurations of the Armocity L-shaped desk, demonstrating its reversible design for left or right corner placement.

4.4 Monitor Stand and Storage Installation

1. Attach the monitor stand shelves to the designated areas on the desktop using the provided hardware.
2. Install the side storage bag and hanger hooks on either the left or right side of the desk, according to your preference.



Image: Key features of the desk including the full-size monitor stand, large fiber storage bag, and two side hooks.

4.5 Power Outlet and LED Light Installation

1. Insert the power outlet unit into the pre-drilled hole on the desktop. Connect its power cord to a wall outlet.
2. Adhere the LED light strip to the underside of the monitor stand or desired location. Connect the LED strip to its controller and then to a USB power source (e.g., one of the desk's USB ports or a separate adapter).



3 AC Outlets
120V/12A



2 USB Ports
5V/2A



Power Cord
6.5FT

Image: Detail of the integrated power outlets (3 AC, 2 USB) and the 6.5ft power cord.

Your browser does not support the video tag.

Video: An overview of the L-shaped gaming desk, showcasing the charger station and LED lights. This video demonstrates the desk's features and functionality.

5. OPERATING INSTRUCTIONS


5.1 Power Outlets and USB Ports

- The integrated power strip provides 3 AC outlets (120V/12A) and 2 USB ports (5V/2A).
- Plug your electronic devices directly into these outlets for convenient power access.
- Ensure the total power consumption of connected devices does not exceed the desk's rated capacity.

5.2 LED Lights

- The LED lights can be controlled via a remote or a smartphone application.

- **Static Mode:** Select from various solid colors to match your ambiance.
- **Dynamic Modes:** Choose from 20 pre-set dynamic lighting effects.
- **Music Sync:** Some models may feature a music synchronization mode, allowing the lights to react to audio. Refer to the LED controller's specific instructions for detailed usage.



🇮🇹 Enjoy your gaming time with this L-shaped Gaming Desk

Image: An L-shaped desk setup illuminated by smart RGB LED lights, showcasing various static and dynamic color modes for a gaming environment.

6. MAINTENANCE AND CARE

- Clean the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Wipe up spills immediately to prevent damage to the engineered wood surface.
- Regularly check all fasteners to ensure they remain tight.
- Keep the power outlets and LED lights free from dust and debris.

7. TROUBLESHOOTING

7.1 LED Lights Not Working

- Check if the LED strip is securely connected to the controller and the power source.
- Ensure the power source (USB port) is active.
- Verify the remote control battery is functional.

7.2 Power Outlets Not Functioning

- Confirm the desk's main power cord is securely plugged into a working wall outlet.
- Check if the wall outlet itself is receiving power (test with another device).
- Ensure no circuit breaker has tripped.

7.3 Desk Wobbles

- Tighten all assembly screws and bolts.
- Adjust the foot pads on the bottom of the legs to level the desk on uneven floors.
- Ensure the X-shaped cross bars are correctly installed and tightened.

8. SPECIFICATIONS

Feature	Detail
Brand	Armocity
Product Dimensions	18.9"D x 47.2"W x 29.1"H
Color	Green
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood
Special Feature	Reversible, Integrated Power Outlets, LED Lights, Storage Shelves
Power Outlets	3 AC Outlets (120V/12A), 2 USB Ports (5V/2A)
Item Weight	21.32 Kilograms

9. WARRANTY AND SUPPORT

Armocity products are designed for quality and durability. For warranty information, product support, or to report missing/damaged parts, please contact Armocity customer service through the retailer's platform or the official Armocity website. Please have your purchase receipt and model number available when contacting support.

Customer Service: Refer to your purchase platform for contact details or visit the official Armocity website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C9T6TBWS>

More documents and user manuals: <https://manuals.plus/>