#### Manuals+

#### Q & A | Deep Search | Upload

#### manuals.plus /

- comiso /
- > comiso C17 Small Bluetooth Speaker User Manual

#### comiso C17

# comiso C17 Small Bluetooth Speaker User Manual

Model: C17

#### 1. Introduction

Thank you for purchasing the comiso C17 Small Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully before use to ensure optimal performance and longevity of the device.

#### 2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel if needed.
- Keep the speaker away from medical devices, as it may interfere with their operation.
- Ensure the charging port cover is securely closed when the speaker is exposed to water to maintain its IPX7 waterproof rating.

#### 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- · comiso C17 Mini Portable Bluetooth Speaker
- USB Type-C Charging Cable
- Lanyard
- · Welcome Guide (this manual)

#### 4. PRODUCT OVERVIEW

The comiso C17 speaker is designed for portability and robust sound. It features a compact design with a durable ABS plastic shell and a silicone base. The Type-C charging port includes an indicator light for convenience.



Image: The comiso C17 Small Bluetooth Speaker in Sky Blue, held in a hand with water splashes, showcasing its compact size and waterproof design.




Image: An exploded view illustrating the internal components of the comiso C17 speaker, highlighting the 5W full-range high-performance driver and passive subwoofer for enhanced bass.

# 5. SETUP

## 5.1. Charging the Speaker

- 1. Locate the Type-C charging port on the speaker.
- 2. Connect the provided USB Type-C cable to the speaker's charging port.
- Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
- 4. The indicator light near the charging port will illuminate during charging and turn off when fully charged.

5. A full charge typically takes approximately 2 hours.

### 5.2. Power On/Off

- To power on: Press and hold the power button until you hear an audible prompt.
- To power off: Press and hold the power button again until you hear an audible prompt.

# 5.3. Bluetooth Pairing

The comiso C17 uses Bluetooth 5.3 for stable and efficient connections.

- 1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED light).
- 2. On your device (smartphone, tablet, laptop), enable Bluetooth.
- 3. Search for available Bluetooth devices. The speaker will appear as "C17" or "comiso C17".
- 4. Select "C17" or "comiso C17" to connect. Once connected, you will hear a confirmation sound, and the LED light will become solid.



Image: The comiso C17 speaker positioned among various compatible devices including laptops, tablets, and smartphones, illustrating its wide compatibility with Bluetooth 5.3 technology.

# 5.4. TWS (True Wireless Stereo) Pairing

For an immersive 360° stereo sound experience, you can pair two comiso C17 speakers together.

- 1. Ensure both C17 speakers are powered on and not connected to any other Bluetooth device.
- 2. On one of the speakers (this will be the primary speaker), double-press the power button. You will hear a prompt indicating it's searching for another speaker.
- 3. The two speakers will automatically connect to each other. A confirmation sound will indicate successful TWS pairing.
- 4. Now, connect your device to the primary speaker via Bluetooth as described in section 5.3. Both speakers will play audio simultaneously.




Image: Two comiso C17 speakers placed on a desk next to a laptop, demonstrating TWS pairing for a stereo audio experience.

# 6. OPERATING INSTRUCTIONS

# **6.1. Playing Audio**

- Once connected via Bluetooth, play audio from your paired device. The sound will be transmitted through the comiso C17 speaker.
- Use your device's controls to play, pause, skip tracks, or adjust volume.

# 6.2. Hands-Free Calling

The speaker features a built-in microphone for hands-free calls.

• When a call comes in, the speaker will ring. Press the power button once to answer the call.

- To end a call, press the power button once again.
- To reject an incoming call, press and hold the power button.

#### 6.3. Volume Control

Adjust the volume directly from your connected device.

# 7. MAINTENANCE

# 7.1. Cleaning

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

# 7.2. Waterproof Care (IPX7)

The comiso C17 speaker is IPX7 waterproof, meaning it can be immersed in water up to one meter deep for 30 minutes. To maintain its waterproof integrity:

- Ensure the Type-C charging port cover is completely sealed before exposing the speaker to water.
- Do not expose the speaker to saltwater or other chemicals. If it comes into contact with such substances, rinse it with fresh water and dry thoroughly.
- Do not charge the speaker if the charging port or cable is wet.




Image: The comiso C17 speaker partially submerged in water with splashes, demonstrating its IPX7 waterproof capability.

# 7.3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

# 8. TROUBLESHOOTING

Troblem Trossible Gause Goldforn	Problem	Possible Cause	Solution
----------------------------------	---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker for at least 30 minutes.
Cannot pair with device.	Bluetooth is off on device; speaker is already paired; speaker is out of range.	Ensure Bluetooth is enabled on your device. Disconnect from other devices. Move speaker closer to your device (within 10 meters).
No sound or low volume.	Volume too low on speaker or device; device not connected.	Increase volume on both the speaker and your device. Re-establish Bluetooth connection.
TWS pairing fails.	Speakers are already connected to a device; speakers are too far apart.	Ensure both speakers are disconnected from other devices before TWS pairing. Place speakers close to each other.
Poor call quality.	Weak signal; microphone obstruction.	Move closer to your phone. Ensure the microphone area is clear.

# 9. SPECIFICATIONS

Feature	Specification
Model Name	C17A
Speaker Type	Portable
Connectivity Technology	Bluetooth 5.3
Speaker Maximum Output Power	5 Watts
Audio Output Mode	Stereo (with TWS pairing)
Water Resistance Level	IPX7
Item Weight	3.84 ounces (0.11 Kilograms)
Product Dimensions	1.6"D x 1.6"W x 1.8"H
Charging Time	2 Hours
Battery Life	7-10 hours (at medium volume)
Bluetooth Range	10 Meters
Power Source	Battery Powered (1 Lithium Polymer battery included)
Control Method	Touch (Power button)

# 10. WARRANTY AND SUPPORT

# **10.1. Warranty Information**

The comiso C17 Small Bluetooth Speaker comes with a worry-free 365-day warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

## 10.2. Customer Support

For any questions, technical assistance, or warranty claims, please contact our friendly customer service team. Refer to the contact information provided in your purchase documentation or visit the official comiso website for support details.

© 2025 comiso. All rights reserved.

#### **Related Documents - C17**

	COMISO C15 IPX7 Waterproof Wireless Speaker User Manual Comprehensive user manual for the COMISO C15 IPX7 Waterproof Wireless Speaker (Model 96110). Learn about its features, functions, Bluetooth connectivity, TWS pairing, light modes, specifications, safety guidelines, and troubleshooting tips.
0 + v 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0	COMISO C15 Wireless Waterproof Speaker User Manual Comprehensive user manual for the COMISO C15 Wireless Waterproof Speaker, detailing features, operation, safety instructions, and troubleshooting.
COOP CREATE AT PROJECT SALES AND ADDRESS OF THE ADD	FCC Confidentiality Request for X26L Device by COMISO Confidentiality request letter submitted to the FCC for the X26L wireless speaker by SHENZHEN COMISO DIGITAL TECHNOLOGY LIMITED, detailing requested confidentiality periods for exhibits.
	COMISO C17PRO Wireless Bluetooth Speaker: User Guide and Specifications Comprehensive guide for the COMISO C17PRO Wireless Bluetooth Speaker, covering setup, TWS pairing, troubleshooting, specifications, and warranty information.
	Comiso X26M Wireless Speaker User Manual and Specifications This document provides comprehensive instructions, troubleshooting tips, and specifications for the Comiso X26M wireless speaker, including details on Bluetooth pairing, charging, and warranty information.
Western weeks and the second s	Mini Electric Air Pump C17 User Manual User manual for the C17 Mini Electric Air Pump, detailing operation notices, warnings, product structure, step-by-step usage instructions, panel controls, and technical specifications. Suitable for inflating cars, bicycles, motorbikes, and inflatable toys.



#### [pdf] Decleration of Conformity

Differences Declaration hss Cover letter SHENZHEN COMISO DIGITAL TECHNOLOGY LIMITED C8S Wireless speaker 2AEZG 2AEZGC8S c8s

Differences Declaration To whom concern, We company SHENZHEN COMISO DIGITAL TECHNOLOGY LIMITED hereby declares: The product models **C17**, C15, M30, X26M, C7S, C10, X26, M246, X28, M20, C28, C9, C6, C26, M10 are identical in the same PCB layout, interior structure and electrical circuits with the model... lang: score:19 filesize: 67.94 K page count: 1 document date: 2018-07-31



#### INSMY C17 PRO Wireless Speaker User Manual

This manual provides instructions for the INSMY C17 PRO wireless speaker, covering setup, operation, troubleshooting, and warranty information. Learn how to pair devices, use TWS functionality, and maintain your speaker.


lang: score:17 filesize: 2.09 M page count: 1 document date: 2022-03-03



#### [pdf] Test Report

HD 271 S1 LAB02 Test report SHENZHEN COMISO DIGITAL TECHNOLOGY LIMITED C8S Wireless speaker 2AEZG 2AEZGC8S c8s

Global United Technology Services Co., Ltd. Report No.: GTS201807000064F02 FCC REPORT Applicant: ... ent Under Test EUT Product Name: Model No.: FCC ID: Applicable standards: Wireless speaker C8S, C17, C15, M30, X26M, C7S, C10, X26, M246, X28, M20, C28, C9, C6, C26, M10 2AEZG-C8S FCC CFR Title 47... lang:en score:16 filesize: 1.38 M page\_count: 27 document date: 2018-07-31



#### [pdf] Test Report

HD 271 S1 LAB02 Test report SHENZHEN COMISO DIGITAL TECHNOLOGY LIMITED C8S Wireless speaker 2AEZG 2AEZGC8S c8s

Global United Technology Services Co., Ltd. Report No.: GTS201807000064F01 FCC REPORT Applicant: ... ent Under Test EUT Product Name: Model No.: FCC ID: Applicable standards: Wireless speaker C8S, C17, C15, M30, X26M, C7S, C10, X26, M246, X28, M20, C28, C9, C6, C26, M10 2AEZG-C8S FCC CFR Title 47... lang:en score:15 filesize: 2.19 M page\_count: 36 document date: 2018-07-31