

Nillkin Z Fold 4

Nillkin Upgraded Case for Samsung Galaxy Z Fold 4 - Instruction Manual

Model: Z Fold 4

1. PRODUCT OVERVIEW

The Nillkin Upgraded Case is designed specifically for the Samsung Galaxy Z Fold 4 5G (2022) to provide comprehensive protection and enhanced functionality. This case features a durable construction, an integrated S Pen holder, and a hidden kickstand for versatile use.

Key Features:

- **Compatibility:** Exclusively designed for Samsung Galaxy Z Fold 4 5G (2022). Not compatible with other models.
- **360° Full Body Protection:** Constructed with a PC hard back shell, four cushioned corner bumpers, and a TPU frame that wraps around the phone body, corners, and hinges. This design protects against drops, cracks, and scratches.
- **Special Dazzling Lens Cover:** Features a high-quality metal lens cover with a 1mm raised edge for camera protection. It is designed to be fingerprint-resistant and supports wireless charging.
- **Removable S Pen Slot & Hidden Kickstand:** Includes a slide-out S Pen slot integrated into the hinge for secure storage and easy access. The S Pen holder also functions as a hidden kickstand, offering hands-free viewing. The detachable design provides flexibility.
- **Unique Frosted Shield Design:** Offers effective drop protection without adding excessive bulk, maintaining a stylish and versatile appearance.

Package Contents:

- Nillkin Z Fold 4 Case with S Pen Holder
- 2 Front Screen Protectors
- Spare 3M Adhesive
- Ancillary Kit

2. SETUP AND INSTALLATION

Follow these steps to correctly install your Nillkin Upgraded Case and screen protectors on your Samsung

2.1 Case Installation

1. **Prepare the Phone:** Ensure your Samsung Galaxy Z Fold 4 is clean and free of dust or debris.




Figure 1: Compatibility check for Samsung Galaxy Z Fold 4.

2. Install the Back Shell:

- Unfold your phone screen.
- Carefully remove the back shell from the phone if it's already on.
- Tear off the remaining 3M adhesive film from the phone frame.
- Open the tool bag and take out the wet cloth to wipe the phone frame first, then clean well with a dust cloth.
- Take out the short 3M adhesive fixed sticker. Tear off the white release film.
- Paste it to the inner side of the lower right border of the back shell.
- Tear off its release film.
- Align your phone with the back shell and carefully install it.
- Repeatedly press the border up and down to ensure it is securely pasted and fixed.

Your browser does not support the video tag.

Video 1: Nilkin Samsung Z Fold 4 Case 3M Film Installation Instruction. This video demonstrates the process of cleaning the phone and applying the 3M adhesive to the back shell before installing the phone.

3. Install the Front Shell:

- Remove the front shell from the phone.
- Tear off the remaining 3M adhesive from the phone frame.
- Take out the long 3M adhesive fixed sticker. Tear off the white release film.
- Paste it to the inner side of the lower right border of the front shell.
- Tear off the release film.
- Align your phone with the front shell and carefully install it.
- Repeatedly press the border up and down to ensure it is securely pasted and fixed.

Your browser does not support the video tag.

Video 2: Nillkin Frosted Samsung Z Fold 4 Case Installation Instruction. This video provides a visual guide for installing both the back and front parts of the case, including the application of adhesive strips.

4. **Install the S Pen Holder:** Insert the S Pen holder from the upper end of the sliding groove on the case.



Figure 2: Detachable S Pen holder installation.

Note: This Z Fold 4 Case is only compatible with flexible film screen protectors. It does NOT work with tempered glass screen protectors. S Pen is not included.

NOTICE

Please make sure to remove the disposable films from the phone case before using




Figure 3: Important notice regarding removal of disposable films.

3. OPERATING INSTRUCTIONS

3.1 Using the S Pen Holder and Kickstand

- The S Pen holder is integrated into the hinge mechanism. Slide it out to access your S Pen.
- The S Pen holder can also be extended to function as a hidden kickstand. This allows for hands-free viewing of your device in a folded or partially folded position.



Built-in Hidden Metal Stand

More comfortable office Entertainment,
free your hands anytime, anywhere

Figure 4: Hidden kickstand in use for comfortable viewing.

**PC Hard Back Shell
+TPU Frame Wrap**



Precise Cut Hole



Invisible Kickstand

Figure 5: Close-up of the invisible kickstand.

3.2 Folding and Unfolding

- The case is designed to allow 180° folding, enabling seamless transition between the large and small screens of your Galaxy Z Fold 4.
- Ensure the case components are securely attached to prevent interference with the folding mechanism.



360 ° Protection

PC and TPU by integrally injection molded to wrap phone's fuselage, corners and hinges



Figure 6: The case supports 180° folding for flexible use.

3.3 Wireless Charging

- The slim design of the case ensures compatibility with wireless charging. Place your device on a wireless charging pad as usual.

4. MAINTENANCE AND CARE

To maintain the appearance and functionality of your Nillkin case, follow these care guidelines:

- **Cleaning:** Wipe the case with a soft, damp cloth to remove dust and smudges. Avoid harsh chemicals or abrasive materials.
- **Adhesive Care:** If the adhesive strips lose their stickiness over time, use the provided spare 3M adhesive strips for reapplication. Ensure surfaces are clean and dry before applying new adhesive.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.

5. TROUBLESHOOTING

If you encounter any issues with your Nillkin case, refer to the following common solutions:

- **Case not fitting securely:** Ensure all 3M adhesive strips are properly applied and the case components are aligned correctly. Re-press the borders to secure the fit.
- **Screen protector issues:** Verify that you are using a flexible film screen protector, as tempered glass protectors are not compatible with this case. Ensure the screen is clean before applying the protector.
- **S Pen holder not sliding smoothly:** Check for any debris in the sliding groove. Clean the groove gently.
- **Wireless charging not working:** Ensure the phone is correctly positioned on the wireless charging pad. If the issue persists, remove the case to confirm it is not interfering.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	8.27 x 5.91 x 0.79 inches
Item Weight	10.6 ounces
Material	PC hard back with TPU Edge
Compatible Phone Models	Samsung Galaxy Z Fold4
Item Model Number	MichYTumP-ZF4
Color	Green

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Nillkin website. Keep your purchase receipt for warranty claims.

- **Return Policy:** 30-day refund/replacement policy.

