

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Mysoda](#) /
- › [Mysoda Ruby 2 Sparkling Water Maker User Manual](#)

Mysoda Ruby 2

Mysoda Ruby 2 Sparkling Water Maker User Manual

1. INTRODUCTION

The Mysoda Ruby 2 Sparkling Water Maker allows you to create fresh carbonated water at home. This manual provides essential information for the safe and efficient use of your device. The Ruby 2 features an award-winning design, an improved anti-freeze nozzle for fine bubbles, and a scratch-proof coating for durability. It operates without electricity and utilizes a quick-lock mechanism for ease of use.



Image: The Mysoda Ruby 2 Sparkling Water Maker, showcasing its sleek design and included water bottle, ready for use.

2. PACKAGE CONTENTS

Your Mysoda Ruby 2 Sparkling Water Maker package includes the following items:


- 1x Mysoda Ruby 2 Sparkling Water Maker
- 1x 1-Liter Reusable Water Bottle

Please note: The CO2 cylinder is sold separately and is not included in the package.

SILENT AND EASY TO USE WITH QUICK-LOCK MECHANISM


01

Fill the water bottle with cold water up to the fill line.



02

Insert the bottle into the quick-lock system, and turn to lock. Push the bottle towards the device so it is fully upright.



03

Press carbonation button 2-3 times, stop when you hear a hissing sound.



04

Enjoy your carbonated water or add your desired fruits/flavors.



Image: An illustration detailing the dimensions of the Ruby 2 device and listing the included components: the sparkling water maker and a 1L reusable water bottle.

3. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage to your device, please adhere to the following safety guidelines:

- Use only cold, clean tap water for carbonation.
- Do not carbonate any liquids other than water. Carbonating other beverages can damage the device and create a safety hazard.
- Keep the sparkling water maker out of reach of children.
- Do not place the device near direct heat sources or in direct sunlight.
- Ensure the water bottle is securely attached to the device before initiating carbonation.
- Never remove the water bottle during the carbonation process.
- Only use Mysoda-approved water bottles with your device. Other bottles may not fit correctly or withstand the pressure.

- Do not overfill the water bottle beyond the indicated fill line.
- Handle CO2 cylinders with care. Refer to the cylinder manufacturer's instructions for safe handling and storage.

4. SETUP

Follow these steps to set up your Mysoda Ruby 2 Sparkling Water Maker:

1. **Unpack the Device:** Carefully remove the sparkling water maker and all components from its packaging.
2. **Insert CO2 Cylinder:** The Ruby 2 uses a common screw-in CO2 cylinder (not included). Locate the cylinder compartment, typically at the back or bottom of the device. Screw the CO2 cylinder firmly into place until it is hand-tight. Do not overtighten.
3. **Prepare Water Bottle:** Before first use, wash the 1-liter reusable water bottle with warm water and mild detergent. Rinse thoroughly.

5. OPERATING INSTRUCTIONS

Creating sparkling water with your Mysoda Ruby 2 is a simple four-step process:

1. **Fill the Bottle:** Fill the Mysoda water bottle with cold tap water up to the indicated fill line. Ensure the water is cold for optimal carbonation.
2. **Attach the Bottle:** Insert the filled water bottle into the quick-lock system of the sparkling water maker. Turn the bottle to lock it securely into position. Push the bottle towards the device so it is fully upright and stable.
3. **Carbonate:** Press the carbonation button located on top of the device 2-3 times. You will hear a distinct hissing sound as the water is carbonated. Stop pressing when you achieve your desired level of fizziness.
4. **Enjoy:** Once carbonation is complete, carefully remove the bottle by turning it counter-clockwise and pulling it down. Your sparkling water is now ready to be enjoyed. You may add fruits or flavors if desired.

PROUD WINNER OF RED DOT DESIGN AWARD 2023



ULTIMATE COMBINATION OF
STUNNING TONE-TO-TONE
COLOR SCHEME AND
ROBUST DESIGN



reddot winner 2023
kitchen appliances design

Image: A visual guide demonstrating the four steps for carbonating water: filling the bottle, inserting and locking it, pressing the carbonation button, and enjoying the finished drink.

mysoda[®]



Carbonate your cold water without the nozzle freezing. Our innovative nozzle creates a high amount of small, strong bubbles for an enjoyable drinking experience. The nozzle is made of a material that retains its original color over the years.

Image: This image highlights the anti-freeze nozzle feature, which ensures consistent carbonation without freezing, producing small, strong bubbles for an enhanced drinking experience. The nozzle's material is designed to retain its original color over time.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Mysoda Ruby 2.

- **Cleaning the Device:** Wipe the exterior of the sparkling water maker with a soft, damp cloth. Do not immerse the device in water or use abrasive cleaners. The scratch-proof coating facilitates easy maintenance.
- **Cleaning the Water Bottle:** Wash the reusable water bottle with warm water and a mild dish soap. Rinse thoroughly. Do not wash the bottle in a dishwasher, as high temperatures can damage the plastic.
- **Nozzle Care:** The anti-freeze nozzle is designed for durability and minimal maintenance. If residue builds up, gently wipe it with a damp cloth.

7. TROUBLESHOOTING

If you encounter issues with your Mysoda Ruby 2, refer to the following common troubleshooting tips:

- **No Carbonation:**

- Ensure the CO2 cylinder is correctly installed and not empty.
- Verify that the water bottle is filled to the indicated line and securely attached to the device.

- **Weak Carbonation:**

- Press the carbonation button more times (up to 3-4 presses) to achieve a stronger fizz.
- Ensure the water used is cold, as cold water absorbs CO2 more effectively.

- **Water Leaking:**

- Check that the water bottle is not overfilled beyond the fill line.
- Confirm the water bottle is correctly and securely installed in the quick-lock system.

- **Hissing Sound Continues After Carbonation:**

- This is normal. It indicates excess pressure being released. Wait a few seconds for the sound to subside before removing the bottle.

8. SPECIFICATIONS

Feature	Specification
Brand	Mysoda
Model Name	Ruby 2 White
Item Volume	1 Liters
Capacity	1 Liters
Power Source	Manual
Operation Mode	Automatic
Manufacture Year	2023
Product Dimensions	9.45 x 5.63 x 16.14 inches (24 x 14.3 x 41 cm)
Item Weight	5.28 pounds (2.4 Kilograms)
Material	Aluminum
Manufacturer	Mysoda Oy

9. WARRANTY AND SUPPORT

For detailed warranty information, product registration, or customer support, please visit the official Mysoda website or contact Mysoda customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Mysoda Official Website: [Visit the Mysoda Store](#)

