

[Manuals.plus](#) /

› [Focket](#) /

› Focket 10-Inch Modern Round LED Ceiling Fan with Light User Manual

Focket Focketk3h4gmtvsa

Focket 10-Inch Modern Round LED Ceiling Fan with Light User Manual

Model: Focketk3h4gmtvsa

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Focket 10-Inch Modern Round LED Ceiling Fan with Light. Please read this manual thoroughly before installation and retain it for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury. This appliance is intended for indoor use only.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All electrical wiring must be performed by a qualified electrician in accordance with local codes and regulations.
- The mounting structure must be capable of supporting the weight of the fan.
- Do not insert fingers or any objects into the fan blades while the fan is operating.
- Keep children and pets away from the fan during operation.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- 1 x Focket 10-Inch Modern Round LED Ceiling Fan with Light
- 1 x Aromatherapy Tablet
- 1 x Remote Control (batteries not included)
- Installation Hardware (screws, wire nuts, etc.)
- User Manual



Image: The Focket 10-inch modern round LED ceiling fan with light, shown with the included aromatherapy tablet. The fan features an enclosed design and an E27 screw-in base.

4. PRODUCT FEATURES

- **Integrated LED Light:** Provides illumination for the room.
- **Low Noise Operation:** Equipped with a built-in copper motor for quiet performance.
- **Aromatherapy Function:** Features a unique design for placing aromatherapy tablets, allowing fragrance to disperse with airflow.
- **Universal E27 Lamp Holder:** Adjustable left, right, up, and down for flexible lighting direction.
- **Stepless Dimming:** Adjust light brightness continuously.
- **Three Wind Speeds:** Offers multiple fan speed settings for comfort.
- **Timing Function:** Allows setting an operating duration.
- **Sleep Mode:** Provides a gentle, quiet setting for nighttime use.
- **Enclosed Fan Design:** Concealed fan blades with a dense mesh for enhanced safety.



Image: The Focket 10-inch ceiling fan with light installed in a room, demonstrating the gentle airflow it provides.

Supports up, down, left and right adjustment.




Image: A close-up view of the Focket ceiling fan's E27 spiral lamp holder, highlighting its adjustable left, right, up, and down movement.

5. SPECIFICATIONS

Attribute	Value
Brand	Focket
Model Name	Focketk3h4gmtvsa
Color	White
Material	Acrylonitrile Butadiene Styrene, Polycarbonate
Style	Modern
Light Fixture Form	Ceiling

Room Type	Bathroom, Bedroom, Dining Room, Garage, Kitchen, Storage Room
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Installation Type	Semi Flush Mount
Special Feature	Dimmable
Control Method	Remote
Light Source Type	LED
Finish Type	Polished
Shade Material	Acrylonitrile Butadiene Styrene, Polycarbonate
Number of Light Sources	1
Light Color	Cool White
Included Components	Aromatherapy Tablet
Lighting Method	LED
Number of Items	1
Wattage	30 watts
Bulb Base	E27
Controller Type	Remote Control
Switch Type	Remote
Unit Count	1.0 Count
Water Resistance Level	Not Water Resistant
Mounting Type	Ceiling Mount
Shade Color	White
Fixture Type	Non Removable
Assembly Required	Yes
Item Weight	1.19 pounds
Package Dimensions	9.84 x 9.84 x 5.91 inches



Image: The Focket 10-inch ceiling fan with light, showing its approximate dimensions: 11cm (4.33 inches) in height and 25cm (9.84 inches) in diameter.

6. INSTALLATION INSTRUCTIONS

This ceiling fan is designed for semi-flush mounting and connects via a universal E27 spiral lamp holder. Professional installation is recommended.

6.1. Pre-Installation

1. Turn off power at the main circuit breaker.
2. Ensure the existing E27 lamp holder is securely mounted and capable of supporting the fan's weight.
3. Unpack all components and verify against the package contents list.

6.2. Mounting the Fan

1. Carefully screw the E27 base of the ceiling fan into your existing E27 lamp holder. Ensure it is tightened securely.
2. Once the fan is securely screwed into the lamp holder, ensure all connections are firm.

6.3. Aromatherapy Tablet Installation

1. Locate the designated slot or compartment for the aromatherapy tablet on the fan unit.
2. Insert the provided aromatherapy tablet into the slot.



Image: A top-down view of the Focket 10-inch ceiling fan, illustrating its E27 screw-in base for easy installation into standard lamp holders and the enclosed fan blades for safety.

7. OPERATING INSTRUCTIONS

Your Focket ceiling fan comes with a remote control for convenient operation. Insert batteries into the remote control before use.

7.1. Light Control

- **Power On/Off:** Press the light button on the remote to turn the LED light on or off.
- **Stepless Dimming:** Use the dimming buttons (usually up/down arrows or a slider) on the remote to adjust the brightness of the light continuously.
- **Color Temperature:** The fan light operates at 6500K (Cool White).

7.2. Fan Speed Control

- **Adjust Speed:** Use the fan speed buttons on the remote to cycle through the three available wind speeds.

7.3. Special Functions

- **Timing Function:** Activate the timer feature via the remote control to set the fan to turn off automatically after a

specified period.

- **Sleep Mode:** Select sleep mode for a gentle, quiet operation suitable for sleeping environments.
- **Aromatherapy:** The fan will circulate air over the aromatherapy tablet, dispersing fragrance into the room when operating.

8. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fan and light with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Windshield Removal:** The fan's windshield can be easily removed for cleaning or access to the fan blades. Gently twist or unclip the windshield as per the design to remove it. Reattach securely after cleaning.
- **Aromatherapy Tablet Replacement:** Replace the aromatherapy tablet as needed to maintain fragrance.



Image: A side view of the Focket 10-inch ceiling fan, highlighting its enclosed blade design for safety and ease of maintenance.



Image: A close-up of the Focket 10-inch ceiling fan's dense mesh grille, which prevents foreign objects from entering and ensures safety.

9. TROUBLESHOOTING

If you encounter issues with your Focket ceiling fan, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan or light does not turn on	No power; loose connection; remote control issues	Check circuit breaker; ensure fan is securely screwed into E27 holder; replace remote batteries; ensure remote is paired.
Fan makes unusual noise	Loose screws; obstruction	Ensure all mounting screws are tight; check for any objects interfering with the blades.

Remote control not working	Dead batteries; remote not paired	Replace batteries; refer to remote pairing instructions (if applicable, usually involves pressing a button combination).
Light flickers or is dim	Loose connection; faulty LED	Ensure fan is securely screwed into E27 holder; contact customer support if LED is faulty.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Focket customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question