

[Manuals.plus](#) /

> [BoxWave](#) /

> BoxWave Stylus PortaPouch Instruction Manual

BoxWave PortaPouch

BoxWave Stylus PortaPouch Instruction Manual

Model: PortaPouch

INTRODUCTION

The BoxWave Stylus PortaPouch is a versatile, self-adhesive holder designed to keep your stylus or pen securely attached to your device or case. Its slim and sleek design ensures your writing tool is always within reach without adding bulk.



Image: The BoxWave Stylus PortaPouch, a convenient self-adhesive holder for your stylus.

SETUP

Follow these steps to properly attach your Stylus PortaPouch:

1. **Prepare the Surface:** Ensure the surface where you intend to attach the PortaPouch is clean, dry, and smooth. This could be your device, case, or any other suitable flat area.
2. **Peel the Backing:** Carefully peel off the protective backing from the adhesive side of the PortaPouch.

3. **Apply the Pouch:** Position the PortaPouch on your chosen surface. Press firmly across the entire adhesive area for several seconds to ensure a strong bond.



Always On Hand

Always have your stylus on hand as PortaPouch adheres to virtually any surface.

Image: The PortaPouch adhered to a notebook, keeping a stylus readily accessible.

OPERATING INSTRUCTIONS

Using your Stylus PortaPouch is straightforward:

- **Inserting a Stylus/Pen:** Gently slide your stylus or pen into the elastic sleeve of the PortaPouch. The elastic material will stretch to accommodate various sizes and then tighten to hold it securely.
- **Removing a Stylus/Pen:** Pull your stylus or pen out of the sleeve when needed. The snug fit ensures it remains in place during transport but allows for easy removal.

The PortaPouch is designed for universal compatibility, fitting most styluses and pens.

Fits Any Stylus Or Pen

Elastic pouch stretches to
fit any stylus or pen.



Image: The elastic pouch stretches to fit various stylus and pen sizes.



Image: The PortaPouch provides a secure home for your stylus, keeping it with your device.

MAINTENANCE

To ensure the longevity and appearance of your Stylus PortaPouch:

- **Cleaning:** For light cleaning, gently wipe the faux leather and elastic fabric with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Adhesive Care:** Once applied, the adhesive is designed for a strong, permanent bond. Repeated removal and reapplication may weaken the adhesive.
- **Storage:** Store the PortaPouch in a cool, dry place if not immediately used.

TROUBLESHOOTING

If you encounter any issues with your Stylus PortaPouch, consider the following:

- **Pouch Not Sticking:** Ensure the surface was clean and dry before application. Press firmly for an extended period to allow the adhesive to bond. Avoid applying to textured or uneven surfaces.
- **Stylus Feels Loose:** The elastic is designed to provide a snug fit. If your stylus feels too loose, it

might be smaller than the intended range. The PortaPouch is best suited for standard-sized styluses and pens.

- **Stylus Difficult to Insert/Remove:** If your stylus is particularly thick, the elastic may be very tight. Apply gentle, consistent pressure. Avoid forcing the stylus, which could damage the pouch or the stylus.

SPECIFICATIONS

Feature	Detail
Model	PortaPouch
Color	Jet Black
Material	Faux Leather, Elastic Fabric
Special Feature	Stylus Holder, Self-Adhesive
Item Weight	0.3 ounces
Dimensions (L x W x T)	7.25 inches x 1.35 inches x 0.08 inches (18.41 cm x 3.43 cm x 0.20 cm)



PortaPouch Dimensions



Image: Detailed dimensions of the Stylus PortaPouch.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your BoxWave Stylus PortaPouch, please contact BoxWave Corporation directly. Refer to your purchase documentation or the official BoxWave website for specific warranty information and customer service contact details.

BoxWave Corporation is committed to providing high-quality accessories and customer satisfaction.