

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Portronics](#) /

› [Portronics Bubble Pro Wireless Keyboard Instruction Manual](#)

Portronics POR-1888

Portronics Bubble Pro Wireless Keyboard Instruction Manual

Model: POR-1888

[Product Overview](#)

[Setup](#)

[Operation](#)

[Maintenance
& Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

1. PRODUCT OVERVIEW

The Portronics Bubble Pro Wireless Keyboard with Touchpad offers versatile connectivity and an ergonomic design for comfortable use across multiple devices. It features dual wireless connectivity options, a built-in touchpad, and multimedia shortcut keys.

2.4 GHz WIRELESS & BLUETOOTH CONNECTIVITY

For enjoying seamless work experience



Up to 10 meters lag-free wireless transmission

Figure 1: Portronics Bubble Pro Wireless Keyboard with Touchpad.

Key Features:

- **Dual Wireless Connectivity:** Supports both Bluetooth 5.0 and 2.4 GHz Wireless USB Receiver for flexible connection options.
- **Built-in Touchpad:** Integrated touchpad with left and right-click buttons, supporting scrolling and zooming functions.
- **Multi-Device Connection:** Connects up to 2 devices simultaneously, allowing easy switching between them.
- **Shortcut Keys:** Includes multimedia hotkeys for quick access to functions like mute, pause, volume control, plus a dedicated Indian Rupee symbol key.
- **Auto Power-Saving:** Automatically enters sleep mode after inactivity to conserve battery life.
- **10 Metres Wireless Range:** Provides a stable connection up to 10 meters (33 feet).
- **Ergonomic Typing:** Features anti-fade keycaps and noiseless key switches for a comfortable typing experience.
- **Spill-Resistant Design:** Designed to withstand accidental spills for increased durability.

2. SETUP GUIDE

2.1. Package Contents

Ensure all items are present in the package:

- Portronics Bubble Pro Wireless Keyboard
- USB Cable (for charging, if applicable, or for 2.4 GHz dongle)
- 2.4 GHz Wireless USB Receiver (located in the battery compartment)

Note: Batteries are not included and must be purchased separately (2 x AAA batteries).

2.2. Battery Installation

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely. The 2.4 GHz USB dongle is also stored here.



Figure 2: Location of battery compartment and 2.4 GHz USB dongle.

2.3. Connecting to Devices

The keyboard supports dual connectivity: Bluetooth 5.0 and 2.4 GHz Wireless.

2.3.1. 2.4 GHz Wireless Connection

1. Remove the 2.4 GHz USB receiver from the battery compartment.
2. Plug the USB receiver into an available USB port on your computer or device.
3. The keyboard should automatically connect.

2.3.2. Bluetooth 5.0 Connection

1. Turn on the keyboard.
2. Activate Bluetooth on your device (e.g., smartphone, tablet, laptop).
3. On the keyboard, press the Bluetooth pairing key (refer to keyboard layout for specific key, often indicated by a Bluetooth icon or 'BT').

4. On your device, search for new Bluetooth devices and select "Portronics Bubble Pro" from the list.
5. Follow any on-screen prompts to complete the pairing process.

PAIRS WITH YOUR DEVICES

Connect 2 devices and switch according to your device



Figure 3: Keyboard connected to a laptop via 2.4 GHz wireless and a smartphone via Bluetooth.

3. OPERATING INSTRUCTIONS

3.1. Switching Between Connected Devices

The Portronics Bubble Pro keyboard allows connection to up to two devices simultaneously. Use the dedicated keys to switch between them:

- Press the **2.4G Wireless** key to switch to the device connected via the USB dongle.

- Press the **Bluetooth** key to switch to the device connected via Bluetooth.

AUTO POWER SAVING

Enters sleep mode automatically when not in use, saving battery life and reducing battery replacement



Figure 4: Keyboard layout highlighting connectivity keys.

3.2. Touchpad Functions

The integrated touchpad provides mouse-like functionality:

- **Pointing:** Move your finger across the touchpad to control the cursor.
- **Left-Click:** Press the left-click button below the touchpad or tap once on the touchpad surface.
- **Right-Click:** Press the right-click button below the touchpad or tap with two fingers on the touchpad surface.
- **Scrolling:** Use two fingers to scroll up or down on the touchpad.
- **Zooming:** Pinch in or out with two fingers to zoom.

BUILT-IN TOUCHPAD



Figure 5: Touchpad area with indicators for point and scroll functions.

3.3. Shortcut Keys

The keyboard is equipped with multimedia hotkeys and a dedicated Rupee symbol key:

- **Multimedia Hotkeys:** Access functions like mute, pause, play, volume up/down, etc., typically located on the F-keys (F1-F12) and activated by pressing the 'Fn' key simultaneously.
- **Indian Rupee Symbol (₹):** A dedicated key is available for typing the Indian Rupee symbol.

3.4. Auto Power-Saving Mode

To conserve battery life, the keyboard automatically enters sleep mode after a period of inactivity. To wake it up, simply press any key or move the touchpad.

NOISELESS TYPING

Enjoy quiet and comfortable typing experience
with noiseless key switch design



Figure 6: Keyboard demonstrating auto power-saving feature.

4. MAINTENANCE

4.1. Cleaning

- Use a soft, damp cloth to wipe the surface of the keyboard.
- For dust and debris between keys, use compressed air.
- The keyboard features a spill-resistant design, allowing easy cleanup of accidental water splashes. However, avoid submerging the device in liquid.

DURABLE AND SPILL-RESISTANT

Easy to wipe it clean after accidental water splashes



Scratch-resistant
ABS Material



Anti-fading
Keycap Fonts

Figure 7: Keyboard showcasing its spill-resistant design.

4.2. Battery Replacement

When the keyboard's performance degrades or it stops responding, it may be time to replace the AAA batteries. Follow the battery installation steps in Section 2.2.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Keyboard not responding	Low battery; Not connected; In sleep mode.	Replace batteries; Re-establish connection (Bluetooth or 2.4 GHz); Press any key to wake up.
Connectivity issues (lag, disconnection)	Interference; Device too far; Low battery.	Move closer to the device; Ensure no strong interference sources; Replace batteries.
Touchpad not working correctly	Driver issue; Dirty touchpad; Software conflict.	Ensure correct drivers are installed (if applicable); Clean touchpad surface; Restart device.
Keys not registering or double-typing	Low battery; Debris under key; Software issue.	Replace batteries; Clean under the affected key; Test on another device to rule out software issues.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Portronics
Model Number	POR-1888
Connectivity Technology	Bluetooth 5.0 & 2.4 GHz Wireless
Color	Black
Form Factor	Wireless Keyboard with Touchpad
Product Dimensions	38 x 13 x 2.5 cm
Item Weight	350 g
Power Source	Battery Powered (2 x AAA, not included)
Wireless Range	Up to 10 meters (33 feet)
Compatible Devices	Laptop, Mac, PC, Smartphone (iOS, Android, Windows Tablets)
Included Components	USB Cable (purpose not specified for this battery-powered model)

7. WARRANTY AND SUPPORT

7.1. Warranty Information

The Portronics Bubble Pro Wireless Keyboard comes with a **1 Year Warranty** from the date of purchase. Please retain your purchase receipt for warranty claims.

7.2. Customer Support

For any support, queries, or warranty claims, please contact Portronics customer service:

- **Manufacturer:** Portronics Digital Pvt Ltd
- **Contact Number:** 9555-245-245
- **Address:** Unit No. 1082-1090, 10th Floor, Block-B, Vegas, Dwarka, Sec-14, New Delhi-110075
- **Online Store:** [Visit the Portronics Store on Amazon.in](#)

8. PRODUCT VIDEOS

8.1. Portronics Bubble Pro Wireless Keyboard Overview

Your browser does not support the video tag.

This video provides a brief overview of the Portronics Bubble Pro Wireless Keyboard, highlighting its dual connectivity, built-in touchpad, multi-device connection, shortcut keys, auto power-saving, 10-meter wireless range, and ergonomic design. It showcases the product's main features and benefits.