

[Manuals.plus](#) /

› [KU XIU](#) /

› KU XIU X55 3-in-1 Magnetic Foldable Wireless Charging Station User Manual

KU XIU X55

KU XIU X55 3-in-1 Magnetic Foldable Wireless Charging Station User Manual

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your KU XIU X55 3-in-1 Magnetic Foldable Wireless Charging Station. Please read this manual thoroughly before operating the device to ensure optimal performance and safety. Keep this manual for future reference.



Figure 1: KU XIU X55 Charging Station in upright mode, charging three devices.

PACKAGE CONTENTS

Verify that all items are present in the package:

- KU XIU X55 3-in-1 Wireless Charging Station
- USB-C Charging Cable
- 20W Power Adapter
- User Manual (this document)
- Storage Box



Figure 2: Included components of the KU XIU X55 package.

SETUP INSTRUCTIONS

1. **Unpack the Charger:** Carefully remove the charging station and all accessories from the packaging.
2. **Connect Power:** Insert the USB-C end of the charging cable into the port on the back of the KU XIU X55 charging station. Connect the USB-A end of the cable to the provided 20W power adapter, then plug the adapter into a wall outlet.
3. **Position the Charger:** The KU XIU X55 is designed for versatile placement. It can be used in a folded flat mode, an upright stand mode, or various angled positions to suit your preference. Adjust the hinges to achieve the desired configuration.




Figure 3: The charging station can be adjusted to various positions for optimal viewing and charging.

OPERATING INSTRUCTIONS

The KU XIU X55 allows simultaneous wireless charging for compatible iPhone models, Apple Watch, and AirPods with a wireless charging case.

1. Charging an iPhone (15W Max)

- Ensure your iPhone is compatible with MagSafe or Qi wireless charging. For optimal magnetic alignment and charging speed, use an iPhone 12 series or newer, or a MagSafe-compatible case.
- Place your iPhone onto the upright magnetic charging pad. The magnets will automatically align your device for efficient charging.
- The charging indicator on your iPhone screen will confirm charging has begun.



Figure 4: iPhone placement and compatibility for the magnetic charging pad.

2. Charging an Apple Watch (5W Max)

- Place your Apple Watch onto the dedicated watch charging module.
- Ensure the watch is properly seated and the charging icon appears on the watch display.



Figure 5: Apple Watch placement and compatibility for its charging module.

3. Charging AirPods (5W Max)

- Place your AirPods case (must be a wireless charging compatible case) onto the flat charging pad at the base of the station.
- The indicator light on your AirPods case will illuminate to confirm charging.




Figure 6: AirPods placement and compatibility for the base charging pad.

Compatibility Notes

- **iPhone:** Compatible with iPhone 12 series and newer (including 17/16/15/14/13/12 Pro/Plus/Pro Max) for magnetic charging. Also supports other Qi-enabled smartphones.
- **Apple Watch:** Compatible with Apple Watch Series 2/3/4/5/6/7/8/9/SE/Ultra/Ultra 2. Not compatible with Apple Watch Series 10.
- **AirPods:** Compatible with AirPods Pro/3/2 with wireless charging cases. Not compatible with AirPods 1st generation or AirPods 2nd generation without a wireless charging case.
- For iPhone magnetic charging, a MagSafe-compatible case is recommended if your phone is not directly MagSafe enabled. Non-magnetic cases may prevent proper alignment and charging.



Figure 7: Magnetic cases are recommended for secure iPhone charging.

MAINTENANCE

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Do not use abrasive cleaners, solvents, or chemical agents.
- **Storage:** When not in use, especially during travel, fold the charging station into its compact form and store it in the provided storage box to protect it from dust and damage.

- **Avoid Liquids:** Keep the charging station away from water and other liquids.
- **Temperature:** Operate and store the device within normal room temperatures. Avoid extreme heat or cold.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging	1. Incorrect placement 2. Incompatible device/case 3. Power adapter/cable issue 4. Foreign object detected	1. Re-position device for proper alignment. 2. Ensure device/case is wireless charging compatible. 3. Check power connections; use provided 20W adapter. 4. Remove any metal objects between device and charger.
Slow charging	1. Insufficient power input 2. Device/charger overheating 3. Thick phone case	1. Use the provided 20W power adapter. 2. Disconnect devices, allow to cool, then retry. 3. Remove phone case or use a MagSafe-compatible thin case.
Magnetic connection is weak	1. Non-MagSafe phone/case 2. Thick phone case	1. Ensure your iPhone is MagSafe compatible or use a MagSafe-compatible case. 2. Remove phone case or use a thinner, MagSafe-compatible case.
Charger indicator light not on	1. No power connection 2. Faulty unit	1. Check power cable and adapter connections. 2. Contact customer support if power is connected but no indicator.

SPECIFICATIONS

- **Model:** X55
- **Input Voltage:** 5 Volts
- **Amperage:** 4 Amps
- **Connectivity:** Wireless
- **Charging Output (iPhone):** Up to 15W Max
- **Charging Output (Apple Watch):** Up to 5W Max
- **Charging Output (AirPods):** Up to 5W Max
- **Special Features:** Charging Indicator, Fast Charging, Magnetic, MagSafe Compatible, Foldable Design
- **Dimensions (Folded):** Approximately 2.68 x 2.68 x 1.18 inches (6.8 x 6.8 x 3 cm)
- **Item Weight:** 4.9 ounces (139 grams)
- **Manufacturer:** Shenzhen Kuxiu Communication Co., Ltd.

SAFETY INFORMATION

- Do not disassemble, modify, or repair the device yourself.
- Avoid exposing the device to extreme temperatures, direct sunlight, or high humidity.

- Keep the device away from strong magnetic fields.
- Do not place metal objects, credit cards, or other foreign objects on the charging surface, as this may interfere with charging or cause damage.
- Ensure proper ventilation around the charger during use.
- This device is equipped with over-current protection, over-voltage protection, over-temperature protection, and foreign object detection for safe operation.

A Variety of Placement

Both Charger and Stand




Figure 8: Built-in intelligent chipset safeguards your devices while charging.

WARRANTY AND SUPPORT

The KU XIU X55 3-in-1 Wireless Charging Station is protected by a registered US patent with patent number USD1030648S. Please verify the authenticity of your purchase.

For any questions, issues, or support inquiries regarding your KU XIU X55 charging station, please contact KU XIU customer service through the retailer where the product was purchased. Please have your purchase details and product model number (X55) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question