

INFANS BE10026

INFANS 4-in-1 Pack and Play User Manual

Model: BE10026 | Brand: INFANS

INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the INFANS 4-in-1 Pack and Play. This versatile nursery center is designed to provide a safe, comfortable, and convenient environment for your child from newborn to toddler. It functions as a bassinet, changing table, spacious playpen, and baby bed with canopy and net.

Please read this manual thoroughly before assembly and use to ensure proper operation and safety. Keep these instructions for future reference.

Important Safety Warnings:

- Always ensure all parts are correctly assembled and locked before placing a child in the playard.
- Never leave your child unattended in the playard.
- Do not use this product if any parts are broken, torn, or missing.
- Ensure the mattress is always placed firmly and securely at the bottom of the playard.
- Keep all small parts and packaging materials away from children.
- This product is suitable for children aged 0-36 months and up to 33 lbs.

SETUP AND ASSEMBLY

Follow these steps carefully to assemble your INFANS 4-in-1 Pack and Play. Refer to the accompanying video for visual guidance.

1. Unpacking and Initial Setup

Remove all components from the carrying bag and packaging. Lay them out on a clean, flat surface to identify all parts.



Image: The INFANS 4-in-1 Pack and Play in its assembled state, alongside its compact carrying bag.

2. Unfolding the Playard

1. Remove the playard from its folded state.
2. Pull the side rails upwards until they lock into place. Ensure all four sides are securely locked.
3. Push down the center of the playard floor until it lies flat.

Easy Folding & Installation

Baby Activity Center



01



02



03



Unfolded
State



Portable Design



Folded
State

Image: Visual guide showing the easy folding and installation process of the playard, from unfolded to folded state.

3. Installing the Bassinet

For infants, the bassinet provides a raised sleeping surface. Assemble the bassinet frame by connecting the metal poles. Insert the poles into the fabric sleeves of the bassinet attachment. Secure the bassinet to the top rails of the playard using the provided clips and straps.

4-In-1 Baby Playard



Detachable Changing Table



Baby Activity Center



Infant Bassinet



Baby Bed with Canopy and Net

Image: The 4-in-1 Baby Playard showcasing its various configurations, including the infant bassinet and detachable changing table.

4. Installing the Changing Table

Attach the changing table to the top rails of the playard. Ensure it is securely fastened with the clips and straps. The changing table is removable for convenience.

5. Installing Canopy, Mosquito Net, Music Box, and Toys

- Assemble the canopy frame and attach it to the designated points on the playard.
- Drape the mosquito net over the canopy and secure it around the playard to protect your baby from insects.
- Attach the music box to the side rail.
- Hang the included toys from the canopy for your baby's entertainment.

Thoughtful Design for Baby



Image: A close-up of the playard highlighting thoughtful design features such as the music box with lights, hanging toys, and a convenient side storage pocket.

Must-Have Baby Crib for Summer

Undisturbed by uninvited guests



Image: The playard configured as a baby crib for summer, featuring a canopy with mosquito nets and a soft, breathable mattress.

Setup Video Guide:

Your browser does not support the video tag.

Video: A comprehensive guide demonstrating the installation process of the INFANS 4-in-1 Pack and Play, including unfolding, bassinet setup, changing table attachment, and canopy installation.

OPERATING INSTRUCTIONS

Using as a Playard:

Once fully assembled, the playard provides a secure space for your child to play. The 4-sided transparent mesh design allows for easy visibility of your baby's movements. Ensure the mattress is at the lowest position for playard use.

4 Sides Seeing Through Net



Image: The playard featuring its 4-sided transparent mesh, allowing clear visibility of the child inside.

Using the Bassinet:

The bassinet is ideal for newborns, providing a comfortable and elevated sleeping area. Always ensure the bassinet is securely attached to the playard rails before placing your baby inside.

Using the Changing Table:

The detachable changing table offers a convenient surface for diaper changes. Always use the safety straps provided on the changing table to secure your baby. Never leave your baby unattended on the changing table.

Music Box and Hanging Toys:

The music box can be activated to soothe your baby or attract their attention. The hanging toys provide visual stimulation and entertainment. Ensure the music box is securely attached and toys are out of reach of a standing child.

Mobility:

The playard features 2 lockable wheels for effortless movement. To move the playard, unlock the wheels. To secure it in place, lock the wheels.

2 Smooth Wheels for Easy Movement



Low Noise



360° Rotation



Image: A detailed view of the playard's two smooth, lockable silent wheels, designed for easy movement and secure positioning.

MAINTENANCE AND CARE

Cleaning Instructions:

The fabric components of the playard, including the mattress, are made from Oxford cloth and mesh material. For cleaning, it is recommended to hand wash only. Use mild soap and cold water. Do not use bleach. Air dry thoroughly before reassembly or storage.

Wipe down the metal frame and plastic components with a damp cloth and mild soap. Ensure all parts are dry to prevent rust or mildew.

Storage:

The playard features a foldable design for easy transport and storage. To fold, remove all attachments (bassinet, changing table, canopy, music box, toys). Pull the center of the playard floor upwards, then release the side rails by pressing the buttons on the top rails. Collapse the playard and secure it with the straps. Store in the included carrying bag.

in a dry place.

TROUBLESHOOTING

If you encounter any issues with your INFANS 4-in-1 Pack and Play, please refer to the following common solutions:

- **Playard not locking:** Ensure the center of the playard floor is fully pushed down. The side rails will not lock if the center is not fully depressed. If the side rails are not locking, try lifting the center slightly, locking the rails one by one, and then pushing the center down again.
- **Parts not fitting:** Double-check that you are using the correct parts for each section as per the assembly instructions. Sometimes, similar-looking poles or connectors are specific to certain attachments.
- **Music box not working:** Check the batteries and ensure they are inserted correctly. If the issue persists, contact customer support.
- **Unpleasant smell:** New products may have a slight manufacturing smell. Air out the product in a well-ventilated area for a few days before use.

If you are unable to resolve an issue, please contact INFANS customer support for assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions	41 x 31 x 29.5 inches (L x W x H)
Item Model Number	BE10026
Target Gender	Unisex
Maximum Weight Recommendation	33 Pounds
Material Type	Oxford Cloth, Steel, PP
Care Instructions	Hand Wash Only
Additional Product Features	Foldable, Lightweight, Portable
Style	With Canopy
Folded Size	30 inches (L) x 20 inches (W) x 6 inches (H)
Item Weight	22 Pounds
Suitable Age	0-36 Months

Product Dimension



Weight Capacity:
33 lbs



Suitable Age:
0-36 Months



Net Weight:
23 lbs




Image: A diagram illustrating the key dimensions, weight capacity, suitable age, and net weight of the INFANS Pack and Play.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your INFANS 4-in-1 Pack and Play, please contact the manufacturer directly. Refer to the product packaging or the official INFANS website for contact information.

INFANS is committed to providing quality and comfortable products for your baby. Your satisfaction is important.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C9Z9VRPQ>

More documents and user manuals: <https://manuals.plus/>