

[Manuals.plus](#) /

› [Ufree](#) /

› Ufree U-1176 Charger Cord Instruction Manual

Ufree U-1176

Ufree U-1176 Charger Cord Instruction Manual

Model: U-1176 | Brand: Ufree

PRODUCT OVERVIEW

The Ufree U-1176 Charger Cord is designed to provide reliable power to your Ufree beard trimmer or similar compatible devices. This package includes a USB charging cable and an AC power adapter, offering versatile charging options.

SPACE SAVING & COMPACT DESIGN

Easy to carry and use




Image: The Ufree U-1176 charger cord and AC adapter, showing both components included in the package.

PACKAGE CONTENTS

- 1 x USB Charging Cable (3.3 feet / 1 meter)
- 1 x AC Power Adapter

SETUP INSTRUCTIONS

1. **Connect the USB Cable:** Insert the USB-A end of the charging cable into the AC power adapter.
2. **Connect to Power Source:** Plug the AC power adapter into a standard wall outlet (100-240V). Alternatively, the USB-A end of the cable can be plugged into any compatible USB power source such as a power bank, laptop, or other USB wall adapter.
3. **Connect to Device:** Insert the small charging end of the USB cable into the charging port of your Ufree beard trimmer or compatible device. Ensure a secure connection.




Image: The compact design of the AC adapter and USB cable, illustrating their dimensions for portability and ease of use.

OPERATING INSTRUCTIONS (CHARGING YOUR DEVICE)

1. Once connected as described in the Setup section, your device should begin charging automatically.
2. Monitor your device's charging indicator (if available) to confirm charging status.
3. Disconnect the charger once your device is fully charged to conserve energy and prolong battery life.



Image: The Ufree charger connected to a beard trimmer, showing a stable charging connection and the device's charge time display.

MAINTENANCE AND CARE

- Keep the charger and cable clean and dry. Avoid exposure to liquids.
- Do not expose the charger to extreme temperatures or direct sunlight.
- Store the charger in a cool, dry place when not in use.
- Avoid bending or twisting the cable excessively to prevent internal damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	Loose connection, faulty outlet, incompatible device.	◦ Ensure all connections are secure. ◦ Try a different wall outlet or USB port. ◦ Verify your device is compatible with 5V 1A USB charging.
Slow charging.	Low power USB source, device drawing more power than supplied.	◦ Use the provided AC adapter for optimal charging speed. ◦ Ensure the USB power source provides at least 5V 1A output.
Charger or device gets hot.	Normal operation (slight warmth), or overheating due to malfunction.	◦ Slight warmth is normal. ◦ If excessively hot, disconnect immediately and contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number (Charger)	YH-S06U0501000
Input	100-240V~50/60Hz
Output	5V 1A

Feature	Detail
Cable Length	3.3 feet (approx. 1 meter)
Connector Type	USB-A to proprietary charging plug (Male-to-Female)
Color	Black
Special Features	Rechargeable device compatibility

WARRANTY AND SUPPORT

Ufree provides a **12-month (one-year) warranty period** for this product from the date of purchase.

For technical assistance, troubleshooting, or warranty claims, please contact Ufree customer service. We offer **24-hour customer service support**.

For more information, visit the [Ufree Store on Amazon](#).