

XOKOTAKI O0313

XOKOTAKI Modular Organizer Instruction Manual

MODEL: O0313

1. Introduction

The XOKOTAKI Modular Organizer is a versatile storage solution designed to help you organize various items such as bags, clothes, toys, and books. Its modular design allows for flexible configuration to fit different spaces within your home, including wardrobes, hallways, bedrooms, and living rooms. This manual provides essential information for the safe and efficient assembly, use, and maintenance of your new organizer.

2. Safety Information and Warnings

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in injury or damage to the product.

- **Caution during installation:** Handle all components with care to prevent pinching or injury.
- **Use only in dry environments:** This product is not designed for outdoor use or in high-humidity areas. Exposure to excessive moisture may compromise the material integrity.
- **Do not overload:** Distribute weight evenly and do not exceed the recommended weight capacity per module to ensure stability.
- **Keep away from open flames and heat sources:** The polypropylene plastic material can melt or deform when exposed to high temperatures.
- **Keep out of reach of small children:** Small parts could pose a choking hazard during assembly.

3. Package Contents

Before beginning assembly, please verify that all components listed below are present in your package:

- 32 x ABS Connectors
- 12 x Panels (35 x 45 cm)
- 9 x Panels (35 x 17 cm)

- 12 x Panels (45 x 17 cm)
- 1 x Wooden Hammer

4. Assembly Instructions

The modular organizer is designed for easy assembly. An illustrated guide is included to assist you. You will primarily use the connectors and the provided wooden hammer to join the panels.

1. **Prepare Components:** Unpack all panels and connectors. Ensure you have enough space to assemble the unit.
2. **Connect Panels:** Begin by joining the panels using the ABS connectors. Insert the corners of the panels firmly into the slots of the connectors. Use the wooden hammer to gently tap the panels into place, ensuring a secure fit.
3. **Build Modules:** Construct individual cubic modules by connecting four side panels and a top/bottom panel.
4. **Stack and Configure:** Once individual modules are built, stack and connect them according to your desired configuration. The 9 modules can be arranged in various ways to suit your space and storage needs.
5. **Finalize Connections:** Ensure all connections are tight and stable. Gently push or tap any loose panels until they are fully seated in the connectors.



Image: Step-by-step assembly process, illustrating how to join panels with connectors.



Image: Dimensional overview of the assembled 9-module organizer, indicating its overall size.

5. Usage and Versatility

The XOKOTAKI Modular Organizer is designed to provide flexible storage for a variety of items. Its 9 modules can be configured to suit different organizational needs within your home.

- **Bag Storage:** Ideal for organizing handbags, clutches, and backpacks, keeping them upright and easily accessible.
- **Clothing Organization:** Store folded clothes, scarves, or small garments within the modules.
- **Toy Storage:** A convenient solution for tidying up children's toys in playrooms or bedrooms.
- **Book and Media Shelf:** Use modules to store books, magazines, or media items.
- **Shoe Rack:** Can be adapted to store shoes, keeping them neatly arranged.

The modular design allows you to create a storage unit that perfectly fits into your wardrobe, a corner of a room, or along a hallway wall, maximizing your storage potential.





Image: The modular organizer showcasing its capacity for storing multiple handbags.



Image: Examples of the organizer's versatility, storing different types of items like clothing, footwear, and books.

6. Maintenance and Care

The XOKOTAKI Modular Organizer is constructed from durable and moisture-resistant PP plastic, making it easy to clean and maintain.

- **Cleaning:** To clean the organizer, simply wipe it with a dry cloth. For more stubborn dirt, a slightly damp cloth can be used, followed by drying with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the plastic surface.
- **Regular Inspection:** Periodically check all connections to ensure they remain secure. Re-tap with the wooden hammer if any panels feel loose.




Image: Illustration of the organizer's material and the recommended method for cleaning.

7. Troubleshooting

While the XOKOTAKI Modular Organizer is designed for straightforward assembly and use, here are some common issues and their solutions:

- **Unit feels wobbly or unstable:** Ensure all panels are fully inserted into the connectors. Use the wooden hammer to firmly tap each connection point until it is secure. Check that the unit is placed on a flat, level surface.

- **Panels do not fit into connectors:** Verify that you are using the correct panels for the intended connection. Apply firm, even pressure, and use the wooden hammer to assist in seating the panels.
- **Missing parts:** Refer to the 'Package Contents' section. If any parts are missing, please contact customer support.

8. Specifications

Feature	Detail
Brand	XOKOTAKI
Model	O0313
Color	O0313
Product Dimensions (assembled)	51 cm (Depth) x 35 cm (Width) x 135 cm (Height)
Item Weight	5.48 Kilograms
Material	PP Plastic
Number of Shelves	9 (modules)
Special Feature	Stain Resistant
Assembly Required	Yes
Care Instructions	Wipe with dry cloth

9. Warranty and Support

For any questions, concerns, or issues regarding your XOKOTAKI Modular Organizer, please contact the manufacturer or your point of purchase. Please have your model number (O0313) and purchase information ready when contacting support.