



Manuals.plus /

› SUPERJARE /

› SUPERJARE TV Stand 53.9" (Gray and White) - Instruction Manual

SUPERJARE B0CB2FBBPH

SUPERJARE TV Stand 53.9" (Gray and White) - Instruction Manual

Model: B0CB2FBBPH

INTRODUCTION

Thank you for choosing the SUPERJARE 53.9-inch TV Stand. This entertainment center is designed to accommodate TVs up to 55 inches, and potentially larger depending on leg placement, offering a stylish and functional solution for your living room or bedroom. It features adjustable shelving, two spacious cabinets for concealed storage, and integrated cord holes for organized cable management. Constructed with durable P2 particleboard and supported by solid wood feet, this TV stand combines modern aesthetics with lasting stability.

SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the TV stand; adhere to weight limits for the top surface and shelves.
- Place the TV stand on a level, stable surface to prevent tipping.
- Keep small parts and packaging materials away from children.
- Consider using anti-tip restraints (not included) for added safety, especially in homes with children or pets.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- TV Cabinet Body (Top, Bottom, Side Panels, Middle Dividers)
- Adjustable Shelves
- Cabinet Doors
- Handles
- Solid Wood Feet (6 pieces, including 2 adjustable middle feet)
- Assembly Hardware (screws, cam locks, dowels, hinges, magnetic catches)

- Screwdriver (for assembly)
- Illustrated Instruction Manual

SETUP / ASSEMBLY INSTRUCTIONS

Assembly of this TV stand is designed to be straightforward with the provided illustrated instructions and numbered components. An included screwdriver facilitates the process. It is recommended to assemble the unit in the room where it will be used.




Image: Dimensions of the TV stand, indicating suitability for TVs up to 55-65 inches. The stand measures 53.9 inches wide, 11.8 inches deep, and 19.7 inches high.

General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list in the instruction manual to ensure everything is present and undamaged.
2. **Attach Feet:** Secure the six solid wood feet to the bottom panel of the TV stand. The two middle feet are adjustable to help balance the unit on uneven floors.
3. **Assemble Main Body:** Follow the numbered steps in the manual to connect the side panels, bottom panel, and middle dividers using the provided hardware (cam locks, dowels, screws). Ensure all connections are snug but do not overtighten until the unit is fully assembled.
4. **Install Shelves:** Insert the adjustable shelves into the designated slots within the open compartments. These shelves can be positioned at three different height levels.

5. **Attach Cabinet Doors:** Mount the cabinet doors using the provided hinges and handles. Ensure the doors align properly and close smoothly. Magnetic catches are included to keep the doors securely closed.
6. **Final Tightening:** Once the entire unit is assembled, gently tighten all screws and fasteners to ensure stability.



Image: Detail of the adjustable middle shelf, showing three possible height settings for flexible storage.



Image: Features such as magnetic cabinet doors for secure closure, adjustable feet for stability on uneven surfaces, and a scratch-resistant surface for durability.

OPERATING INSTRUCTIONS

Adjustable Shelves:

The middle shelf in the open compartment is adjustable to three different height levels. To adjust, simply remove the shelf, reposition the support pins to your desired height, and place the shelf back onto the pins. This allows for customization to fit various media devices or decorative items.

Cabinet Storage:

The two cabinets provide enclosed storage space. Open the doors by gently pulling the handles. The magnetic catches will keep the doors closed when not in use, helping to conceal clutter and maintain a tidy appearance.

Cable Management:

The TV stand includes four cord holes located on the back panel of the open compartments. Utilize these holes to route power cables and audio/video wires, keeping them organized and out of sight. This helps prevent tangled cables and maintains a clean aesthetic.



Image: The back of the TV stand featuring multiple cord holes to help organize and manage cables from electronic devices.

MAINTENANCE

Cleaning:

To clean the TV stand, simply wipe it with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these

may damage the finish. Dry immediately with a clean, soft cloth.

General Care:

- Periodically check all fasteners and re-tighten if necessary to maintain stability.
- Avoid exposing the TV stand to direct sunlight or extreme temperature changes, which can cause warping or fading.
- Use coasters or protective pads under hot or wet items to prevent damage to the surface.

TROUBLESHOOTING

Unit feels wobbly:

Ensure all assembly screws and cam locks are fully tightened. Check that the adjustable middle feet are properly adjusted to make firm contact with the floor, compensating for any unevenness.

Cabinet doors do not close properly:

Verify that the hinges are correctly installed and tightened. Check the alignment of the magnetic catches on the door and the cabinet frame. Adjust if necessary.

Missing or damaged parts:

Refer to the 'Support' section for contact information to request replacement parts.

SPECIFICATIONS

Brand:	SUPERJARE
Model:	B0CB2FBBPH
Color:	Gray and White
Size:	53.9"
Item Dimensions (L x W x H):	53.9 x 11.8 x 19.7 inches
Item Depth:	15.7 inches
Item Weight:	19822 Grams
Material Type:	Engineered Wood, Wood
Style:	Modern
Required Assembly:	Yes
Included Components:	4 Solid Wood Feet, Handles, TV Cabinet Body

WARRANTY INFORMATION

This SUPERJARE TV Stand comes with a standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and claims process, please refer to the documentation included with your purchase or contact SUPERJARE customer support directly.

SUPPORT

Should you require assistance with assembly, have questions about product features, or need to report missing/damaged parts, please contact SUPERJARE customer support. You can typically find contact information (email, phone, or website) on the product packaging or within the included instruction manual. Please have your model number (B0CB2FBBPH) and purchase date ready when contacting support.