



**Manuals.plus /**

› **WEWARM /**

› WEWARM HT8006N Infrared Outdoor Heater 1500W Instruction Manual

## **WEWARM HT8006N**

# **WEWARM HT8006N Infrared Outdoor Heater 1500W Instruction Manual**

This manual provides essential information for the safe and efficient operation of your WEWARM HT8006N Infrared Outdoor Heater. Please read thoroughly before use.

## **INTRODUCTION**

The WEWARM HT8006N Infrared Outdoor Heater is a versatile 1500W heating solution designed for both indoor and outdoor use. Featuring 3 heat settings (700W, 1000W, 1500W) and a 12-hour programmable timer, it offers customizable comfort. Its IP65 waterproof and dustproof rating ensures durability in various weather conditions. The heater can be used as a standing unit with its adjustable tripod or conveniently wall-mounted. Safety features include overheat and tip-over protection, along with a child safety lock.



The WEWARM HT8006N Infrared Outdoor Heater on its adjustable tripod stand, showcasing its sleek design and included remote control. This image highlights the product's readiness for immediate use in an outdoor setting.



An infrared patio heater providing warmth to a group of people enjoying an outdoor meal, demonstrating its effectiveness in extending outdoor seasons.

## IMPORTANT SAFETY INFORMATION

Before operating this appliance, read all instructions and warning labels. Failure to follow these instructions may result in electric shock, fire, or serious injury.

### General Safety Precautions

- Always plug the heater directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not use outdoors if not specifically designed for outdoor use. (This heater is IP65 rated for outdoor use).
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause

fire, electric shock, or injury to persons.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

### Specific Safety Features

- **Overheat Protection:** The heater is equipped with an automatic overheat protection system that will shut off the unit if it becomes too hot.
- **Tip-Over Safety Shutoff:** If the heater is accidentally tipped over, the safety switch will automatically turn off the unit to prevent hazards.
- **Child Safety Lock:** This feature prevents unintended changes to settings, ensuring safe operation around children.



Close-up of the heater's control panel with water droplets, illustrating its IP65 dustproof and waterproof rating for enhanced durability and safety in outdoor environments.



An animated image demonstrating the heater's automatic power-off protection when tipped, highlighting a key safety feature.

## **PACKAGE CONTENTS**

Please check the box for the following items:

- Infrared Heater Unit
- Tripod Stand
- Wall Mounting Brackets
- Fireproof Rack (Safety Rack)
- Remote Control
- Installation Hardware (screws, nuts, bolts)
- User Manual



The complete package contents laid out, including the infrared heater unit, tripod stand, remote control, and various installation accessories.

## SETUP INSTRUCTIONS

### Tripod Stand Assembly

1. Unfold the tripod legs and secure them firmly.
2. Extend the main pole of the tripod to your desired height and lock it in place using the adjustment knob.
3. Attach the heater unit to the top of the tripod pole using the provided bracket and bolt pin. Ensure all connections are secure.
4. Adjust the angle of the heater as needed and tighten the adjustment screws.
5. Install the fireproof rack by inserting its ends into the designated holes on the back of the heater and securing with screws.

A video demonstrating the step-by-step assembly of the infrared heater onto its tripod stand, including securing the legs, attaching the heater, and adjusting its height.

A comprehensive video guide showing the installation process for the outdoor patio heater, covering both tripod and wall-mounted options, and basic operation.



The heater mounted on its adjustable tripod, with dimensions indicating its height and width, illustrating its adaptability to different spaces.

### Wall Mounting (Optional)

1. Select a suitable wall location, ensuring it is a safe distance from combustible materials (at least 3 feet / 0.9m).
2. Mark the drilling points for the wall mounting brackets.
3. Drill holes and insert the expansion bolts (if necessary).
4. Secure the wall mounting brackets to the wall.
5. Attach the heater unit to the wall mounting brackets using the provided screws and nuts. Ensure the heater is securely fastened and level.
6. Install the fireproof rack by inserting its ends into the designated holes on the back of the heater and securing with screws.

The infrared heater securely mounted on a brick wall, demonstrating its alternative installation method for fixed heating solutions.

## OPERATING INSTRUCTIONS

### Powering On/Off

Plug the heater into a suitable electrical outlet. Locate the main power switch (usually on the side or back of the unit) and turn it ON. The LED display will illuminate.

To turn the heater ON or OFF, press the power button on the control panel or the remote control.

### Adjusting Heat Settings

The heater offers 3 heat settings: Low (700W), Medium (1000W), and High (1500W).

Press the "HI", "MED", or "LO" buttons on the control panel or remote control to select the desired heat level. The LED display will show the current setting.

# Infrared Heat Up In 3 Seconds

Instant heating carbon fiber

750W 1000W 1500W

An image illustrating the rapid heating capability of the infrared heater, showing the three available power settings: 750W, 1000W, and 1500W.

## Using the Timer Function

The heater features a 12-hour programmable timer.

To activate the timer, press the "Timer" button on the control panel or remote control. Each press will increase the timer duration by 1 hour, up to 12 hours. The LED display will show the set timer.


The heater will automatically turn off once the set timer duration has elapsed.



A close-up view of the heater's control panel displaying the '12h' timer function, indicating its programmable shutdown capability.

## Remote Control

The included remote control allows for convenient operation of all heater functions from a distance. Ensure the remote has working batteries.



A user operating the heater with the remote control, highlighting the ease of use and the clear LED display on the unit.



A hand holding the remote control for the heater, showing its buttons for power, heat settings, timer, and child lock.

## Child Safety Lock

To activate the child safety lock, press and hold the "Child Lock" button on the remote control for 3 seconds. The lock indicator on the LED display will illuminate.

To deactivate, press and hold the "Child Lock" button again for 3 seconds.

## MAINTENANCE

### Cleaning

Always unplug the heater and allow it to cool completely before cleaning.

Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.

Do not immerse the heater in water or allow water to drip into the interior.

Periodically check the heating elements for dust or debris. Use a soft brush or compressed air to gently clean if necessary.

### Storage

When not in use, store the heater in a cool, dry place, preferably in its original packaging.

## TROUBLESHOOTING

### Heater Does Not Turn On

- Check if the power cord is securely plugged into a working outlet.
- Ensure the main power switch on the unit is in the ON position.
- Verify that the remote control batteries are not depleted.
- Check if the overheat or tip-over safety features have been activated. Unplug the unit, wait a few minutes, and then plug it back in.

### Heater Not Emitting Enough Heat

- Ensure the heater is set to the highest heat setting (1500W).
- Check for any obstructions blocking the heat output.
- Consider the size of the area being heated; infrared heaters are most effective for direct, localized heating.

### Remote Control Not Working

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the heater's receiver.
- Check if the child safety lock is activated on the remote.

## SPECIFICATIONS

<b>Brand</b>	WEWARM
<b>Model Number</b>	HT8006N
<b>Power</b>	1500W (Adjustable: 700W, 1000W, 1500W)
<b>Voltage</b>	110 Volts
<b>Amperage</b>	12.5 Amps
<b>Indoor/Outdoor Usage</b>	Outdoor (IP65 Rated)
<b>Waterproof Rating</b>	IP65
<b>Timer</b>	12-hour programmable
<b>Mounting Type</b>	Wall Mount and Standing (with tripod)
<b>Product Dimensions</b>	2.76"D x 6.3"W x 32.28"H
<b>Item Weight</b>	15.43 pounds
<b>Special Features</b>	Adjustable Height, Digital Display, Overheat Protection, Tip-Over Safety Shutoff, Child Safety Lock

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official WEWARM website. Keep your purchase receipt as proof of purchase.