

[Manuals.plus](#) /

› [HKY](#) /

› HKY 24V AC/DC Power Adapter User Manual

HKY HKY

HKY 24V AC/DC Power Adapter User Manual

Model: HKY

INTRODUCTION

This user manual provides essential information for the safe and effective use of your HKY 24V AC/DC Power Adapter. Please read this manual thoroughly before using the product and retain it for future reference.

The HKY 24V AC/DC Power Adapter is designed to provide a stable and reliable power supply for various Casio musical instruments, including specific models of Privia, Celviano, MZ-X, and CGP series pianos and keyboards. It features robust construction and multiple safety protections to ensure optimal performance and device longevity.

SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the product and connected devices:

- Ensure the power adapter's voltage and current specifications match the requirements of your device.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not disassemble or modify the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

Continuous and Stable Power Supply

Durable, multiple quality and safety verifications



Pure copper core



High level of safety certification marks

Wire Length
**1.2M/
47inch**



Image: The HKY power adapter features a UL certified plug, ensuring high safety standards for electrical connections.

SPECIFICATIONS

Feature	Detail
Input Voltage	100-240V AC, 50-60Hz
Output Voltage	24V DC
Output Current	2.73A
Output Power	65W
Connector Type	Barrel Connector (as pictured)
Cable Length	Approximately 10 feet (3 meters) total length
Safety Certifications	UL, CE, FCC, RoHS compliant
Protection Features	Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)



Image: The HKY 24V AC/DC Power Adapter, showing the main unit, AC power cord, and DC output cable with barrel connector.

COMPATIBLE MODELS

This power adapter is compatible with a wide range of Casio musical instruments. Please verify your device's power requirements before connecting.

- Casio Model: AD-E24250LW, PSAA60W-240, AD-A24250LW
- Casio MZ-X Series: MZ-X500, MZ-X300

- Casio CGP Series: CGP-700, CGP-700BK
- Casio AP Series: AP-450, AP-450BK, AP-450BN, AP-460, AP-460BN, AP-460BK, AP-460WE, AP-420, AP-420BK, AP-470
- Casio Privia PX Series: PX-860, PX-860WE, PX-860BK, PX-860BN, PX-780, PX-780BK, PX-780m, PX-830, PX-830BK, PX-830BP, PX-A800, PX-A800BN, PX-870, PX-870BK, PX-870BN, PX-870WE, PX-850, PX-850BN, PX-850BK, PX-850WE, PX-758M, PX-758MBK
- Casio CT-X Series: CT-X5000

SETUP AND CONNECTION

1. **Unpack:** Carefully remove the HKY power adapter from its packaging.
2. **Inspect:** Check the adapter and cables for any visible damage. Do not use if damaged.
3. **Connect to Device:** Locate the DC input jack on your Casio piano or keyboard. Insert the barrel connector of the HKY power adapter firmly into this jack. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the AC power cord of the adapter into a standard 100-240V wall outlet.
5. **Power On:** Once connected, you can power on your musical instrument.

Compact Size & Extra Long Cable

(Total Length : 10FT)



Image: The HKY power adapter connected to a Casio keyboard, demonstrating its compact size and the extra-long 10-foot cable for flexible placement.



Image: A user playing a Casio keyboard, illustrating the practical application of the HKY power adapter in a home setting.

OPERATING INSTRUCTIONS

The HKY power adapter operates automatically once connected. It provides a continuous and stable power supply to your compatible Casio device.

- **Stable Power:** The adapter is designed for continuous operation, providing consistent 24V DC power.
- **Safety Features:** Built-in Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) safeguard both the adapter and your connected device from electrical irregularities.
- **Energy Efficiency:** The adapter is designed to be energy-efficient, complying with modern standards.




Image: An illustration of the high-quality internal components of the HKY power adapter, highlighting features like overcharging prevention and intelligent current matching for stable power delivery.

MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your HKY power adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the cable. Do not place heavy objects on the cable. The adapter features reinforced stress points and flexible insulation to withstand wear and tear.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires or cracked casing.

Advanced Component



Pure copper cable

Antioxidant and corrosion
Energy-saving transmission
Long service life

Magic Tape Strap

Easily bundle Power cord
Easily carry for travel and work



Anti-interference Magnetic Ring

International standards
Compatibility materials
Safe and durable

Benging test

Wire through the bending
test, longer service life




Image: A diagram illustrating advanced components of the HKY power adapter, including pure copper cable for durability, a magic tape strap for cable management, and an anti-interference magnetic ring.




Image: An illustration demonstrating the flexible insulation and bending test results, indicating the cable's durability and resistance to damage from repeated bending.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly connected. Power outlet issue. Incompatible device. Adapter or device malfunction.	Ensure all connections are secure. Test the outlet with another device. Verify your device model is listed as compatible. Contact customer support if issues persist.

Problem	Possible Cause	Solution
Adapter feels hot.	Normal operation (slight warmth). Overload or poor ventilation.	Ensure adequate ventilation around the adapter. If it's excessively hot or emitting smoke/smell, unplug immediately and contact support.
Intermittent power.	Loose connection. Damaged cable.	Check all connections. Inspect the cable for damage. If damaged, discontinue use and replace.

If you encounter problems not listed here or if the suggested solutions do not resolve the issue, please contact HKY customer support.

WARRANTY AND SUPPORT

HKY is committed to providing high-quality products and excellent customer service.


- **Warranty:** This product comes with a **3-year warranty** and a **90-day money-back guarantee**.
- **Customer Support:** For any quality problems, suggestions, or technical assistance, please contact our customer service team. We offer **24/7 email support** and aim to reply within 24 hours.

About our Customer Service



Safe & Reliable

Made with high quality materials



Reinforced Stress Points

Withstand more wear and tear



Image: An overview of HKY's customer service commitment, including a 30-day money-back guarantee, 3-year warranty, and 24/7 service, alongside a diagram of the cable's internal construction for reliability.

© 2025 HKY. All rights reserved.

For more information, visit [the HKY Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CB389R9P>

More documents and user manuals: <https://manuals.plus/>