

[manuals.plus](#) /

› [EcoTypee](#) /

› [EcoTypee 6-Grid Rotating Rice Dispenser User Manual](#)

EcoTypee Grain Storage Container Dispenser

EcoTypee 6-Grid Rotating Rice Dispenser User Manual

Model: Grain Storage Container Dispenser

Brand: EcoTypee

1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your EcoTypee 6-Grid Rotating Rice Dispenser. Designed for efficient storage and dispensing of various dry foods, this appliance helps keep your kitchen organized and your food fresh.

Key Features:

- 6-Grid Design:** Separate compartments for organized storage of different dry foods.
- 360° Rotation:** Allows easy access to any compartment with a simple turn.
- Press-Type Dispensing:** One-button operation for controlled and mess-free food retrieval.
- Food-Grade Materials:** Constructed from durable, BPA-free PP and PET for safe food storage.
- Airtight Seal:** Lid design and material help protect contents from moisture and dust.
- Transparent Body:** Clear compartments for easy monitoring of food levels.
- Space-Saving:** Compact design suitable for various kitchen layouts.

2. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your EcoTypee Rotating Rice Dispenser:

- Main Body:** The base and rotating structure.
- Storage Compartments:** Six individual sections for different dry foods.
- Lid:** Removable top cover for refilling and sealing.
- Dispensing Buttons:** Located under each compartment for controlled release.
- Rice Hopper (Drawer):** Collects dispensed food.
- Insect Repellent Box:** Central compartment for optional insect repellent.



Figure 2.1: The EcoTypee 6-Grid Rotating Rice Dispenser, showcasing its transparent compartments filled with different dry foods, ready for use in a kitchen setting.



Figure 2.2: An exploded view highlighting key components such as the removable lid, individual storage compartments, the funnel spout, and the drawer-type rice hopper.

3. SETUP INSTRUCTIONS

- 1. Unpack the Dispenser:** Carefully remove all packaging materials and inspect the dispenser for any damage.
- 2. Initial Cleaning:** Before first use, hand wash all removable parts (lid, rice hopper) with mild soap and water. Wipe the main body with a damp cloth. Ensure all parts are completely dry before assembly. *Note: This product is not dishwasher safe.*
- 3. Place the Dispenser:** Position the dispenser on a stable, flat surface in your kitchen. Ensure there is enough space around it for rotation and access to the dispensing drawer.
- 4. Fill Compartments:** Open the lid by lifting the recessed handle. Pour your desired dry foods (rice, beans, grains, etc.) into each of the six separate compartments. Avoid overfilling.
- 5. Insert Insect Repellent (Optional):** If desired, place a suitable insect repellent (e.g., bay leaves, cloves) into

the central insect repellent box.

6. **Secure the Lid:** Place the lid back onto the dispenser, ensuring it is properly seated to maintain an airtight seal.

4. OPERATING INSTRUCTIONS

4.1 Selecting Dry Food

1. **Rotate the Dispenser:** Gently rotate the main body of the dispenser until the desired compartment is aligned with the dispensing button and rice hopper.



Figure 4.1: This image illustrates the 360-degree rotating design of the dispenser, allowing easy access to any of the six compartments.

4.2 Dispensing Dry Food

1. **Position Rice Hopper:** Ensure the drawer-type rice hopper is fully inserted beneath the dispensing button.
2. **Press Dispensing Button:** Press the button located directly below the selected compartment. Dry food will

flow out into the rice hopper.

3. **Control Portion:** Release the button to stop the flow. Repeat pressing if more food is needed.
4. **Remove Hopper:** Once the desired amount is dispensed, pull out the rice hopper to retrieve the food.



Figure 4.2: The press-type button mechanism for dispensing dry food from a selected compartment, highlighting the ease of use.

5. MAINTENANCE

5.1 Cleaning

- **Regular Cleaning:** Periodically empty the dispenser and clean all parts.
- **Hand Wash Only:** Wash the lid and rice hopper with warm, soapy water. Rinse thoroughly and dry completely.
- **Wipe Main Body:** Use a damp cloth to wipe the exterior and interior of the main body. Do not submerge the main body in water.
- **Avoid Abrasives:** Do not use abrasive cleaners or scrubbers, as they may scratch the surface.
- **Drying:** Ensure all components are completely dry before reassembling and refilling to prevent moisture buildup.

5.2 Refilling

- When a compartment is low, lift the lid and carefully pour in more dry food.
- Ensure the lid is securely replaced after refilling to maintain freshness.

6. TROUBLESHOOTING

- **Food Not Dispensing:**

- Ensure the correct compartment is aligned with the dispensing button.
- Check if the food is clumped or stuck. Gently shake the dispenser or use a clean, dry utensil to dislodge.
- Verify that the dispensing mechanism is clear of any obstructions.

- **Lid Not Sealing Properly:**

- Ensure the lid is correctly aligned with the main body and pressed down firmly.
- Check for any food particles or debris on the rim of the dispenser or lid that might prevent a proper seal.

- **Dispenser Not Rotating Smoothly:**

- Ensure the dispenser is on a flat, stable surface.
- Check for any debris or food particles caught in the rotating mechanism.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.35" L x 10.35" W x 10.63" H (26.3cm x 26.3cm x 27cm)
Capacity	Approx. 17.64 lbs (8 kg) total dry food
Material	Food-Grade Polypropylene (PP), Polyethylene Terephthalate (PET)
Color	White
Number of Compartments	6
Special Features	360° Rotation, Good Sealing, Press-Type Dispensing
Care Instructions	Hand Wash Only



Figure 7.1: This image provides the product dimensions, indicating its compact size suitable for various kitchen spaces.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your EcoTypee 6-Grid Rotating Rice Dispenser, please contact the manufacturer or your point of purchase. Please refer to your purchase documentation for specific warranty details.

© 2023 EcoTypee. All rights reserved.

Related Documents - Grain Storage Container Dispenser

	<p><u>KoMo Grain Mills and Flakers User Manual</u></p> <p>Comprehensive user manual for KoMo grain mills and flakers, detailing operation, safety, maintenance, technical specifications, recipes, and innovative technology. Learn how to use your KoMo mill for fresh, healthy grains and flakes.</p>
	<p><u>How to Cook Perfect Fluffy Rice with Ninja Speedi and Ninja Combi</u></p> <p>A comprehensive guide to cooking fluffy, perfect rice using the Ninja Speedi and Ninja Combi appliances. Learn essential rinsing techniques, precise ingredient ratios, and specific cooking times for delicious results.</p>
	<p><u>GreenPan Carb-Reducing Rice Cooker User Guide</u></p> <p>Comprehensive user guide for the GreenPan Carb-Reducing Rice Cooker, detailing important safeguards, operation instructions for various rice and grain types, low carb modes, bean cooking, troubleshooting, and warranty information.</p>
	<p><u>TIAKI Vacuum Seal Pet Feed Container User Manual & Operating Guide</u></p> <p>User manual for the TIAKI Vacuum Seal Pet Feed Container. Learn how to operate the device for air extraction and introduction, understand LED indicators, and ensure optimal pet food freshness.</p>
	<p><u>KitchenAid Grain and Rice Cooker Quick Start Guide and Product Overview</u></p> <p>This guide provides essential information for the KitchenAid Grain and Rice Cooker, including a product overview, feature modes, quick start instructions, and cook times and capacities for various grains and beans.</p>
	<p><u>TADAR Glass Spice Containers: Safety and Usage Instructions</u></p> <p>Official safety and usage instructions for TADAR glass spice containers. Learn how to properly store, use, and care for your spice dispensers to ensure safety and longevity.</p>

