

ELS PET DGYSJ

ELS PET 270oz/8L Dog Water Fountain Instruction Manual

PRODUCT OVERVIEW

The ELS PET 270oz/8L Dog Water Fountain is designed to provide a continuous supply of fresh, filtered water for pets. Its large capacity is suitable for small to large-sized dogs, cats, and multi-pet households, reducing the frequency of refills. The fountain features a unique wireless pump for easy cleaning, an automatic power-off sensor for low water levels, and a triple filtration system to ensure water quality. The unit operates quietly and is constructed from durable, healthy materials.



Image: The ELS PET 8L Dog Water Fountain in use, showing its suitability for multiple pets including dogs and cats.

KEY FEATURES

- **8L Large Capacity:** Provides 270oz (2.13 gallons) of water, ideal for small to large dogs, cats, and multi-pet families, reducing the need for frequent refills.
- **Unique Wireless Pump:** Facilitates easy cleaning of all components without tangled wires in the water. Features an automatic power-off function at low water levels to protect the pump.

- **Ultra-Quiet Operation:** Equipped with a pump that operates below 15dB, ensuring a peaceful environment for pets and owners.
- **LED Indicator Light:** A blue light indicates sufficient water levels, while a red light signals the need for a refill.
- **Triple Filtration System:** Includes a nano ultrafiltration membrane with 0.01 micrometer accuracy, foam cotton, and a filter screen to remove suspended solids, colloids, and impurities, keeping water fresh.
- **Easy to Clean & Install:** Detachable water tank design and wireless pump simplify assembly, disassembly, and cleaning.
- **Healthy Materials:** Made from 304 food-grade stainless steel and BPA-free materials for pet safety.

PACKAGE CONTENTS

Please ensure all components are present before assembly:

- Main Water Reservoir (Base Unit)
- Stainless Steel Drinking Tray
- Wireless Water Pump
- Filter Assembly (includes foam cotton, filter screen, nano ultrafiltration membrane)
- Power Adapter
- Instruction Manual

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Clean Components:** Wash the stainless steel drinking tray, water reservoir, and filter components (excluding the wireless pump) with mild soap and water. Rinse thoroughly.
3. **Assemble Filter:** Insert the foam cotton, filter screen, and nano ultrafiltration membrane into the filter housing. Ensure they are correctly seated.
4. **Place Wireless Pump:** Position the wireless water pump securely at the designated spot inside the main water reservoir. No wires should be immersed in water.
5. **Install Filter Assembly:** Place the assembled filter unit over the wireless pump.
6. **Add Water:** Fill the water reservoir with clean water up to the maximum fill line. Observe the water level indicator.
7. **Place Drinking Tray:** Carefully place the stainless steel drinking tray on top of the reservoir, ensuring it is stable.
8. **Connect Power:** Plug the power adapter into a wall outlet. The fountain should begin operating, and the LED indicator will light up.

ELS PET

8L/ Dog Water Fountain

272oz Large Capacity for Large Dogs & Multiple Pet Families



Image: Illustration of the wireless pump design and the water level indicator on the fountain base.

Your browser does not support the video tag. This video demonstrates the large capacity and quiet operation of the ELS PET water fountain, along with its spill-proof design. It also shows the fountain in operation.

Video: Demonstration of the ELS PET water fountain's features, including its large capacity, quiet operation, and spill-proof design.

OPERATING INSTRUCTIONS

Once assembled and plugged in, the ELS PET water fountain will automatically begin circulating water. The LED indicator provides visual feedback on the water level.

- **Normal Operation:** When the water level is sufficient, the LED indicator will display a blue light, indicating proper function.
- **Low Water Alert:** If the water level drops below the minimum sensing point, the LED indicator will turn red. The pump will automatically power off to prevent damage and alert you to refill the reservoir.
- **Refilling:** To refill, unplug the unit, remove the drinking tray, and add clean water to the reservoir. Reassemble and plug in to resume operation.



Image: The ELS PET water fountain illustrating the blue light for normal water levels and the red light for low water, indicating the automatic power-off feature.

MAINTENANCE

Regular cleaning and filter replacement are crucial for maintaining water quality and extending the life of

your fountain.

Cleaning the Fountain

1. **Disassembly:** Unplug the fountain. Remove the stainless steel drinking tray, filter assembly, and wireless pump.
2. **Wash Components:** Wash the drinking tray and water reservoir with mild soap and water. The stainless steel tray is machine washable.
3. **Clean Wireless Pump:** The wireless pump can be easily detached and cleaned. Disassemble the pump by separating the housing, removing the plastic cover, and carefully pulling out the magnetic impeller. Clean all parts with a brush and rinse thoroughly. Some users recommend soaking in bleach water for 10 minutes, followed by a thorough rinse.
4. **Rinse and Dry:** Rinse all components thoroughly to remove any soap residue. Ensure parts are dry before reassembly.

Filter Replacement

- The triple filtration system includes foam cotton, a filter screen, and a nano ultrafiltration membrane. These components should be replaced regularly to ensure optimal water purification.
- Frequency of replacement depends on water quality and pet usage, typically every 2-4 weeks.
- To replace, remove the old filter components and insert new ones into the filter housing.



Image: Exploded view of the triple filtration system, showing the foam cotton, filter screen, and PAN material fiber (nano ultrafiltration membrane).



Image: The stainless steel drinking tray detached from the fountain, highlighting its ease of cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not operating / No water flow	Power adapter not plugged in. Low water level (red LED). Wireless pump or filter clogged. Wireless pump not correctly seated.	Ensure power adapter is securely plugged into both the fountain and the wall outlet. Refill water to the appropriate level. Disassemble and thoroughly clean the wireless pump and filter components. Replace filter if necessary. Ensure the wireless pump is properly positioned in the reservoir.
Excessive noise during operation	Low water level. Wireless pump or filter clogged. Impeller in pump is dirty or obstructed.	Add water to the reservoir. Clean the wireless pump and filter. Disassemble the pump and clean the impeller and its housing.
Water appears dirty or has an odor	Filter needs replacement. Fountain components require cleaning.	Replace all filter components. Thoroughly clean the entire fountain, including the reservoir, tray, and pump.

SPECIFICATIONS

Feature	Detail
Brand	ELS PET
Model Name	DG-YSJ
Item Model Number	DGYSJ
Capacity	8 Liters (270oz / 2.13 Gallons)
Material	304 Food-Grade Stainless Steel, BPA-Free Plastic
Item Weight	5.6 pounds
Product Dimensions (LxWxH)	13 x 13 x 6.5 inches
Voltage	230 Volts (AC)
Noise Level	Below 15dB (Sleep Mode)
Target Audience	Dogs, Cats, Multi-Pet Families
Specific Uses	Indoor

WARRANTY AND SUPPORT

The ELS PET 270oz/8L Dog Water Fountain comes with a **30-day warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For technical support, warranty claims, or inquiries regarding replacement parts (such as filters), please contact ELS PET customer service through the retailer where the product was purchased or visit the official ELS PET store online.

Online Store: [ELS PET Store on Amazon](#)