

Furniwell LC0181

Furniwell LC0181 Armless Office Chair User Manual

Model: LC0181
Brand: Furniwell

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Furniwell LC0181 Armless Office Chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

SAFETY INFORMATION

- This chair has a maximum weight capacity of **250 pounds**.
- It is recommended for office use only.
- Exercise caution during assembly to prevent injury.
- Ensure all screws and bolts are tightened securely before use.
- Do not stand on the chair.
- Keep small parts away from children during assembly.

For any concerns, contact Furniwell customer support.

PRODUCT OVERVIEW AND COMPONENTS

The Furniwell LC0181 is an armless office chair designed for comfort and space efficiency. Key

features include a padded seat, 360-degree swivel, and adjustable height.

Key Features:

- **Comfortable Padded Seat:** High-density sponge cushion and ergonomic backrest for extended sitting.
- **Armless Design:** Allows for easy storage under desks and saves space.
- **360° Swivel:** Provides flexibility and convenience in your workspace.
- **Height Adjustable:** Gas lift mechanism for adjusting seat height from 17.72 to 21.26 inches.
- **Silent Casters:** Smooth-rolling wheels designed for hard floors.

Components (Typical):

1. Seat Cushion
2. Backrest
3. Gas Lift Cylinder
4. Base (Star Base with Wheels)
5. Casters (Wheels)
6. Mechanism Plate (under seat)
7. Screws and Allen Wrench (for assembly)



Image: The Furniwell LC0181 armless office chair in pink, showcasing its overall design.

Ergonomic Armless Design

Better save space



Image: A diagram highlighting the ergonomic armless design, which allows the chair to be easily tucked under a desk, saving space.

SETUP AND ASSEMBLY INSTRUCTIONS

Please ensure all parts are present before beginning assembly. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

Required Tools:

- Allen Wrench (usually included)

Assembly Steps:

1. **Attach Casters to Base:** Insert each caster into the holes at the end of the star base until it clicks securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Secure it with the provided screws using the Allen wrench. Ensure the lever is facing the front of the seat.

4. **Attach Backrest to Seat:** Align the backrest support with the corresponding holes on the seat mechanism. Secure with screws.
5. **Connect Seat to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the tapered end of the gas lift fits securely into the mechanism plate.

Important:

After assembly, sit on the chair to ensure the gas lift cylinder is properly seated in the mechanism. Verify all screws are tight before regular use.



Image: A diagram illustrating the product dimensions (height, seat depth, seat width) and the maximum weight capacity of 250 lbs.

OPERATING INSTRUCTIONS

Adjusting Seat Height:

To adjust the seat height, locate the lever on the right side, underneath the seat.

- **To raise the seat:** While standing, pull the lever upwards. The seat will rise automatically. Release the lever at the desired height.

- **To lower the seat:** While seated, pull the lever upwards. The seat will lower. Release the lever at the desired height.

Swivel Function:

The chair seat is designed to rotate 360 degrees. Simply rotate the seat to adjust your working angle or position.



Image: A close-up illustrating the adjustable height lever, 360-degree smooth swivel function, and silent casters of the chair.

MAINTENANCE

- **Cleaning Fabric:** The product care instructions specify "Dry Clean". For minor spills, gently blot with a clean, dry cloth. For deeper cleaning, consult a professional dry cleaner.
- **Casters:** Periodically check casters for hair or debris that may hinder smooth rolling. Clean as needed.
- **Hardware:** Regularly check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability and safety.
- **Gas Lift:** If the gas lift mechanism becomes stiff or fails to hold height, it may need replacement.

Contact customer support for assistance.

Caution:

Avoid using harsh chemicals or abrasive cleaners on any part of the chair, as this may damage the finish or fabric.

TROUBLESHOOTING

Chair does not adjust height:

- Ensure the gas lift lever is fully engaged.
- Check if the gas lift cylinder is properly inserted into the mechanism and base.
- If the issue persists, the gas lift may be faulty and require replacement.

Chair is wobbly:

- Verify all assembly screws are securely tightened.
- Ensure the base and casters are correctly assembled.

Casters do not roll smoothly:

- Check for debris (e.g., hair, lint) wrapped around the caster wheels. Clean as necessary.
- Ensure the casters are fully inserted into the base.

For issues not listed here, please contact Furniwell customer support.

SPECIFICATIONS

Feature	Detail
Brand	Furniwell
Model Name	LC0181
Color	Pink
Product Dimensions	18.15"D x 17.72"W x 34.26"H
Adjustable Height Range	17.72 - 21.26 inches
Maximum Weight Recommendation	250 Pounds
Back Style	Solid Back
Arm Style	Armless
Furniture Base Movement	Swivel

Fill Material	Sponge
Product Care Instructions	Dry Clean
Recommended Uses	Office

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact Furniwell directly through their official website or the retailer where the product was purchased.

You can visit the Furniwell Store for more information: [Furniwell Official Store](#)