

AKO AKO-15692

AKO AKO-15692 Three-Phase PROPlus Basic Electronic Control Panel with Defrost 10200W User Manual

Model: AKO-15692 | Brand: AKO

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of the AKO AKO-15692 Three-Phase PROPlus Basic Electronic Control Panel with Defrost 10200W. Please read this manual thoroughly before installation and operation.



Figure 1: Front view of the AKO AKO-15692 control panel. This image displays the front of the AKO AKO-15692 control panel. On the left, a digital display shows '-19.4' with 'ECO' and defrost indicators. Below the display are navigation buttons (up, down, set, escape, power, question mark, light). The right side features a transparent hinged cover, revealing internal circuit breakers and a rotary switch.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent injury and damage to the device:

- Installation and maintenance must be performed by qualified personnel only.
- Disconnect power before performing any work on the control panel.
- Ensure proper grounding to prevent electrical shock.
- Do not expose the unit to moisture or extreme temperatures outside its operating range.
- Verify all connections are secure and correct before applying power.

3. PRODUCT OVERVIEW

The AKO-15692 is a three-phase electronic control panel designed for refrigeration systems requiring defrost management. It integrates control, protection, and monitoring functions for optimal performance and energy efficiency.

Key Features:

- Three-phase power compatibility (up to 10200W).
- Integrated defrost control.
- Digital display for temperature and status.

- User-friendly control interface.
- Robust enclosure for industrial environments.

4. SETUP AND INSTALLATION

4.1 Unpacking

Carefully unpack the control panel and inspect it for any signs of damage. Retain the packaging materials for future transport or storage.

4.2 Mounting

The unit is designed for screw-mounted installation. Choose a dry, well-ventilated location away from direct heat sources or excessive vibration. Ensure sufficient space for wiring and ventilation.

1. Mark the mounting points on the wall using the panel's dimensions.
2. Drill appropriate holes and insert wall plugs if necessary.
3. Secure the control panel to the wall using suitable screws.

4.3 Electrical Connections

All electrical connections must comply with local and national electrical codes. Refer to the wiring diagram provided inside the panel cover for specific connections.

- **Power Supply:** Connect the three-phase power supply to the designated terminals.
- **Compressor:** Connect the compressor load to the appropriate output terminals.
- **Defrost Heaters:** Connect defrost heaters to their dedicated output terminals.
- **Sensors:** Connect temperature sensors to the specified input terminals.
- **Grounding:** Ensure all grounding connections are properly made.

Warning: Incorrect wiring can lead to severe damage or electrical shock. Consult a qualified electrician if unsure.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

Press the (Power) button to turn the unit on or off. The digital display will illuminate upon power-on.

5.2 Display and Navigation

The digital display shows the current temperature or system status. Use the following buttons for navigation and settings:

- **SET:** Enter/confirm settings.
- **▲ (Up):** Increase values or navigate up.
- **▼ (Down):** Decrease values or navigate down.
- **ESC:** Exit menu or cancel operation.
- **?:** Access help or information.
- *** (Light):** Control internal light (if applicable) or display brightness.

5.3 Setting Temperature

1. Press the **SET** button. The current setpoint will flash.
2. Use the **▲** or **▼** buttons to adjust the desired temperature.
3. Press **SET** again to confirm the new setpoint.

5.4 Defrost Cycle

The unit features automatic defrost control. Parameters such as defrost interval and duration can be configured through the settings menu. Consult the detailed programming section in the full manual for advanced configurations.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of the control panel.

6.1 Cleaning

- Disconnect power before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no moisture enters the internal components.

6.2 Inspections

Periodically inspect the following:

- **Wiring:** Check for loose or damaged wires.
- **Terminals:** Ensure all terminal connections are tight.
- **Enclosure:** Look for any signs of physical damage or corrosion.
- **Ventilation:** Ensure ventilation openings are clear and unobstructed.

7. TROUBLESHOOTING

This section addresses common issues. For more complex problems, contact technical support.

Problem	Possible Cause	Solution
Panel does not power on.	No power supply; Blown fuse/tripped breaker.	Check main power supply; Inspect fuses/breakers and reset if necessary.
Incorrect temperature reading.	Faulty sensor; Sensor incorrectly placed.	Check sensor connections; Verify sensor placement; Replace sensor if faulty.
Defrost not initiating.	Incorrect defrost settings; Defrost heater fault.	Review defrost parameters in settings; Check defrost heater and wiring.

8. SPECIFICATIONS

Feature	Detail
Model	AKO-15692
Brand	AKO
Power Rating	10200W

Feature	Detail
Phase	Three-phase
Installation Type	Screw-mounted
Defrost Function	Integrated

9. WARRANTY AND SUPPORT

9.1 Warranty Information

AKO products are covered by a standard manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official AKO website for detailed terms and conditions.



9.2 Technical Support


For technical assistance, spare parts, or service inquiries, please contact AKO customer support. Have your model number (AKO-15692) and purchase date ready when contacting support.
Contact information (e.g., phone, email, website) can typically be found on the product packaging or the official AKO website.

© 2023 AKO. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - AKO-15692

	AKO Gas Leak Detection Alarm User Manual: Models AKO-55624 & AKO-55724 Comprehensive user manual for AKO Gas Leak Detection Alarm systems, covering models AKO-55624 and AKO-55724. Includes equipment description, installation, configuration, operation, technical specifications, and accessories.
	AKO PROPlus 3PH Electronic Panel Quick Guide This document provides a quick guide for the AKO PROPlus 3PH Electronic Panel, covering installation, operation, maintenance, and technical specifications. It details various models, parameters, and functions for optimal use of the electronic panel in refrigeration and climate control systems.

	AKO PROPlus 3PH BASIC Electronic Panel User Manual Comprehensive user manual for the AKO PROPlus 3PH BASIC Electronic Panel, detailing installation, configuration, operation, maintenance, and technical specifications for cold room management. Includes troubleshooting and parameter settings.
	AKO PROCool Electronic Panel User Guide and Configuration Comprehensive guide to the AKO PROCool Electronic Panel, covering quick and advanced configuration, maintenance, troubleshooting, and technical specifications for models AKO-17632 through AKO-17521.
	Manual de Usuario Transmisor de Gas V3 AKO-575xxx Manual de usuario detallado para el Transmisor de Gas V3 AKO-575xxx de AKO Electromecánica. Cubre instalación, funcionamiento, configuración, mantenimiento, especificaciones técnicas y accesorios.
	AKO PROCool Electronic Control Panel Quick Start Guide Quick start guide for AKO PROCool electronic control panels, covering installation, configuration, technical specifications, and maintenance for models AKO-17632 through AKO-17521.



[\[pdf\]](#) Documentation

351569057 cdr Daniel Gutierrez Manuals and documentation · Ako 6 help ako assets |||
tr ru 1569H057 Ed.07 AKO-1569x AKO-1569x-EVC Elektronik panel PROPlus 3PH BASIC PROPlus 3PH BAS ... sr birimi Kondansr fanlari Evaporatr fanlari Rezistans defrost lik G beslemesi AKO-15690 AKO-15691 **AKO-15692** 2,5 - 4 A 4 - 6,3 A 3 A 6,3 - 10 A I N 7.000 W 4 A I N AKO-15693 AKO-15697 10 ...
lang:id **score:32** filesize: 4.44 M page_count: 28 document date: 2025-05-28




[\[pdf\]](#) Documentation

351569048 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets |||
RU 1569H048 Ed.03 AKO-1569x AKO-1569x-EVC PROPlus 3PH BASIC 1569H048 Ed.03 1.- 2 AUX 3 , . . 25 . Y . . 26 . Y . 2.- AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...
lang:i-klngon **score:32** filesize: 8.08 M page_count: 28 document date: 2020-12-02



[\[pdf\]](#)

351569057 cdr Daniel Gutierrez Manuales y documentación · Ako 5 help ako assets |||
tr ru 1569H057 Ed.06 AKO-1569x AKO-1569x-EVC Elektronik panel PROPlus 3PH BASIC PROPlus 3PH BAS ... sr birimi Kondansr fanlari Evaporatr fanlari Rezistans defrost lik G beslemesi AKO-15690 AKO-15691 **AKO-15692** 2,5 - 4 A 4 - 6,3 A 3 A 6,3 - 10 A I N 7.000 W 4 A I N AKO-15693 AKO-15697 10 ...
lang:id **score:32** filesize: 4.31 M page_count: 28 document date: 2022-12-20



[\[pdf\]](#) Documentation

351569071 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets |||

255 mm GND B A GND I2 I1 GND S3 GND S2 GND S1 PE 6 mm 6 mm 355 mm 255
16 16 355 1 6 mm 2 90 ... L 1F 2 N N N 4 N N A1 A2 A3 NO C NC 2 4 6 10 12 14 16
18 20 AKO-15690 AKO-15691 **AKO-15692** AKO-15693 RESISTENCIA
DESESCARCHE ELECTRIC DEFROST RESISTANCE DGIVRAGE
ABTAUHEIZUNG REZ...

lang:fr **score:32** filesize: 5.73 M page_count: 1 document date: 2020-12-04




[\[pdf\]](#) Documentation Guide

351569051 cdr Daniel Gutierrez Manuals and documentation · Ako 3 help ako assets |||

E GB F 1569H051 Ed.04 AKO-1569x AKO-1569x-EVC Cuadro electrónico PROPlus
3PH BASIC PROPlus 3PH BASI ... s condensador Ventiladores evaporador
Resistencias desescarche Luz Alimentacin AKO-15690 AKO-15691 **AKO-15692**
AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-
EVC **AKO-15692-EVC** AKO-15...

lang:es **score:31** filesize: 8.99 M page_count: 44 document date: 2020-12-02



[\[pdf\]](#) Documentation Guide

351569051 cdr Daniel Gutierrez Manuals and documentation · Ako 5 help ako assets |||

es en fr 1569H051 Ed.06 AKO-1569x AKO-1569x-EVC Cuadro electrónico PROPlus
3PH BASIC PROPlus 3PH BA ... s condensador Ventiladores evaporador
Resistencias desescarche Luz Alimentacin AKO-15690 AKO-15691 **AKO-15692**
AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-
EVC **AKO-15692-EVC** AKO-15...

lang:es **score:31** filesize: 5.72 M page_count: 44 document date: 2025-05-28




[pdf] Installation Guide Documentation

351567901 cdr Daniel Gutierrez Manuals and documentation · Ako help ako assets |||

E GB TR RU 1567H901 Ed.01 AKO-15679 Antes de realizar cualquier manipulacin en el interior del cua ... yapabilir. - . . Compatibilidad / Compatibility / uygunluk / : AKO-15690,AKO-15691,**AKO-15692**,AKO-15693 E Extraer los conectores centrales. GB Remove the central connectors. TR Orta ko...

lang:es score:31 filesize: 4.35 M page_count: 4 document date: 2016-06-08



[pdf] User Manual Documentation

351569054 cdr Daniel Gutierrez Manuals and documentation · Ako 3 help ako assets |||

DP 1569H054 Ed.04 AKO-1569x AKO-1569x-EVC Elektronische Schaltanlage PROPlus 3PH BASIC Quadro elet ... ondensator Ventilatoren Verdampfer Widerstnde Abtaung Licht Strom- versorgung AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:de score:31 filesize: 7.02 M page_count: 28 document date: 2020-12-02



[pdf] User Manual Documentation

351569054 cdr Daniel Gutierrez Manuals and documentation · Ako 5 help ako assets |||

de pt 1569H054 Ed.06 AKO-1569x AKO-1569x-EVC Elektronische Schaltanlage PROPlus 3PH BASIC Quadro e ... ondensator Ventilatoren Verdampfer Widerstnde Abtaung Licht Strom- versorgung AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...


lang:de score:31 filesize: 4.33 M page_count: 28 document date: 2025-05-28



[pdf] Guide

351569051 cdr Daniel Gutierrez Manuales y documentación · Ako 4 help ako assets |||
 es en fr 1569H051 Ed.05 AKO-1569x AKO-1569x-EVC Cuadro electrónico PROPlus 3PH BASIC PROPlus 3PH BA ... s condensador Ventiladores evaporador Resistencias desescarche Luz Alimentacin AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:es score:31 filesize: 5.54 M page_count: 44 document date: 2022-12-20



[pdf] User Manual

351569054 cdr Daniel Gutierrez Manuales y documentación · Ako 4 help ako assets |||
 de pt 1569H054 Ed.05 AKO-1569x AKO-1569x-EVC Elektronische Schaltanlage PROPlus 3PH BASIC Quadro e ... ondensator Ventilatoren Verdampfer Widerstnde Abtaung Licht Strom- versorgung AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:de score:31 filesize: 4.25 M page_count: 28 document date: 2022-12-20



[pdf] Installation Guide

351567901 cdr Daniel Gutierrez Manuales y documentación · Ako 1 help ako assets |||
 es en tr ru 1567H901 Ed.02 AKO-15679 Antes de realizar cualquier manipulacin en el interior del cu ... yapabilir. - . . Compatibilidad / Compatibility / uygunluk / : AKO-15690, AKO-15691, **AKO-15692**, AKO-15693 es Extraer los conectores centrales. en Remove the central connectors. tr Orta k...

lang:es score:30 filesize: 1.99 M page_count: 4 document date: 2022-12-20



[AKO PROPlus 3PH BASIC Electronic Panel User Manual](#)

Comprehensive user manual for the AKO PROPlus 3PH BASIC Electronic Panel, detailing installation, configuration, operation, maintenance, and technical specifications for cold room management. Includes troubleshooting and parameter settings.

lang:en score:29 filesize: 9.04 M page_count: 28 document date: 2022-12-20



[\[pdf\] Documentation](#)

351569047 cdr Daniel Gutierrez Manuals and documentation · Ako 3 help ako assets |||

TR AKO-1569x AKO-1569x-EVC Elektronik panel PROPlus 3PH BASIC Kullanici kılavuzu 1569H047 Ed.04 1 ... sr birimi Kondansr fanlari Evaporatr fanlari Rezistans defrost lik G beslemesi AKO-15690 AKO-15691 **AKO-15692** 2,5 - 4 A 4 - 6,3 A 3 A 6,3 - 10 A I N 7.000 W 4 A I N AKO-15693 AKO-15697 10 ...

lang:id score:29 filesize: 8.12 M page_count: 28 document date: 2020-12-02



[\[pdf\] Documentation](#)

351569044 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets |||

D 1569H044 Ed.03 AKO-1569x AKO-1569x-EVC Elektronische Schaltanlage PROPlus 3PH BASIC Benutzerhand ... ondensator Ventilatoren Verdampfer Widerstnde Abtauung Licht Strom- versorgung AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:de score:28 filesize: 8.13 M page_count: 28 document date: 2020-12-02



[\[pdf\]](#) User Manual Documentation

351569041 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets |||

E 1569H041 Ed.03 AKO-1569x AKO-1569x-EVC Cuadro electrónico PROPlus 3PH BASIC Manual de usuario 1 ... s condensador Ventiladores evaporador Resistencias desescarche Luz Alimentación AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:es score:28 filesize: 8.16 M page_count: 28 document date: 2020-12-02



[\[pdf\]](#) User Manual Documentation

351569046 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets |||

P 1569H046 Ed.03 AKO-1569x AKO-1569x-EVC Quadro eletrônico PROPlus 3PH BASIC Manual de utilizador ... entiladores condensador Ventilador evaporador Resistências degelo Luz Alimentação AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:es score:28 filesize: 8.14 M page_count: 28 document date: 2020-12-02



[\[pdf\]](#) Documentation

351569043 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets |||

F 1569H043 Ed.03 AKO-1569x AKO-1569x-EVC Tableau électronique PROPlus 3PH BASIC Manuel d'utilisation ... condensation Ventilateur vaporisateur Résistances dégivrage éclairage Alimentation AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:fr score:28 filesize: 8.15 M page_count: 28 document date: 2020-12-02



[\[pdf\]](#) User Manual

351569046 cdr Daniel Gutierrez Manuales y documentación · Ako 3 help ako assets |||

pt 1569H046 Ed.04 AKO-1569x AKO-1569x-EVC Quadro eletrnico PROPlus 3PH BASIC Manual de utilizador ... entiladores condensador Ventilador evaporador Resistncias degelo Luz Alimentao AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:es **score:28** filesize: 9.07 M page_count: 28 document date: 2022-12-20



[\[pdf\]](#) User Manual

351569041 cdr Daniel Gutierrez Manuales y documentación · Ako 3 help ako assets |||

es 1569H041 Ed.04 AKO-1569x AKO-1569x-EVC Cuadro electrnico PROPlus 3PH BASIC Manual de usuario ... s condensador Ventiladores evaporador Resistencias desescarche Luz Alimentacin AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:es **score:28** filesize: 9.06 M page_count: 28 document date: 2022-12-20




[\[pdf\]](#)

351569043 cdr Daniel Gutierrez Manuales y documentación · Ako 3 help ako assets |||

fr 1569H043 Ed.04 AKO-1569x AKO-1569x-EVC Tableau lectronique PROPlus 3PH BASIC Manuel d utilisati ... condensation Ventilateur vaporateur Rsistances dgivrage clairage Alimentation AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:fr **score:28** filesize: 9.06 M page_count: 28 document date: 2022-12-20




[\[pdf\]](#) Documentation Catalog

Manuals and documentation · Ako catalog fra 2016 help ako assets |||

Catalogue Commercial 2016 CONTRÔLE ET RÉGULATION POUR LA RÉFRIGÉRATION INDUSTRIELLE ET COMMERCIALE NOT ... 2 AKO-15673 AKO-15680 AKO-15681 AKO-15682 AKO-15683 AKO-15690 AKO-15690-EVC AKO-15691 AKO-15691-EVC **AKO-15692 AKO-15692-EVC** AKO-15693 AKO-15693-EVC AKO-15697 AKO-15697-EVC AKO-15699 AKO-15699-1 AKO-15...

lang:fr **score:27** filesize: 10.92 M page_count: 78 document date: 2016-05-17



[\[pdf\]](#) Documentation

3515690E71 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets 355 mm 255 AKO

15690 EVC 15691 1 3 5 7 9 11 13 15 17 19 21 L1 L2 L3 14 A1 111 513 L4 ES GND CS L BC |||

355 mm 255 mm GND B A GND I2 I1 GND S3 GND S2 GND S1 PE 6 mm 6 mm GND Tr MODBUS RS-485 255 1 ... S2 Tr 1 3 5 7 9 11 L 11 14 BC L N B1 B2 A N 2 4 6 10 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15693-EVC RESISTENCIA DESESCARCHE ELECTRIC DEFROST RESISTANCE DGIVRAGE ABTAUHEIZU...

lang:tl **score:26** filesize: 5.74 M page_count: 1 document date: 2020-12-04




[\[pdf\]](#) Documentation Catalog

Manuals and documentation · Ako 351000202 2 help ako assets |||

COMMERCIAL CATALOGUE CONNECTED SOLUTIONS FOR PRODUCT CARE ENERGY EFFICIENCY www.ako.com MORE TH ... 0 W Light 230 V-I 250 W 250 W 250 W 250 W 250 W Model Packaging AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 1 unit COLD ROOM CONTROLLERS P_31 06_ ELECT...


lang:en **score:25** filesize: 21.75 M page_count: 138 document date: 2021-06-22



[\[pdf\]](#) User Manual Documentation

351569042 cdr Daniel Gutierrez Manuals and documentation · Ako 2 help ako assets PROPlus 3PH BASIC Electronic Panel 1 Presentation is the global electronic solution to manage positive negative cold room stores in combination with YStandard condensing units YStreamlined YOr as a service panel decentralised systems It offers high degree of IP65 protection for installation damp environments ||| GB AKO-1569x AKO-1569x-EVC PROPlus 3PH BASIC Electronic Panel User Manual 1569H042 Ed.03 1569H042 ... sing unit Condenser fans Evaporator fan Defrost resistances Light Power supply AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:en **score:23** filesize: 8.16 M page_count: 28 document date: 2020-12-02



[\[pdf\]](#)

3515690E71 cdr Daniel Gutierrez 355 mm 255 AKO 15690 EVC 15691 15692 help ako assets 1 ||| 355 mm 255 mm GND B A GND I2 I1 GND S3 GND S2 GND S1 PE 6 mm 6 mm GND Tr MODBUS RS-485 255 1 ... S2 Tr 1 3 5 7 9 11 L 11 14 BC L N B1 B2 A N 2 4 6 10 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15693-EVC RESISTENCIA DESESCARCHE ELECTRIC DEFROST RESISTANCE DGIVRAGE ABTAUHEIZU...


lang:i-klngon **score:21** filesize: 5.75 M page_count: 1 document date: 2020-12-02



[\[pdf\]](#) Documentation

Manuals and documentation · Ako 351000004 2 help ako assets CATÁLOGO COMERCIAL 01 Termómetros termostatos y controladores montaje panel homologados RD244 2016 ICT155 2020 02 ||| CATLOGO COMERCIAL SOLUCIONES DE REFRIGERACIN SOSTENIBLE Y EFICIENTE PARA AHORRAR ENERGA Y PROTEGER E ... 0.200 W 20.000 W Luz 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Modelo AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 Envase 1 ud. P_31 06_ CUADROS ELECTRNICOS DE...


lang:es **score:20** filesize: 22.94 M page_count: 148 document date: 2021-06-22



[\[pdf\]](#)

351569057 cdr Daniel Gutierrez Szafa sterownicza PROPlus 3PH BASIC Электронный щит управления 1 help ako assets ||| TR RU 1569H057 Ed.02 AKO-1569x AKO-1569x-EVC Szafa sterownicza PROPlus 3PH BASIC PROPlus 3PH BA ... y skraplacza Wentylator parownika Rezystory odszraniania Owietlenie Zasilanie AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:sw **score:20** filesize: 7.57 M page_count: 28 document date: 2015-09-25



[pdf]

351569057 cdr Daniel Gutierrez Elektronik panel PROPlus 3PH BASIC Электронный щит управления 3 help ako assets |||

TR RU 1569H057 Ed.04 AKO-1569x AKO-1569x-EVC Elektronik panel PROPlus 3PH BASIC PROPlus 3PH BAS ... sr birimi Kondansr fanlari Evaporatr fanlari Rezistans defrost lik G beslemesi AKO-15690 AKO-15691 **AKO-15692** 2,5 - 4 A 4 - 6,3 A 3 A 6,3 - 10 A I N 7.000 W 4 A I N AKO-15693 AKO-15697 10 ...

lang:id **score:20** filesize: 4.31 M page_count: 28 document date: 2018-09-07




[pdf] Instructions Guide

3515690513 cdr Daniel Gutierrez help ako assets |||

fr ar AKO-1569x AKO-1569x-EVC PROPlus 3PH BASIC Electronic Panel PROPlus 3PH Guide rapide / 15 ... condensation Ventilateur vaporateur Rsistances dgivrage clairage Alimentation AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:fr **score:20** filesize: 4.32 M page_count: 28 document date: 2022-12-20



[pdf]

351569071 cdr Daniel Gutierrez 355 mm 255 AKO 15690 15691 15692 RS 485 MODBUS Digital input 2 1 GND Tr 52 \$1 ■ ■ ■ 33 3 L 11 14 N B1 B2 4 5 ■ ■ TERMISTANCIA THERMISTOR help ako assets |||

255 mm GND B A GND I2 I1 GND S3 GND S2 GND S1 PE 6 mm 6 mm 355 mm 255 16 16 355 1 6 mm 2 90 ... L 1 F 2 N N N 4 N N A1 A2 A3 NO C NC 2 4 6 10 12 14 16 18 20 AKO-15690 AKO-15691 **AKO-15692** AKO-15693 RESISTENCIA DESESCARCHE ELECTRIC DEFROST RESISTANCE DGIVRAGE ABTAUHEIZUNG REZ...

lang:fr **score:20** filesize: 5.73 M page_count: 1 document date: 2020-12-02




[\[pdf\]](#) User Manual

351569054 cdr Daniel Gutierrez Elektronische Schaltanlage PROPlus 3PH BASIC Quadro eletrônico 2 help ako assets |||

DP 1569H054 Ed.03 AKO-1569x AKO-1569x-EVC Elektronische Schaltanlage PROPlus 3PH BASIC Quadro elet ... ondensator Ventilatoren Verdampfer Widerstnde Abtauung Licht Strom- versorgung AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:de **score:19** filesize: 4.25 M page_count: 28 document date: 2018-09-07



[\[pdf\]](#) User Manual

351569042 cdr Daniel Gutierrez PROPlus 3PH BASIC Electronic Panel help ako assets |||

GB AKO-1569x AKO-1569x-EVC PROPlus 3PH BASIC Electronic Panel User Manual 1569H042 Ed.01 1569H042 ... sing unit Condenser fans Evaporator fan Defrost resistances Light Power supply AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15693-EVC AKO-...

lang:en **score:18** filesize: 8.8 M page_count: 28 document date: 2015-05-08



[\[pdf\]](#) User Manual

351569042 cdr Daniel Gutierrez PROPlus 3PH BASIC Electronic Panel 1 help ako assets |||

GB AKO-1569x AKO-1569x-EVC PROPlus 3PH BASIC Electronic Panel User Manual 1569H042 Ed.02 1569H042 ... sing unit Condenser fans Evaporator fan Defrost resistances Light Power supply AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:en **score:17** filesize: 8.79 M page_count: 28 document date: 2015-10-22



[\[pdf\]](#) User Manual

351569041 cdr Daniel Gutierrez Cuadro electrónico PROPlus 3PH BASIC 1 help ako assets |||

E 1569H041 Ed.02 AKO-1569x AKO-1569x-EVC Cuadro electrónico PROPlus 3PH BASIC Manual de usuario 1 ... s condensador Ventiladores evaporador Resistencias desescarche Luz Alimentación AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:es score:16 filesize: 8.84 M page_count: 28 document date: 2015-09-25



[\[pdf\]](#)

351569043 cdr Daniel Gutierrez Tableau électronique PROPlus 3PH BASIC 1 help ako assets |||

F 1569H043 Ed.02 AKO-1569x AKO-1569x-EVC Tableau électronique PROPlus 3PH BASIC Manuel d'utilisation ... condensation Ventilateur vaporisateur Résistances dégivrage éclairage Alimentation AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** AKO-15...

lang:fr score:16 filesize: 8.86 M page_count: 28 document date: 2015-09-25




[\[pdf\]](#) Catalog

CATÁLOGO COMERCIAL 2016 Ako catalog esp help ako assets |||

CATLOGO COMERCIAL 2016 REGULACIÓN Y CONTROL DE TEMPERATURA PARA EL MERCADO DE LA REFRIGERACIÓN, LA INDUSTRIA Y LA CONSTRUCCIÓN ... AKO-15682 31 AKO-15683 31 AKO-15690 46 AKO-15690-EVC 46 AKO-15691 46 AKO-15691-EVC 46 **AKO-15692** 46 **AKO-15692-EVC** 46 AKO-15693 46 AKO-15693-EVC 46 AKO-15697 46 AKO-15697-EVC 45...

lang:es score:16 filesize: 13.63 M page_count: 100 document date: 2016-04-21




[\[pdf\]](#) Catalog

CATÁLOGO CONDENSADO 2016 Ako catalog esp int help ako assets |||

CATLOGO CONDENSADO 2016 REGULACIN Y CONTROL DE TEMPERATURA PARA EL MERCADO DE LA REFRIGERACIN, LA IN ... 2 AKO-15673 AKO-15680 AKO-15681 AKO-15682 AKO-15683 AKO-15690 AKO-15690-EVC AKO-15691 AKO-15691-EVC **AKO-15692 AKO-15692-EVC** AKO-15693 AKO-15693-EVC AKO-15697 AKO-15697-EVC AKO-15699 AKO-15699-1 AKO-15...

lang:es **score:15** filesize: 13.31 M page_count: 98 document date: 2016-04-22




[\[pdf\]](#) Catalog

Catalogue Commercial 2015Catalogo AKO2015 FRhelp ako assets Catalogo FR |||

Catalogue Commercial 2015 CONTRLE ET RGULATION POUR LA RFRIGATION INDUSTRIELLE ET COMMERCIALE NOT ... KO-15658 AKO-15659 AKO-156632 AKO-15673 AKO-15680 AKO-15681 AKO-15682 AKO-15683 AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15699 AKO-15690 AKO-15697 AKO-15690-EVC AKO-15691-EVC **AKO-15692-EVC** Emballa...

lang:fr **score:15** filesize: 11.85 M page_count: 72 document date: 2015-07-30



[\[pdf\]](#) Catalog

Catalogo general GB 2015 indd COMERCIAL CATALOGUE catcom2015 en help ako assets |||

COMERCIAL CATALOGUE 2015 REGULATION AND CONTROL OF TEMPERATURE FOR REFRIGERATION, INDUSTRY AND CONST ... 2 AKO-15673 AKO-15680 AKO-15681 AKO-15682 AKO-15683 AKO-15690 AKO-15690-EVC AKO-15691 AKO-15691-EVC **AKO-15692 AKO-15692-EVC** Pack Page 1 Unit 31 1 Unit 31 1 Unit 31 1 Unit 30 10 Units 43 1 ...

lang:en **score:14** filesize: 20.3 M page_count: 92 document date: 2015-05-08



[\[pdf\]](#)

CATÁLOGO COMERCIAL Catálogo AKO MEX help ako assets |||

CATLOGO COMERCIAL SOLUCIONES DE REFRIGERACION SOSTENIBLE Y EFICIENTE PARA AHORRAR ENERGIA Y PROTEGER E ... 0.200 W 20.000 W Luz 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Modelo AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 Envase 1 ud. P_28 06_ CUADROS ELECTRONICOS DE...

lang:es **score:14** filesize: 15.55 M page_count: 126 document date: 2020-05-21



[\[pdf\]](#) Catalog

CATÁLOGO COMERCIAL 351000004 Catalogo AKO ES help ako assets |||

CATLOGO COMERCIAL SOLUCIONES DE REFRIGERACION SOSTENIBLE Y EFICIENTE PARA AHORRAR ENERGIA Y PROTEGER E ... 0.200 W 20.000 W Luz 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Modelo AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 Envase 1 ud. P_31 06_ CUADROS ELECTRONICOS DE...

lang:es **score:13** filesize: 19.14 M page_count: 150 document date: 2020-04-22



[\[pdf\]](#) Catalog

Catalogo AKO ES indb 351000004 1 help ako assets |||

CATLOGO COMERCIAL SOLUCIONES DE REFRIGERACION SOSTENIBLE Y EFICIENTE PARA AHORRAR ENERGIA Y PROTEGER E ... 0.200 W 20.000 W Luz 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Modelo AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 Envase 1 ud. P_31 06_ CUADROS ELECTRONICOS DE...

lang:es **score:13** filesize: 25.66 M page_count: 150 document date: 2021-01-12



[\[pdf\]](#)

CATÁLOGO COMERCIAL Ako 01 Termómetros termostatos y controladores montaje panel 02 mural 03

Termostatos controladores 351000006 1 help ako assets |||

CATLOGO COMERCIAL SOLUCIONES DE REFRIGERACION SOSTENIBLE Y EFICIENTE PARA AHORRAR ENERGIA Y PROTEGER E ... 0.200 W 20.000 W Luz 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Modelo AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 Envase 1 ud. P_28 06_ CUADROS ELECTRONICOS DE...

lang:es **score:13** filesize: 18.21 M page_count: 126 document date: 2021-06-22



[\[pdf\]](#) Catalog

Catálogo en indb 351000202 help ako assets |||

COMMERCIAL CATALOGUE CONNECTED SOLUTIONS FOR PRODUCT CARE ENERGY EFFICIENCY www.ako.com MORE TH ... 0 W Light 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Model Packaging AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 1 unit COLD ROOM CONTROLLERS P_31 06_ ELECT...

lang:en **score:13** filesize: 45.28 M page_count: 138 document date: 2020-11-16



[\[pdf\]](#)

351000004 help ako assets |||

CATLOGO COMERCIAL SOLUCIONES DE REFRIGERACION SOSTENIBLE Y EFICIENTE PARA AHORRAR ENERGIA Y PROTEGER E ... 0.200 W 20.000 W Luz 230 V-I 250 W 250 W 250 W 250 W 250 W 250 W 250 W Modelo AKO-15690 AKO-15691 **AKO-15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 Envase 1 ud. P_31 06_ CUADROS ELECTRONICOS DE...

lang:es **score:13** filesize: 25.69 M page_count: 150 document date: 2020-06-16

AKO

COMMERCIAL
CATALOGUE

CONNECTED SOLUTIONS
FOR PRODUCT CARE,
& ENERGY EFFICIENCY



www.ako.com

[\[pdf\]](#) Catalog

Catálogo en indb 351000202 1 help ako assets |||

COMMERCIAL CATALOGUE CONNECTED SOLUTIONS FOR PRODUCT CARE
ENERGY EFFICIENCY www.ako.com MORE TH ... 0 W Light 230 V-I 250 W 250 W
250 W 250 W 250 W 250 W 250 W Model Packaging AKO-15690 AKO-15691 **AKO-
15692** AKO-15693 AKO-15697 AKO-15699 AKO-15699-1 1 unit COLD ROOM
CONTROLLERS P_31 06_ ELECT...

lang:en **score:13** filesize: 24.1 M page_count: 138 document date: 2021-01-12