

[Manuals.plus](#) /

› [Luoba](#) /

› Luoba Smart Watch for Kids Instruction Manual

Luoba i19

Luoba Smart Watch for Kids Instruction Manual

Model: i19

1. INTRODUCTION

Thank you for choosing the Luoba Smart Watch for Kids. This multi-functional smartwatch is designed to provide entertainment and educational value for children aged 3-10 years. It features a 1.44-inch touchscreen and comes equipped with a variety of functions including 20 puzzle games, a camera, video recording, music playback, an alarm clock, stopwatch, and calendar. It also incorporates new learning features such as object sound recognition, fitness exercises, and good habits teaching. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new smartwatch.



Image: The Luoba Smart Watch for Kids in green, showcasing its design and digital display.

2. SETUP

2.1 Charging the Device

Before first use, fully charge the smartwatch. Connect the provided USB charging cable to the charging port on the side of the watch and plug the other end into a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging port is typically covered by a small rubber flap for protection. A full charge usually takes approximately 2-3 hours.

2.2 Powering On/Off

To power on the smartwatch, press and hold the power button located on the side of the watch until the screen

illuminates. To power off, press and hold the power button again until the power-off prompt appears on the screen, then confirm your selection.

2.3 Adjusting the Strap

The watch strap is adjustable to fit various wrist sizes. Use the buckle and the multiple holes on the strap to find a comfortable and secure fit for the wearer. Ensure the watch is not too tight or too loose for optimal comfort during use.

3. OPERATING INSTRUCTIONS

3.1 Navigating the Touchscreen

The Luoba Smart Watch features a responsive 1.44-inch touchscreen. Swipe left or right to browse through different applications and functions. Tap on an icon to select and open an application. Use the physical home button on the side to return to the main clock interface.



Image: Overview of the smartwatch's multifunctional interface, displaying icons for various features.

3.2 Core Functions

- **Camera & Video:** The watch supports taking photos and recording videos. Access these functions through their respective icons. Children can capture their daily moments directly from their wrist.



Image: Two children playing, with the smartwatch prominently displaying its camera and video recording capabilities.

- **Recording:** Use the recording function to capture audio notes or messages.
- **Music Playback:** The watch has built-in fun children's songs. You can also connect the watch to a computer via USB to transfer additional music files your child enjoys.
- **Alarm Clock:** Set multiple alarms to help with daily routines, such as waking up or reminding for activities.
- **Stopwatch:** A simple stopwatch function for timing activities or games.
- **Calendar:** View the current date and month.
- **Analog Clock:** Choose from various 12-hour and 24-hour analog clock faces and customize the watch background wallpaper to personalize the display.





Image: A selection of customizable analog clock faces and background wallpapers available on the smartwatch.

3.3 Educational and Game Features

- **20 Puzzle Games:** The smartwatch includes 20 built-in puzzle games designed to enhance children's logical thinking, reaction ability, and hand-eye coordination.

20 Fun Puzzle Games

Kids Smart Watch with 3 Exciting+17 Puzzle Games



Teddy Bear Escape



Car grab goods



Mario eat gold



Sky ang gold



Tetris



Memory



Parking puzzle




Sudoku

Image: A young boy interacting with the smartwatch, highlighting the 20 built-in puzzle games that develop cognitive skills.

- **Learning Themes:** Explore three easy learning themes: recognizing 10 object sounds, 9 steps of fitness exercises, and 5 good habits teaching. These features are designed to make learning fun and interactive.

Kids Toys with Easy Learning Themes



Learning Good Habits Teaching



Fitness Exercises Steps Teaching



Recognizing 10 Object Sound

Image: Visual representation of the smartwatch's easy learning themes, covering good habits, fitness, and object sounds.

4. MAINTENANCE

To ensure the longevity and optimal performance of your Luoba Smart Watch, follow these maintenance guidelines:

- **Cleaning:** Wipe the watch screen and strap regularly with a soft, dry cloth. For stubborn smudges, a slightly damp cloth can be used, but ensure no moisture enters the charging port or speaker.
- **Battery Care:** Avoid completely draining the battery frequently. Charge the watch when the battery indicator is low. Store the watch in a cool, dry place when not in use for extended periods.
- **Storage:** Keep the watch away from extreme temperatures, direct sunlight, and high humidity.
- **Water Resistance:** The watch is not waterproof. Avoid exposing it to water, rain, or excessive moisture.

5. TROUBLESHOOTING

If you encounter any issues with your Luoba Smart Watch, please refer to the following common troubleshooting steps:

- **Watch Not Turning On:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes before attempting to power it on again.
- **Screen Unresponsive:** Try restarting the watch by holding down the power button. If unresponsive, allow the battery to fully drain and then recharge it.
- **Sound Issues:** Check the volume settings in the watch's menu. Ensure the speaker is not obstructed.
- **Games Not Loading:** Ensure there is sufficient storage space. Try restarting the device.
- **Unable to Transfer Music:** Verify the USB cable connection is secure. Ensure the watch is recognized by your computer. Check the file format of the music (typically MP3 is supported).

If the problem persists after trying these steps, please contact customer support for further assistance.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	9.17 x 1.65 x 0.55 inches
Item Weight	1.28 ounces
Country of Origin	China
ASIN	B0CB3TND27
Item Model Number	i19
Manufacturer Recommended Age	36 months - 12 years
Batteries	1 Lithium Ion battery required (included)
Special Feature	Video Recording
Connectivity Technology	USB
Battery Cell Composition	Lithium Polymer
GPS	No GPS
Shape	Round
Screen Size	1.44 Inches
Brand	Luoba
Model Name	i19
Style	Modern
Color	green

7. WARRANTY AND SUPPORT

Luoba offers a **1-year warranty** for this smartwatch, ensuring peace of mind regarding manufacturing defects or malfunctions under normal use. We are committed to providing friendly and responsive customer service.

For any questions, technical support, or warranty claims, please contact our customer service team through the retailer's platform or visit the official Luoba store online. Please have your product model (i19) and purchase details ready when contacting support.

Visit the [Luoba Store](#) for more information and products.

