

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BANGSON](#) /

› [BANGSON 1.1 Cu.ft Mini Upright Freezer Model US-BSR-017-2 Instruction Manual](#)

BANGSON US-BSR-017-2

BANGSON 1.1 Cu.ft Mini Upright Freezer Instruction Manual

Model: US-BSR-017-2

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your new BANGSON 1.1 Cu.ft Mini Upright Freezer. Retain this manual for future reference.

- Ensure the freezer is unplugged before cleaning or performing any maintenance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is intended for household use only.

2. PRODUCT OVERVIEW

The BANGSON 1.1 Cu.ft Mini Upright Freezer is designed for compact storage of frozen goods. It features a reversible door and adjustable leveling legs for versatile placement.



Image: Front view of the BANGSON 1.1 Cu.ft Mini Upright Freezer with its door open, revealing various frozen food items and a removable shelf.



Image: Overview of the freezer's main features, including large food storage capacity, low noise operation, energy efficiency, and a compact design.

reversible door.

3. SETUP AND INSTALLATION

3.1 Unpacking

- Remove all packaging materials, including foam and adhesive tape.
- Inspect the freezer for any shipping damage. Report any damage to your retailer immediately.

3.2 Placement

Choose a location with a firm, level floor that can support the freezer when fully loaded. Allow adequate space around the unit for proper ventilation.

- **Dimensions:** 18.5 inches (L) x 18 inches (D) x 19.1 inches (H).
- Allow at least 4 inches of space at the back and sides for proper air circulation.
- Avoid direct sunlight or heat sources.



Image: Visual representation of the freezer's dimensions, highlighting its compact size.

1.100.14 Mini Freezer




Large Food Storage



Low Noise



Energy Saving



Reversible Door

Image: Examples of the freezer's versatile placement in different environments such as a kitchen, living room, bedroom, or office.

3.3 Leveling the Freezer

The freezer must be level for proper operation. Adjust the leveling legs at the bottom of the unit by turning them clockwise or counter-clockwise until the freezer is stable.

Reversible Door

Easy to change the direction of the door switch



Adjustable Leveling Legs

Keep the freezer stable even on uneven grounds



Image: Detail of the adjustable leveling legs, which help stabilize the freezer on uneven surfaces.

3.4 Door Reversal

The door of this freezer is reversible, allowing it to open from either the left or right side. Refer to the detailed instructions in the full product manual for the door reversal procedure.

3.5 Initial Operation

- After placement, allow the freezer to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle.
- Plug the freezer into a dedicated 115V electrical outlet.
- Set the temperature control to a medium setting (e.g., '3').
- Allow the freezer to cool for 2-4 hours before loading with frozen items.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The freezer features a 5-level adjustable thermostat located at the rear of the unit. Turn the dial to select your desired temperature setting.

- **Setting '1'**: The warmest setting (approximately 7°F / -14°C).
- **Settings '2'-'4'**: Partial freezing range.
- **Setting '5'**: The coldest setting (approximately -8°F / -22°C).

ADJUSTABLE TEMPERATURE

Can be adjusted 5 levels from 7°F to -8°F



Image: Visual guide to the 5-level temperature control knob, indicating the range from warmest to coldest settings.

4.2 Loading the Freezer

For optimal performance, avoid overloading the freezer. Ensure there is enough space for air to circulate around items.

1.1 Cu.ft Upright Freezer



Ice Cube



Ice Cream



Breast Milk



Seafood



Image: Illustrates the 1.1 Cu.ft capacity and types of items suitable for storage, such as ice, ice cream, breast milk, and seafood.

4.3 Energy Saving Tips

- Keep the freezer door closed as much as possible.
- Do not place hot food directly into the freezer; allow it to cool to room temperature first.
- Defrost the freezer regularly to prevent excessive ice buildup, which reduces efficiency.

5. MAINTENANCE AND CLEANING

5.1 Defrosting

This freezer requires manual defrosting. Defrost when ice buildup on the interior walls reaches approximately 1/4 inch (6 mm) thickness.

1. Unplug the freezer from the power outlet.
2. Remove all frozen food and place it in another freezer or cooler.
3. Leave the door open to allow ice to melt naturally. Place towels or a shallow pan to collect water.

4. Once defrosted, clean and dry the interior thoroughly before plugging the freezer back in and returning food.

5.2 Cleaning

Regular cleaning helps maintain the freezer's performance and appearance.

- **Interior:** Use a soft cloth with a solution of mild detergent and warm water. Rinse and dry thoroughly. The removable shelf can be washed separately.
- **Exterior:** Wipe with a soft cloth dampened with water and a mild detergent.
- **Door Seal:** The door seal is removable for easy cleaning. Clean with warm soapy water and ensure it is dry before reattaching. A clean seal ensures efficient operation.

BANGSON MINI FREEZER DETAILS




Recessed Door Handle



Stainless Steel Door



Movable Shelf



Removable Door Seal

Image: Close-up details of the freezer, highlighting the movable shelf and removable door seal for maintenance.

6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Freezer does not operate	No power; circuit breaker tripped; power cord not plugged in securely.	Check power supply; reset circuit breaker; ensure cord is firmly plugged in.
Freezer is not cold enough	Temperature control set too warm; door opened too frequently; excessive ice buildup; poor ventilation.	Adjust temperature to a colder setting; minimize door openings; defrost the unit; ensure adequate space around the freezer.
Excessive noise	Freezer is not level; objects vibrating against the unit.	Adjust leveling legs; ensure nothing is touching the freezer.
Door does not close properly	Freezer is not level; door seal is dirty or damaged; items obstructing the door.	Level the freezer; clean or replace door seal; rearrange items inside.

7. SPECIFICATIONS

Detailed technical specifications for the BANGSON 1.1 Cu.ft Mini Upright Freezer.

Feature	Specification
Brand	BANGSON
Model Number	US-BSR-017-2
Capacity	1.1 Cubic Feet
Dimensions (L x D x H)	18.5 x 18 x 19.1 inches
Item Weight	35.3 pounds
Voltage	115 Volts
Temperature Range	-8°F to 7°F (-22°C to -14°C)
Defrost Type	Manual Defrost
Door Hinges	Reversible
Door Material Type	Stainless Steel
Shelves	2 (wire)
Certification	DOE
Estimated Yearly Energy Cost	\$25
Estimated Yearly Electricity Use	203 kWh

ENERGYGUIDE



Freezer

- Manual Defrost
- Compact

Brand: **BANGSON**

Model:US-BSR-017-2

Capacity: 1.1 Cubic Feet

Compare ONLY to other labels with yellow numbers. Labels with yellow numbers are based on the same test procedures.

Estimated Yearly Energy Cost

\$25



203 kWh

Estimated Yearly Electricity Use

- Your cost will depend on your utility rates and use.
- Both cost ranges based on models of similar size capacity.
- Models with similar features have manual defrost.
- Estimated energy cost based on a national average electricity cost of 12 cents per kWh.

ftc.gov/energy

Image: EnergyGuide label providing estimated yearly energy cost and electricity usage for the freezer.

8. WARRANTY AND SUPPORT

8.1 Product Warranty

The BANGSON 1.1 Cu.ft Mini Upright Freezer comes with a **one-year service warranty** from the date of purchase.

This warranty covers manufacturing defects and ensures courteous service for product-related issues. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact BANGSON customer support:

- **Website:** [Visit the BANGSON Store on Amazon](#)
- **Email:** Refer to your purchase documentation for specific contact email.
- **Phone:** Refer to your purchase documentation for specific contact number.