

TechniSat DIGITRADIO 4 IR

TechniSat DIGITRADIO 4 IR Stereo Internet Radio User Manual

MODEL: DIGITRADIO 4 IR (0000/3957)

Product Overview

The TechniSat DIGITRADIO 4 IR is a versatile stereo internet radio designed for high-quality audio reception and playback. It supports DAB+, FM, and internet radio, offering a wide range of national and regional programs. The device features Bluetooth audio streaming, allowing playback from smartphones and tablets, and includes a USB port for MP3 file playback. Equipped with two 10W ELAC speakers and a clear 3.5-inch TFT color display, it delivers excellent sound and user experience. Control is intuitive via rotary knobs, remote control, or a smartphone application.

Package Contents

- DIGITRADIO 4 IR Stereo Internet Radio (Black)
- Telescopic antenna with mounting tool
- Power adapter
- Remote control with batteries (2 x AAA)
- User manual

Device Features and Controls

Familiarize yourself with the main components and controls of your DIGITRADIO 4 IR.



Image: Front view of the TechniSat DIGITRADIO 4 IR radio, showing the central display, two large rotary knobs for volume/standby and select/snooze, and several control buttons (Mode, Menu, Fav, Scan, Play/Pause, Skip tracks).



Image: Rear view of the TechniSat DIGITRADIO 4 IR radio, highlighting the connection ports: RF IN for antenna, USB 5V 1A, AUDIO IN (AUX), and DC IN 12V 3A power input. Two bass reflex ports are also visible.



Image: The remote control for the TechniSat DIGITRADIO 4 IR radio, featuring buttons for power, EQ, scan, alarm, sleep timer, playback controls, menu navigation, volume, and a numeric keypad for direct station access.

Setup

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Antenna Connection:** Connect the telescopic antenna to the RF IN port on the rear of the device.

Extend the antenna for optimal reception.

3. **Power Connection:** Connect the power adapter to the DC IN 12V 3A port on the rear of the radio, then plug it into a wall outlet.
4. **Initial Setup Wizard:** Upon first power-on, the radio will guide you through an initial setup wizard. Follow the on-screen instructions to set language, time, date, and network connection.
5. **Network Connection (Wi-Fi):** Select your Wi-Fi network from the list and enter the password. A stable internet connection is required for internet radio and streaming services.

Operating Instructions

Power On/Off and Standby

Press the **VOL / STANDBY** rotary knob to switch the device on or off. In standby mode, the display shows the time and date.

Mode Selection

Press the **MODE** button on the front panel or remote control to cycle through available modes: DAB+, FM, Internet Radio, Bluetooth, USB, and AUX In.

DAB+ Radio

1. Select DAB+ mode.
2. The radio will automatically scan for available DAB+ stations.
3. Use the **SELECT / SNOOZE** rotary knob or the < / > buttons on the remote to navigate through stations.
4. Press the **SELECT / SNOOZE** knob or **OK** on the remote to select a station.
5. To save a favorite station, press and hold the **FAV** button, then select a preset number.

FM Radio

1. Select FM mode.
2. Press the **SCAN** button to automatically search for FM stations.
3. Manually tune using the **SELECT / SNOOZE** rotary knob or the < / > buttons.
4. To save a favorite station, press and hold the **FAV** button, then select a preset number.

Internet Radio

1. Ensure the radio is connected to your Wi-Fi network.
2. Select Internet Radio mode.
3. Browse stations by location, genre, or search.
4. Press the **SELECT / SNOOZE** knob or **OK** on the remote to select a station.
5. To save a favorite station, press and hold the **FAV** button, then select a preset number.

Bluetooth Audio Streaming

1. Select Bluetooth mode on the radio. The display will show "Pairing".
2. Enable Bluetooth on your smartphone or tablet and search for available devices.
3. Select "DIGITRADIO 4 IR" from the list to pair.

4. Once paired, you can stream audio from your device to the radio.

USB Playback

1. Insert a USB drive containing MP3 files into the USB port on the rear of the radio.
2. Select USB mode.
3. Use the controls to navigate and play your music files.

AUX Input

1. Connect an external audio source (e.g., an MP3 player) to the AUX IN port on the rear of the radio using a 3.5mm audio cable (not included).
2. Select AUX mode.
3. Audio from the connected device will play through the radio's speakers.

Alarm Clock and Sleep Timer

Access alarm and sleep timer settings via the **MENU** button or dedicated buttons on the remote control. Follow the on-screen prompts to configure these functions.

Display Settings

Adjust display brightness for operating and standby modes through the **MENU** settings. The radio also features an auto-dimming function.

Maintenance

To ensure the longevity and optimal performance of your DIGITRADIO 4 IR, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the radio. Do not use abrasive cleaners, waxes, or solvents.
- **Display Care:** Gently wipe the display with a soft, lint-free cloth. Avoid pressing hard on the screen.
- **Ventilation:** Ensure the ventilation openings are not blocked to prevent overheating.
- **Environment:** Keep the radio away from direct sunlight, heat sources, dust, and moisture.

Troubleshooting

If you encounter issues with your DIGITRADIO 4 IR, refer to the following common solutions:

- **No Power:** Ensure the power adapter is securely connected to both the radio and a working power outlet.
- **No Sound:** Check the volume level. Ensure the correct audio source mode is selected. If using AUX or Bluetooth, verify the external device's volume and connection.
- **Poor Radio Reception (DAB+/FM):** Extend and adjust the telescopic antenna. Try repositioning the radio to improve signal strength.
- **Internet Radio Connection Issues:** Verify your Wi-Fi network connection. Ensure the Wi-Fi password is entered correctly. Restart your Wi-Fi router and the radio.
- **Bluetooth Pairing Problems:** Ensure the radio is in Bluetooth pairing mode. Delete "DIGITRADIO 4 IR" from your device's Bluetooth list and attempt to pair again.

- **Connect App Not Recognizing Radio:** If using a companion app, try restarting your smartphone or tablet if the app fails to connect to the radio.
- **USB Playback Issues:** Ensure the USB drive is formatted correctly (FAT32) and contains supported MP3 audio files.

Specifications

Feature	Detail
Brand	TechniSat
Model Number	0000/3957
Color	Black
Connectivity Technology	Auxiliary, Bluetooth, USB, Wi-Fi
Special Features	Access to music services (Spotify, Amazon Music, Klassikradio Select, Calm Radio), USB interface with charging function and MP3 playback, FM Radio, Bluetooth audio streaming (reception), Favorite memory (30 DAB+ / 30 FM / 30 Internet)
Compatible Devices	Headphones, Smartphone, Tablet
Product Dimensions	38L x 18.5W x 13.5H cm
Tuning Technology	DAB+
Supported Radio Bands	DAB+, FM, Internet
Power Source	Corded Electric
Included Components	Power adapter, Telescopic antenna with mounting tool, DIGITRADIO 4 IR, User manual, Remote control with batteries

Warranty and Support Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official TechniSat website. Please note that spare parts availability for this product is currently unavailable, and information regarding guaranteed software updates is not provided.

For technical support or service inquiries, please contact TechniSat customer service through their official channels.

Related Documents - DIGITRADIO 4 IR

 <p>TechniSat</p> <p>DIGITRADIO 601 DIGITRADIO 631</p> <p>Internet Radio with DAB+/UKW Tuner and Bluetooth Streaming</p>	<p>TechniSat DIGITRADIO 601 & 631: Bedienungsanleitung für Internetradio mit DAB+/UKW und Bluetooth</p> <p>Umfassende Bedienungsanleitung für das TechniSat DIGITRADIO 601 und DIGITRADIO 631. Erfahren Sie mehr über die Funktionen, Einrichtung und Bedienung Ihres Internet-Radios mit DAB+/UKW-Tuner und Bluetooth-Streaming.</p>
 <p>TechniSat</p> <p>DIGITRADIO 140</p>	<p>TechniSat DIGITRADIO 140 Instruction Manual</p> <p>Comprehensive instruction manual for the TechniSat DIGITRADIO 140, covering setup, operation, features like Internet Radio, DAB+, FM, Bluetooth, CD/MP3 playback, and troubleshooting.</p>
 <p>Operating instructions</p> <p>DIGITRADIO 217</p> <p>Internet Radio with DAB+/UKW Tuner and Bluetooth Streaming</p> <p>TechniSat</p>	<p>TechniSat DIGITRADIO 217 Operating Instructions</p> <p>Comprehensive operating instructions for the TechniSat DIGITRADIO 217, detailing its features, setup, functions, and safety guidelines for DAB+/UKW radio with Bluetooth audio streaming and alarm clock functionality.</p>
 <p>Operating instructions</p> <p>DIGITRADIO 217</p> <p>Internet Radio with DAB+/UKW Tuner and Bluetooth Streaming</p> <p>TechniSat</p>	<p>TechniSat DIGITRADIO 217 Operating Instructions</p> <p>User manual for the TechniSat DIGITRADIO 217, a DAB+/UKW radio featuring Bluetooth audio streaming and an alarm clock function. Learn about setup, operation, safety, and technical specifications.</p>
 <p>Operating instructions</p> <p>DIGITRADIO 550 IR</p> <p>TechniSat</p>	<p>TechniSat DIGITRADIO 550 IR Operating Instructions</p> <p>Comprehensive operating instructions for the TechniSat DIGITRADIO 550 IR, covering setup, functions, safety, and technical specifications. Learn how to use your DAB+, FM, and Internet radio.</p>
 <p>TechniSat</p> <p>DIGITRADIO 143 CD</p>	<p>TechniSat DIGITRADIO 143 CD Instruction Manual</p> <p>Comprehensive instruction manual for the TechniSat DIGITRADIO 143 CD, covering setup, operation, features like internet radio, DAB+, FM, Bluetooth, and CD playback, along with troubleshooting and technical data.</p>