

[Manuals.plus](#) /

> [UPBRIGHT](#) /

> UpBright 19V AC/DC Adapter User Manual

UPBRIGHT POKITTER Orca Mini Power Supply

UpBright 19V AC/DC Adapter User Manual

Model: POKITTER Orca Mini Power Supply

INTRODUCTION

This manual provides essential information for the safe and efficient use of your UpBright 19V AC/DC Adapter. Please read this manual thoroughly before using the product and retain it for future reference.

The UpBright 19V AC/DC Adapter is designed to provide reliable power to compatible devices such as the POKITTER Orca Mini Portable Smart TV Projector. It features global input voltage compatibility and built-in protection mechanisms.

IMPORTANT SAFETY INSTRUCTIONS

- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose to rain or moisture.
- **Proper Voltage:** Ensure the input voltage of your device matches the output voltage of this adapter (19V DC).
- **Ventilation:** Do not cover the adapter during operation. Ensure adequate ventilation to prevent overheating.
- **Cable Care:** Do not place heavy objects on the power cord. Avoid bending, twisting, or pulling the cord excessively.
- **Disconnect Power:** Always unplug the adapter from the power outlet before cleaning or when not in use for extended periods.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact qualified service personnel for repair.
- **Children:** Keep out of reach of children.


SETUP

Follow these steps to set up your UpBright AC/DC Adapter:

1. **Unpack:** Carefully remove the adapter and power cord from the packaging.
2. **Inspect:** Check the adapter and cables for any visible damage. Do not use if damaged.
3. **Connect Power Cord:** Connect the appropriate AC power cord (provided) to the adapter's AC input port. Ensure it is firmly seated.

Come With A Suitable AC Power Cord (Only One)

to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image: This image displays various types of AC power cords (US, EU, UK, AU) that may be supplied with the adapter, along with the adapter itself. Only one suitable power cord for your region will be included.

4. **Connect to Device:** Plug the DC output connector of the adapter into the DC input port of your compatible device (e.g., POKITTER Orca Mini Projector). Ensure the connection is secure.



Image: The UpBright 19V AC/DC Adapter showing its main body, the DC output cable with its plug, and the AC input cable. The label on the adapter provides specifications and safety warnings.

5. **Plug into Outlet:** Insert the AC power cord plug into a suitable wall power outlet.

OPERATING INSTRUCTIONS

Once the adapter is properly connected, it will supply power to your device. No further operation is required for the adapter itself.

- **Power Indicator:** Some adapters may have an LED indicator to show when power is being supplied. Refer to the adapter's label for details.
- **Device Operation:** Operate your connected device according to its own user manual.
- **Disconnecting:** To disconnect power, first unplug the AC power cord from the wall outlet, then disconnect the DC plug from your device.

MAINTENANCE AND CARE

Proper care will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cables.
- **Inspection:** Periodically inspect the adapter, power cord, and connectors for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power to device	Adapter not plugged in; loose connection; faulty outlet; damaged adapter/cable.	Ensure all connections are secure. Try a different wall outlet. Inspect adapter and cables for damage. If damaged, discontinue use and replace.
Adapter feels hot	Normal operation (slight warmth); insufficient ventilation; overloaded.	A slight warmth is normal. Ensure adapter is in a well-ventilated area. Verify device power requirements do not exceed adapter's output. If excessively hot, disconnect immediately.
Device not charging/powering on correctly	Incorrect adapter voltage/current; device issue.	Confirm the adapter's output specifications (19V DC) match your device's requirements. Consult your device's manual.

SPECIFICATIONS

Feature	Detail
Brand	UPBRIGHT
Model	POKITTER Orca Mini Power Supply
Input Voltage	100-240VAC, 50/60Hz (World Wide Input Voltage)
Output Voltage	19V DC
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Dimensions (L x W x H)	15.24 x 7.62 x 5.08 cm (approx. 6 x 3 x 2 inches)
Weight	283.5 g (approx. 10 ounces)

WARRANTY AND SUPPORT

UpBright products are designed for reliability and performance. This adapter comes with:

- **30 Days Refund Policy:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **24 Months Exchange Policy:** For any manufacturing defects or issues under normal use, the product is eligible for exchange within 24 months.

For support or warranty claims, please contact your retailer or visit the official UpBright website. Please have your purchase details and product model number ready.



Image: A representation of the UpBright Limited Warranty Certificate, indicating the terms of warranty and a gold seal signifying product warranty.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CB5RLLSR>

More documents and user manuals: <https://manuals.plus/>