

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Hot Wheels](#) /
- › [Hot Wheels City Pizza Slam Cobra Attack Playset Instruction Manual](#)

## Hot Wheels HTN81

# Hot Wheels City Pizza Slam Cobra Attack Playset Instruction Manual

Model: HTN81 | Brand: Hot Wheels

## INTRODUCTION

---

Welcome to the exciting world of Hot Wheels City! This manual provides essential information for setting up, operating, and maintaining your Hot Wheels City Pizza Slam Cobra Attack Playset. Prepare for thrilling adventures as you help save the pizza shop from the menacing cobra.



Figure 1: The Hot Wheels City Pizza Slam Cobra Attack Playset, featuring a pizza shop, snake, and track elements.

## SAFETY INFORMATION

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**

- Keep out of reach of children under 3 years due to small parts.
- Adult assembly is required.
- Do not modify the playset.
- Ensure all connections are secure before play to prevent track separation.

## SETUP

Follow these steps to assemble your Hot Wheels City Pizza Slam Cobra Attack Playset:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify all components are present against the included parts list.
2. **Assemble Base:** Connect the base track pieces together. Ensure they snap securely into place.
3. **Attach Pizza Shop Tower:** Secure the pizza shop tower to the designated slot on the base.

4. **Connect Snake Tail Spiral:** Attach the orange snake tail spiral track to the top of the pizza shop tower and the blue launcher mechanism.
5. **Position Cobra Head:** Connect the cobra head to the end of the spiral track, ensuring it is securely positioned to interact with the car's path.
6. **Place Movable Elements:** Position the orange movable ramp and the yellow track diverters as shown in the diagrams.



Figure 2: Packaging of the playset, showing assembled view and components.

## OPERATING INSTRUCTIONS

The playset offers three random paths for your Hot Wheels car. Follow these steps to initiate play:

1. **Load Car:** Place one 1:64 scale Hot Wheels car into the blue launcher at the start of the track.
2. **Prepare Cobra:** Ensure the cobra's tail is in the upright position, ready to be released.
3. **Launch Car:** Press the red launch button firmly. The car will race down the track and trigger the cobra's tail mechanism.
4. **Observe Outcome:** The car will randomly take one of three paths:
  - **Path 1: Cobra's Mouth:** The car races through the cobra's mouth and into the dumpster.
  - **Path 2: Pizza Shop Safety:** The car races through the pizza shop and out to safety.
  - **Path 3: Pizza Slam:** The car sends a pizza pie smack into the cobra's face, defeating it.
5. **Reset Playset:** After each launch, reset the cobra's tail and any moved track elements to their starting positions for continuous play.



*Figure 3: A child engaging with the playset, demonstrating the launch mechanism.*



**ONE ROUTE RACES THROUGH THE COBRA'S MOUTH & INTO THE DUMPSTER**

*Figure 4: Close-up of a Hot Wheels car entering the cobra's mouth, leading to the dumpster.*



**ANOTHER GOES THROUGH THE PIZZA SHOP & OUT TO SAFETY**

Figure 5: A Hot Wheels car triggering the pizza to hit the cobra's face.



**A THIRD ROUTE ACTIVATES A PIZZA PIE TO KNOCK OUT THE COBRA**

Figure 6: A Hot Wheels car successfully navigating through the pizza shop to safety.

## MAINTENANCE

To ensure the longevity and optimal performance of your playset, follow these maintenance guidelines:

- **Cleaning:** Wipe down the playset with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect all track connections and moving parts for any signs of wear or damage. Replace any broken or worn parts immediately.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not launch properly.	Launcher mechanism is stuck or car is not positioned correctly.	Ensure the car is fully seated in the launcher. Check for any obstructions in the launcher mechanism.
Car gets stuck on the track.	Track pieces are not fully connected or there is debris on the track.	Verify all track connections are secure. Clean the track surface of any dust or small objects.
Cobra mechanism does not activate.	Car is not hitting the activation point with enough force or mechanism is jammed.	Ensure the car is launched with sufficient speed. Check for any obstructions around the cobra mechanism.

## SPECIFICATIONS

- **Product Dimensions:** 12.99 x 23.62 x 13.97 inches
- **Item Weight:** 2 pounds
- **Country of Origin:** China
- **Model Number:** HTN81
- **Manufacturer Recommended Age:** 3 years and up
- **Included:** 1 Hot Wheels City Pizza Slam Cobra Attack playset, 1 Hot Wheels car (1:64 scale)

## WARRANTY AND SUPPORT

For warranty information or product support, please visit the official Hot Wheels website or contact Mattel customer service. Keep your proof of purchase for any warranty claims.

**Official Hot Wheels Store:** [Visit Store](#)