



Manuals.plus /

› **Home Centre /**

› Home Centre Color Refresh Essence Sierra Polyresin Soap Dispenser - 410ml User Manual

Home Centre ESSENCE CR -SIERRA BEIGE 1

Home Centre Color Refresh Essence Sierra Polyresin Soap Dispenser

MODEL: ESSENCE CR -SIERRA BEIGE 1

Introduction

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Home Centre Color Refresh Essence Sierra Polyresin Soap Dispenser. Designed for durability and aesthetic appeal, this dispenser features a textured floral surface and a robust metal pump mechanism. Please read these instructions carefully to ensure optimal performance and longevity of your product.



Image: The Home Centre Color Refresh Essence Sierra Polyresin Soap Dispenser, showcasing its design and texture.

Setup

1. **Unpack the Dispenser:** Carefully remove the soap dispenser from its packaging. Inspect for any signs of damage.
2. **Remove the Pump:** Gently twist the metal pump counter-clockwise to detach it from the dispenser body.
3. **Fill with Liquid Soap:** Pour your preferred liquid hand soap, lotion, or shower gel into the dispenser body. Do not overfill; leave a small space at the top to accommodate the pump mechanism. The dispenser has a capacity of 410ml.
4. **Reattach the Pump:** Carefully place the pump back onto the dispenser body and twist clockwise until securely fastened.
5. **Prime the Pump:** Press the pump head several times until soap begins to dispense. This may require 5-10 presses initially.



Image: The soap dispenser with its dimensions indicated: 21 cm (height) and 9 cm (width).

Operating Instructions

To dispense soap, simply press down on the pump head. The pump mechanism is designed for smooth and consistent delivery of liquid contents. Release the pump head to allow it to return to its original position.

When the dispenser is low on liquid, follow the 'Remove the Pump' and 'Fill with Liquid Soap' steps from the Setup section to refill.

Maintenance

Regular cleaning will help maintain the appearance and functionality of your soap dispenser.

- **Exterior Cleaning:** Wipe the exterior of the dispenser with a soft, damp cloth. For stubborn spots, a mild soap solution can be used. Rinse thoroughly with a damp cloth and dry immediately.
- **Interior Cleaning:** Periodically, empty the dispenser and rinse the interior with warm water. For a more thorough cleaning, you can use a bottle brush. Ensure the interior is completely dry before refilling.
- **Pump Cleaning:** If the pump becomes stiff or clogged, remove it from the dispenser and rinse it under warm running water. You can pump warm water through the mechanism to clear any blockages.

- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or harsh chemical detergents, as these can damage the polyresin material and the metal finish of the pump.

Troubleshooting

- **Pump Not Dispensing:**
 - Ensure the dispenser is filled with liquid.
 - Prime the pump by pressing it repeatedly until liquid appears.
 - Check for clogs in the pump nozzle. Clean as described in the Maintenance section.
- **Pump Sticking:**
 - Clean the pump mechanism thoroughly to remove any dried soap residue.
 - Ensure the liquid soap used is not too thick for the pump mechanism. Diluting slightly with water may help if the soap is very viscous.
- **Leakage:**
 - Ensure the pump head is securely twisted onto the dispenser body.
 - Check for cracks or damage to the dispenser body. If damaged, discontinue use.

Specifications

Model Number	ESSENCE CR -SIERRA BEIGE 1
Material	Polyresin
Capacity	410 ml
Color	Beige
Product Dimensions (L x W x H)	8.27" x 3.54" x 8.27" (21 cm x 9 cm x 21 cm)
Item Weight	300 Grams
Pack Content	1 Soap dispenser

Warranty and Support

For any questions, concerns, or support regarding your Home Centre Color Refresh Essence Sierra Polyresin Soap Dispenser, please contact the retailer or manufacturer directly. Please retain your proof of purchase for warranty claims, if applicable. Specific warranty details may vary by region and retailer.