

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 13.5V AC/DC Adapter Instruction Manual for Hyper Tough 12V Max Cordless Tools

UPBRIGHT 99303

UpBright 13.5V AC/DC Adapter Instruction Manual

For Hyper Tough 12V Max Cordless Drills, Impact Drivers, and Work Lights

PRODUCT OVERVIEW

The UpBright 13.5V AC/DC Adapter is designed to provide reliable power for charging Hyper Tough 12V Max 1.5Ah Li-ion batteries used in various cordless tools. This adapter ensures your tools are ready for use by delivering the correct voltage and current for efficient charging. It features built-in safety protections including Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard both the adapter and your devices.




Image: The UpBright 13.5V AC/DC Adapter, a compact black power supply unit with a barrel connector cable.

WHAT'S IN THE BOX

Your UpBright AC/DC Adapter package includes the following:

- 1 x UpBright 13.5V AC/DC Adapter

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY




Image: The UpBright AC/DC Adapter shown alongside various international plug adapters (AU, EU, UK) and a warranty certificate, indicating global compatibility and product support.

SETUP INSTRUCTIONS

Follow these steps to set up your UpBright AC/DC Adapter for charging your Hyper Tough 12V Max tools:

1. **Verify Compatibility:** Ensure your Hyper Tough tool's battery is a 12V Max 1.5Ah Li-ion type. This adapter is specifically designed for models such as 99303, 99307, 93307, 99312, 98936, and 99334.
2. **Connect the Adapter:** Insert the barrel connector of the UpBright adapter into the charging port of your Hyper Tough battery or tool's charging base.
3. **Plug into Power:** Plug the AC end of the adapter into a standard 100-240VAC 50/60Hz wall outlet.
4. **Begin Charging:** The battery should begin charging automatically. Refer to your tool's manual for specific charging indicators.

Important Note: The 12V 1.5Ah rating refers to the drill's battery voltage, not the charger's output voltage. The charger provides 13.5V DC output.

UpBright AC Adapter Power Supply Compatible with:

(Machine not Included)



Image: The UpBright AC Adapter shown with a Hyper Tough 12-Volt Max Cordless Drill, illustrating compatibility.

UpBright AC Adapter Power Supply Compatible with:

(Machine not Included)



Image: The UpBright AC Adapter shown with a Hyper Tough 12-Volt Max Cordless Impact Driver, demonstrating compatibility.

UpBright AC Adapter Power Supply Compatible with:

(Machine not Included)



Image: The UpBright AC Adapter shown with a Hyper Tough 12-Volt Max 2 Speed Drill and Work Light Kit, highlighting its use with combo kits.

OPERATING INSTRUCTIONS

Once the adapter is properly connected to your battery and a power source, the charging process will commence. The adapter is designed for continuous use during charging cycles. Always ensure the adapter is placed in a well-ventilated area during operation to prevent overheating.

- **Charging Time:** Refer to your Hyper Tough tool's battery manual for estimated charging times.
- **Disconnection:** Once charging is complete, disconnect the adapter from the power outlet first, then from the battery/tool.
- **Safety:** Do not use the adapter if the cable is damaged or if the adapter casing is compromised.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your UpBright AC/DC Adapter, follow these maintenance guidelines:

- **Cleaning:** Wipe the adapter with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid bending or crimping the power cord excessively. Do not place heavy objects on the cord.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage. Discontinue use if damage is observed.

TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC Adapter, consider the following:

- **Adapter Not Charging:**
 - Ensure the adapter is securely plugged into both the wall outlet and the battery/tool.
 - Check if the wall outlet is functional by plugging in another device.
 - **Battery Condition:** Rechargeable batteries have a limited lifespan, typically 1 to 3 years. An old or faulty battery may not accept a charge, which is not an issue with the charger itself. Consider testing with a different battery if available.
- **Overheating:** If the adapter feels excessively hot, disconnect it immediately. Ensure it is used in a well-ventilated area and not covered.
- **No Power Indicator:** If your tool or battery has a charging indicator and it's not lighting up, recheck all connections.

PRODUCT SPECIFICATIONS

Brand	UPBRIGHT
Model Number	Hyper Tough 99303 12V Max Power Supply
Input Voltage	100-240VAC, 50/60Hz (Worldwide Input)
Output Voltage	13.5V DC
Output Current	400mA (0.4A)
Connector Type	Barrel Connector
Compatible Devices	Hyper Tough 12V Max 1.5Ah Li-ion Battery Cordless Drills, Impact Drivers, Work Lights (Models: 99303, 99307, 93307, 99312, 98936, 99334)
Special Features	OVP, OCP, SCP Protection (Over Voltage, Over Current, Short Circuit Protection)
Product Dimensions	4 x 3 x 2 inches
Item Weight	2.39 ounces

WARRANTY AND SUPPORT

UpBright products are designed for reliability and performance. This adapter comes with a **30-day refund policy** and a **24-month exchange warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use.

For warranty claims or technical support, please contact your retailer or the UpBright customer service directly. Ensure you have your purchase receipt and product details available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question