

[manuals.plus](#) /

› [Silvergear](#) /

› [Silvergear XL Smartwatch Instruction Manual](#)

Silveragear 8711568088660

Silveragear XL Smartwatch Instruction Manual

Model: 8711568088660

INTRODUCTION

This manual provides comprehensive instructions for the Silveragear XL Smartwatch. It covers setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device. The Silveragear XL Smartwatch features a large 2.41-inch IPS display, integrated cameras, 4G connectivity, and extensive fitness tracking capabilities.



Figure 1: Silvergear XL Smartwatch overview.

ENJOY MULTIMEDIA ENTERTAINMENT WHEREVER YOU ARE



SPORT COMPETITIONS



TV PROGRAMMES



SERIES



VIDEOS



MUSIC



WATCH THEM ON YOUR EXTRA-LARGE SCREEN!

Figure 2: The Silvergear XL Smartwatch offers a perfect balance of style, functionality, and advanced technology, including a 2.41-inch IPS display, live video streaming, app downloads, fitness tracking, and communication features.

1. SETUP

1.1 Unboxing and Package Contents

Carefully unpack your Silvergear XL Smartwatch and verify all contents.

WHAT'S IN THE BOX?



Figure 3: Package contents including the Smartwatch XL, charging base, screen protector, and two screwdrivers. Dimensions are also shown: 4.5 cm height, 6.5 cm width, 1.5 cm thickness for the watch body, and strap lengths of 8.5 cm and 12 cm. The watch weighs 120 grams.

- Silvergear XL Smartwatch
- Charging Base
- Screen Protector
- 2x Screwdrivers (for SIM card tray)
- User Manual (this document)

1.2 Charging the Smartwatch

Before first use, fully charge the smartwatch.

1. Connect the charging base to a USB power adapter (not included) or a computer's USB port.
2. Place the smartwatch onto the charging base, ensuring the charging pins align.
3. The watch display will indicate charging status. Allow approximately 2-3 hours for a full charge.

1.3 SIM Card Installation

To enable 4G connectivity, calls, and internet access, install a Nano SIM card.



Figure 4: Illustration of how to insert a Nano SIM card into the smartwatch. The image also shows the watch's ability to download apps from the Play Store.

1. Locate the SIM card tray on the side of the smartwatch.
2. Use the provided screwdriver to open the SIM card tray.
3. Carefully insert a Nano SIM card into the tray, ensuring correct orientation.
4. Close the SIM card tray securely with the screwdriver.

1.4 Initial Power On and Setup

Press and hold the power button until the Silvergear logo appears. Follow the on-screen prompts to complete the initial setup, including language selection, time zone, and network connection.

2. OPERATING THE SMARTWATCH

2.1 Basic Navigation

- **Touchscreen:** Swipe left, right, up, or down to navigate through menus and screens. Tap to select items.
- **Power Button:** Press to wake/sleep the screen. Press and hold to power on/off or restart.
- **Back Button (if applicable):** Some watches have a dedicated back button or gesture. Refer to on-screen prompts.

2.2 Communication Features

With a Nano SIM card installed, you can make and receive calls and messages directly from your smartwatch.

- **Calls:** Tap the "Phone" icon to access the dialer or contacts.
- **Messaging:** Tap the "Messaging" icon to send and receive text messages.
- **Apps:** Download communication apps from the Play Store for additional functionality.

2.3 Camera Functionality

The smartwatch is equipped with both front and side cameras for capturing photos and videos.



Figure 5: The smartwatch features a 5MP front camera and a 2MP side camera, allowing you to capture photos and videos directly from your wrist.

- **Access Camera:** Tap the "Camera" icon on the home screen or app drawer.

- **Switch Cameras:** Use the on-screen icon to switch between the 5MP front camera and the 2MP side camera.
- **Capture:** Tap the shutter button to take a photo or start/stop video recording.

2.4 Multimedia Entertainment

Enjoy videos, TV programs, series, and music directly on your smartwatch's extra-large screen.



Figure 6: The extra-large screen allows you to enjoy multimedia content such as sport competitions, TV programmes, series, videos, and music.

- **Video/TV:** Use pre-installed apps or download streaming services from the Play Store.
- **Music:** Play music stored on the device or stream from compatible apps.

2.5 Fitness and Health Tracking

Monitor your physical activity and health metrics with the integrated sensors.



Figure 7: The smartwatch offers pedometer and fitness tracking for various activities including running, hiking, cycling, basketball, football, jumping rope, and badminton.

- **Pedometer:** Tracks your daily steps, distance, and calories burned.
- **Heart Rate Monitor:** Provides accurate heart rate readings.
- **Workout Modes:** Select from 9 pre-defined exercise types (e.g., running, walking, cycling, swimming) to track your performance.
- **Sleep Tracking:** Monitors your sleep patterns (if supported by the device's software).

2.6 App Downloads

Expand your smartwatch's functionality by downloading applications from the Play Store.

- Ensure your smartwatch is connected to Wi-Fi or has an active 4G data connection.
- Tap the "Play Store" icon and browse or search for desired applications.
- Follow on-screen instructions to download and install apps.

3. MAINTENANCE

3.1 Cleaning

To maintain the appearance and functionality of your smartwatch:

- Wipe the screen and body with a soft, lint-free cloth.
- For stubborn marks, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.
- Ensure the charging contacts are clean and dry before charging.

3.2 Water and Dust Resistance

The Silvergear XL Smartwatch is rated IP67 for water and dust resistance.



Figure 8: The smartwatch is IP67 water- and dustproof, designed to withstand various weather conditions. This includes IP67 splashproof and IP67 dustproof ratings.

- **IP67 Rating:** This means the device is protected from dust ingress and can withstand immersion in water up to 1 meter for up to 30 minutes.
- It is suitable for splashes, rain, and incidental exposure to water.
- Avoid prolonged immersion, hot water, or high-pressure water jets.
- Ensure the SIM card tray is properly sealed to maintain water resistance.

3.3 Software Updates

Periodically check for software updates to ensure optimal performance and access to new features.

- Connect your smartwatch to Wi-Fi.
- Navigate to "Settings" > "About Watch" > "Software Update" (or similar path).
- Follow on-screen instructions to download and install any available updates.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Smartwatch does not power on.	Low battery; device frozen.	Charge the device for at least 30 minutes. Press and hold the power button for 10-15 seconds to force restart.
Cannot make/receive calls.	No SIM card; SIM card not properly inserted; no network signal; incorrect network settings.	Ensure SIM card is correctly installed and activated. Check network signal strength. Verify network settings in the smartwatch.
Screen is unresponsive.	Software glitch; screen protector interference.	Restart the smartwatch. Remove and reapply the screen protector if it's causing issues.
Fitness tracking data is inaccurate.	Improper fit; sensor obstruction; software calibration needed.	Ensure the watch is worn snugly on your wrist. Clean the sensor area. Check for software updates.
Cannot connect to Wi-Fi.	Incorrect password; out of range; router issue.	Verify Wi-Fi password. Move closer to the Wi-Fi router. Restart the router.

If you encounter issues not listed here, or if the suggested solutions do not resolve the problem, please refer to the support section.

5. SPECIFICATIONS

Below are the technical specifications for the Silvergear XL Smartwatch (Model: 8711568088660).

REVOLUTIONARY FITNESS AND ENTERTAINMENT WATCH WITH SMART FEATURES AND XL SCREEN



ANDROID 7.1.1



MT6739 QUAD-CORE
CPU, 1.5 GHZ



2.41-INCH
FULL SCREEN



640X480
RESOLUTION



4G & WIFI



Figure 9: Key technical specifications of the Silvergear XL Smartwatch, including Android 7.1.1 OS, MT6739 Quad-Core CPU (1.5 GHz), 2.41-inch full screen, 640x480 resolution, and 4G & WiFi connectivity.

Feature	Detail
Brand	Silveragear
Model Number	8711568088660
Operating System	Android (version 7.1.1 from image)
Screen Size	2.41 Inches
Display Type	LCD (IPS from description)
Resolution	640x480 (from image)
Processor	MT6739 Quad-Core CPU, 1.5 GHz (from image)
Connectivity	4G, Wi-Fi

Feature	Detail
Front Camera	5 Megapixels
Side Camera	2 Megapixels
Memory Storage Capacity	500 MB
Water & Dust Resistance	IP67
GPS	No GPS
Compatible Devices	Smartphone

6. WARRANTY INFORMATION

The Silvergear XL Smartwatch comes with a manufacturer's warranty.

- **Manufacturer Warranty:** 2 years.
- This warranty covers defects in materials and workmanship under normal use.
- It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
- Please retain your proof of purchase for warranty claims.

7. SUPPORT

For further assistance, technical support, or warranty claims, please contact Silvergear customer service.

- Refer to the Silvergear official website for contact details.
- Have your product model number (8711568088660) and proof of purchase ready when contacting support.