

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GETPRO](#) /

> [GETPRO 32x19 Inch Fireclay Kitchen Sink Instruction Manual \(Model E-R271910\)](#)

GETPRO E-R271910

GETPRO 32x19 Inch Fireclay Kitchen Sink

Model: E-R271910 - Instruction Manual

INTRODUCTION

Thank you for choosing the GETPRO 32x19 inch Fireclay Kitchen Sink. This manual provides essential information for the proper installation, operation, and maintenance of your new sink. Please read these instructions carefully before beginning installation or use to ensure optimal performance and longevity of your product.

Key Features:

- **Premium Fireclay Construction:** Made from 100% fine fireclay and imported Italian enamel, ensuring extreme durability, density, and a smooth, non-porous, high-gloss surface.
- **Dual Mount Design:** Versatile installation options for both top-mount (drop-in) and under-mount configurations, compatible with various countertop materials.
- **Exceptional Durability:** Resistant to high temperatures, damage, acids, and common household chemicals, preventing cracks and breaks.
- **Deep Single Bowl:** A 10-inch deep basin provides ample space for washing large pots and pans, minimizing splashes.
- **Included Accessories:** Comes with a custom 304 stainless steel bottom grid and a kitchen sink drain strainer.

100%

NATURAL TRUE FINE
FIRECLAY SINK



HIGHLY DURABILITY

Extremely hard fireclay porcelain enamel surface is virtually indestructible and highly resistant to chips, scratches, impact & stains.

BAKED AT 2400°F



Double-fired at high temperatures of 2400F for superior durability, resulting in an ultra hard high-gloss finish that stands up to heavy use

ITALIAN GLAZE

Elegant matt black with ultra-durable & non-fade color finish with a perfectly smooth surface is your smart choice for the kitchen remodel.





Image: Illustration detailing the 100% natural true fine fireclay construction and high-temperature baking process.

PACKAGE CONTENTS

Please verify that all components are present before proceeding with installation.

- GETPRO 32x19 Inch Fireclay Kitchen Sink
- 304 Stainless Steel Bottom Grid
- Kitchen Sink Drain Strainer

DESIGN FOR EASY DRAINING



**With a Gently Sloped Bottom
Fast Draining Without Water Pouring**

QUICK DRAIN TECHNOLOGY

Image: Contents of the GETPRO kitchen sink package, including the fireclay sink, bottom grid, and drain strainer.

SPECIFICATIONS

Brand	GETPRO
Model Number	E-R271910
Dimensions (L x W x H)	32 x 19 x 10 inches (81.28 x 48.26 x 25.4 cm)
Material	Fireclay
Color	White
Style	Single Bowl
Finish	Glossy White
Installation Method	Top-Mount or Under-Mount

Number of Faucet Holes	1
Included Components	Fireclay Sink, Stainless Steel Bottom Grid, Kitchen Sink Drain Strainer
Weight	31.3 kg (approximately 69 lbs)



Image: Detailed dimensions for the GETPRO 32x19 inch fireclay kitchen sink, showing inner and outer measurements, and recommended cutout sizes for installation.

INSTALLATION INSTRUCTIONS

The GETPRO fireclay sink offers both top-mount (drop-in) and under-mount installation options. Due to the significant weight of the fireclay sink (approximately 69 lbs), it is recommended to have assistance during handling and installation.

1. Prepare the Countertop Cutout:

- For **Top-Mount Installation**: The recommended rough countertop opening dimensions are approximately 31 7/8" x 19 1/8". The sink's 1.5-inch wide mounting rim supports its weight on the existing cutout.

- For **Under-Mount Installation**: The recommended rough countertop opening dimensions are approximately 29" x 15 15/16".
- Always measure the actual sink to ensure a perfect cutout before making any modifications to your countertop. Refer to the "Specifications" section and accompanying dimension image for precise measurements.

2. Position the Sink:

- Carefully lower the sink into the prepared cutout. Ensure it is centered and level.
- For under-mount installations, secure the sink to the underside of the countertop using appropriate mounting clips and silicone sealant (not included).
- For top-mount installations, apply a bead of silicone sealant around the edge of the cutout before dropping the sink in, then press firmly into place.

3. Connect Plumbing:

- Install the included drain strainer into the sink's drain opening.
- Connect the plumbing according to local codes and manufacturer's instructions for your faucet and garbage disposal (if applicable). The sink is compatible with all standard garbage disposal units.
- Ensure all connections are watertight.

DUAL MOUNT DESIGN WITH THICK MOUNT DECK

Choose your favor style to match your kitchen

Undermount Installation

Drop In Installation



Thoughtful dual mount design offers both topmount and undermount installation to meet all materials and style of countertop. Thick mount deck, Ideal for remodeling, it supports the weight of fireclay sink for easy installation into an existing countertop cutout.

Image: Visual comparison of under-mount and top-mount sink installations.

OPERATION

Your GETPRO fireclay sink is designed for daily kitchen tasks with convenience and durability in mind.

Daily Use:

- The 10-inch deep single bowl provides ample capacity for washing dishes, pots, and pans without splashing.
- The included stainless steel bottom grid helps protect the sink's surface from scratches and impacts, and allows for better drainage.
- The sink's design features a gently sloped bottom for efficient water drainage, preventing water pooling.
- It is compatible with standard garbage disposal units for convenient waste management.




Image: Illustration of the extra-deep bowl design and garbage disposal compatibility.

PREMIUM QUALITY DESIGN


GETPRO®



Scratch Resistant



Anti-Osmosis



Easy Clean



Heat Resistant

Image: Diagram illustrating the quick drain technology with a gently sloped bottom.

CARE AND MAINTENANCE

Proper care will ensure your GETPRO fireclay sink maintains its pristine appearance and functionality for many years.

Cleaning:

- **Daily Cleaning:** Wipe the sink clean with a soft cloth or sponge and mild dish soap after each use. Rinse thoroughly with water.
- **Stain Removal:** For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic or fireclay sinks. Avoid harsh chemicals, abrasive pads, or steel wool, as these can damage the enamel surface.
- **Preventing Water Spots:** Dry the sink after use to prevent mineral deposits and water spots, especially in hard water areas.
- **Bottom Grid Care:** Regularly clean the stainless steel bottom grid to prevent food buildup and maintain hygiene.

General Care:

- Avoid dropping heavy or sharp objects into the sink, which could cause chips or cracks, despite its durability.
- Do not use the sink as a cutting surface.
- The fireclay material is resistant to high temperatures, but avoid placing extremely hot items directly on the surface for prolonged periods without protection.



STAIN RESISTANT

Ultra-smooth surface resists dirt and grime, is extremely easy to clean



REVERSIBLE FRONT

Both front and back side are classic flat. The timeless design allows front and back convertible. Easy for installation.



HIGH-GLOSS PORCELAIN GLAZE

Indestructible enamel finish easily stands up to heavy use



HEAT RESISTANT

Up to 300F and resists thermal shock and temperature fluctuations



SCRATCH RESISTANT

Advanced glazing technology offers unmatched protection from scratching and chipping



NO CRAZING

Ultra-fine fireclay prevents yellowing and crazing (hairline surface cracks)

Image: Visual representation of the sink's premium quality design features, including scratch resistance, anti-osmosis, easy cleaning, and heat resistance.

TROUBLESHOOTING

This section addresses common issues you might encounter with your GETPRO fireclay sink.

Problem	Possible Cause	Solution
Slow Drainage	Food debris or grease buildup in the drain.	Remove the drain strainer and clean any visible debris. Use a plumbing snake or a natural drain cleaner if necessary. Avoid harsh chemical drain cleaners.

Water Spots/Mineral Buildup	Hard water evaporation leaving mineral deposits.	Wipe the sink dry after each use. For existing spots, use a solution of white vinegar and water (1:1 ratio) or a specialized hard water stain remover. Rinse thoroughly.
Minor Scratches/Scuff Marks	Metal utensils or pots rubbing against the surface.	While highly scratch-resistant, minor marks can occur. Use a non-abrasive cleaner and a soft cloth to gently buff out the marks. Ensure the bottom grid is always in place during use.
Chipping/Cracking	Impact from heavy objects.	Fireclay is extremely durable, but not indestructible. Avoid dropping heavy items into the sink. If damage occurs, contact customer support for repair options or warranty claims.

WARRANTY INFORMATION

GETPRO provides a **3-year warranty** for this fireclay kitchen sink. This warranty covers manufacturing defects. If you receive a fireclay kitchen sink with any defects, GETPRO will send a new kitchen sink free of charge. Please retain your proof of purchase for warranty claims. The warranty does not cover damage resulting from improper installation, misuse, abuse, accident, or normal wear and tear.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your GETPRO fireclay kitchen sink, please contact our customer support team.

Please refer to the contact details provided on the GETPRO official website or your purchase documentation for the most current support information.

Our team is dedicated to providing excellent service and support.