

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Briloner](#) /

› [BRILONER LED Ceiling Light 78cm \(On/Off, 4000K Neutral White\) Instruction Manual](#)

Briloner 78cm On/Off LED Ceiling Light (B0CB8THFVV)

BRILONER LED Ceiling Light 78cm

Model: 78cm On/Off LED Ceiling Light (B0CB8THFVV)

INTRODUCTION

Thank you for choosing the BRILONER LED Ceiling Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.



Image: The BRILONER LED Ceiling Light, highlighting its neutral white 4000K color temperature and IP44 splash protection rating.

This LED ceiling light is designed for various indoor environments, including bathrooms, offices, kitchens, hallways, basements, and living rooms, thanks to its IP44 protection against splashing water.

SAFETY INFORMATION

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Always disconnect power at the main circuit breaker before installation or maintenance.
- **IP44 Rating:** This fixture is protected against splashing water (IP44) and is suitable for damp locations like bathrooms. However, it is not submersible.
- **Light Source:** This product contains a light source of energy efficiency class F. The light source is not user-replaceable.
- **Handling:** Handle the fixture with care to avoid damage to the glass or internal components.
- **Disposal:** Dispose of the product responsibly at the end of its life cycle, following local regulations for electronic waste.

SETUP AND INSTALLATION

Follow these steps for safe and correct installation of your BRILONER LED Ceiling Light.

1. **Preparation:** Ensure the power supply to the installation area is switched off at the main circuit breaker. Gather necessary tools (screwdriver, drill, wire strippers, etc.).
2. **Mounting Location:** Choose a suitable location on the ceiling, ensuring it can support the weight of the fixture and is free from obstructions.
3. **Mounting Bracket:** Attach the mounting bracket to the ceiling using appropriate screws and wall plugs. Ensure it is securely fastened.
4. **Wiring:** Connect the electrical wires from the ceiling to the terminal block on the fixture. Ensure correct polarity (Live, Neutral, Earth) as indicated on the fixture. Double-check all connections for tightness.
5. **Attach Fixture:** Carefully attach the LED ceiling light to the mounting bracket, securing it with the provided screws. Ensure no wires are pinched.
6. **Final Check:** Once the fixture is securely mounted and wired, restore power at the main circuit breaker.



Image: The BRILONER LED Ceiling Light installed in a bathroom, demonstrating its suitability for damp environments.

OPERATING INSTRUCTIONS

This BRILONER LED Ceiling Light features a simple On/Off operation.

- **Switching On/Off:** Use your standard wall switch to turn the light fixture on or off.
- **Light Output:** The fixture provides a consistent 2800 lumens of neutral white light (4000K) when switched on.



Image: The BRILONER LED Ceiling Light providing uniform illumination in a dining room setting.

MAINTENANCE

To ensure the longevity and optimal performance of your LED ceiling light, follow these maintenance guidelines:

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or electrical components.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician.

- **Light Source:** The integrated LED light source is designed for a long lifespan and is not replaceable by the user. Do not attempt to open the sealed light unit.

TROUBLESHOOTING

If you encounter any issues with your BRILONER LED Ceiling Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply; loose wiring; faulty switch.	Check circuit breaker. Ensure all wiring connections are secure. Test the wall switch. If problem persists, consult an electrician.
Light flickers.	Loose wiring; incompatible switch (if dimmer was used, though this model is On/Off).	Check wiring connections. Ensure the fixture is connected to a standard On/Off switch.
Light is dim.	Not applicable for this On/Off model; fixture is designed for full brightness.	Ensure the fixture is not connected to a dimmer switch. If light is unexpectedly dim, consult an electrician.

If troubleshooting steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Briloner
Model	78cm On/Off LED Ceiling Light (B0CB8THFVV)
Dimensions (L x W x H)	780 x 180 x 65 mm
Power Consumption	25 Watts
Luminous Flux	2800 Lumens
Color Temperature	4000K (Neutral White)
IP Protection Class	IP44 (Splash-proof)
Material	Glass
Style	On/Off
Energy Efficiency Class	F



Image: Technical drawing illustrating the dimensions of the ceiling light.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Briloner website. Keep your proof of purchase for warranty claims.

Briloner Website: [Visit Briloner Store on Amazon](#)