

## uutensil Stirr Plus

# Uutensil Stirr Plus Automatic Pan Stirrer Instruction Manual

Model: Stirr Plus

## 1. SAFETY INFORMATION

Please read all instructions carefully before using the Uutensil Stirr Plus. Retain this manual for future reference.

- **Heat Resistance:** The removable nylon legs are heat-resistant up to 120°C (248°F). Do not expose the main unit to temperatures exceeding this limit.
- **Pan Compatibility:** Safe for use with non-stick pans and pots. Ensure the stirrer fits securely within your cookware before operation.
- **Supervision:** While designed for hands-free operation, it is recommended to monitor the stirrer, especially when cooking delicate or thick mixtures, to prevent burning or overflow.
- **Charging:** Use only the provided USB charging cradle and cable. Do not attempt to charge the unit with other chargers.
- **Cleaning:** Always remove the main unit from the stirring legs before cleaning. The stirring legs are dishwasher safe. The main unit should be wiped clean with a damp cloth. Do not immerse the main unit in water.
- **Battery:** Contains 1 Lithium Ion battery. Do not attempt to replace the battery yourself.

## 2. PRODUCT OVERVIEW

The Uutensil Stirr Plus is an automatic pan stirrer designed to simplify cooking by providing hands-free stirring for various dishes.

### Components:

- Main Stirring Unit (with integrated controls and battery)
- Removable Nylon Stirring Legs

- USB Charging Cradle
- USB Charging Cable




Image: The Uutensil Stirr Plus main unit and its USB charging stand.



Image: The main stirring unit detached from the removable nylon stirring legs.

## 3. SETUP

### 3.1 Assembly

1. Align the main stirring unit with the top opening of the nylon stirring legs.
2. Gently push the main unit down until it clicks securely into place. Ensure it is firmly attached before use.

### 3.2 Charging

The Stirr Plus features a rechargeable Lithium Ion battery. A full charge takes approximately 2 hours and provides up to 4 hours of continuous stirring.

1. Connect the USB charging cable to the charging cradle and a suitable USB power source.
2. Place the main stirring unit (detached from the legs) onto the charging cradle. Ensure the pins align for proper contact.
3. The indicator lights on the main unit will show charging status.



Image: The main stirring unit placed on its USB charging cradle.

## 4. OPERATING INSTRUCTIONS

---

The Utensil Stirr Plus is designed for hands-free stirring of soups, sauces, porridge, gravy, and other liquid to semi-liquid mixtures.

1. **Placement:** Place the assembled stirrer directly into your pot or pan, ensuring the stirring legs rest on the bottom of the cookware.
2. **Power On/Speed Selection:** Press the power button on top of the main unit once to turn it on. The stirrer will begin rotating at the lowest speed. Press the button again to cycle through the three available speed options (low, medium, high).
3. **Automatic Rotation:** The stirrer will automatically rotate and change direction as it encounters the edges of the pan, ensuring even stirring.
4. **Timer Function:** The integrated timer allows you to set stirring durations from 1 to 10 minutes. Refer to the product packaging or a detailed user guide for specific timer setting instructions, as this feature is activated via the main unit's controls. A gentle pulse and flashing lights indicate when the pre-set time is complete.
5. **Power Off:** Press and hold the power button to turn off the stirrer.





Image: The Utensil Stirr Plus in operation, stirring contents within a pot on a stovetop.



Image: Close-up of the Uutensil Stirr Plus actively stirring a mixture in a small pot.

## Official Product Video:

Your browser does not support the video tag.

Video: Demonstrates the Uutensil Stirr Plus in action, showing its hands-free stirring, charging process, and ease of cleaning. This video is provided by the seller.

## 5. CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your Uutensil Stirr Plus.

1. **Disassembly:** After use, turn off the stirrer and carefully remove the main stirring unit from the nylon legs.

2. **Stirring Legs:** The nylon stirring legs are food and dishwasher safe. Rinse off any food residue and place them in the dishwasher or wash by hand with warm, soapy water.
3. **Main Unit:** The main stirring unit is not waterproof. Wipe it clean with a damp cloth. Do not immerse it in water or place it in a dishwasher.
4. **Storage:** Store the stirrer and charging cradle in a clean, dry place when not in use.



Image: The three-legged design of the stirring unit, which is removable for cleaning.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stirrer does not turn on.	Battery is depleted.	Charge the main stirring unit using the USB charging cradle. Ensure proper connection.
Stirrer vibrates but does not rotate.	Stirring legs not properly attached or obstruction.	Ensure the stirring legs are securely clicked into the main unit. Check for any food particles or debris obstructing the rotation mechanism.
Stirrer struggles with contents or stops.	Mixture is too thick or pan is too small.	The Stirr Plus is best suited for liquid to semi-liquid mixtures. For very thick sauces, manual stirring may be required. Ensure the pan size allows for free movement of the stirrer.
Stirrer turns on by itself (unintended operation).	Possible internal malfunction.	If the unit exhibits unintended operation, discontinue use and contact customer support.

## 7. SPECIFICATIONS

- **Model:** Stirr Plus
- **Brand:** Uutensil
- **Product Dimensions (Stirrer without stand):** 9.5 x 4.72 inches (height x diameter)
- **Overall Product Dimensions:** 4.92 x 4.92 x 9.25 inches
- **Item Weight:** 4.8 ounces
- **Battery:** 1 Lithium Ion battery (rechargeable)
- **Charging Time:** Approximately 2 hours
- **Operating Time:** Up to 4 hours of continuous stirring per charge
- **Heat Resistance (Legs):** Up to 120°C (248°F)
- **Speeds:** 3 adjustable speeds
- **Timer:** 1 to 10 minutes

## 8. WARRANTY AND SUPPORT

---

For warranty information, technical support, or to inquire about replacement parts, please refer to the contact information provided on your product packaging or visit the official Uutensil website.

**Manufacturer:** Uutensil