

[Manuals.plus](#) /

› [Norelco](#) /

› Philips Norelco OneBlade 360 Hybrid Electric Trimmer & Shaver Instruction Manual

Norelco OneBlade 360 Face


Philips Norelco OneBlade 360 Hybrid Electric Trimmer & Shaver Instruction Manual

Model: OneBlade 360 Face

INTRODUCTION

The Philips Norelco OneBlade 360 is a revolutionary electric grooming device designed for men who maintain facial styles, beards, or stubble. Its unique dual-protection system, featuring a glide coating combined with rounded tips, ensures a comfortable and easy shaving experience. The fast-moving cutter operates at 12,000x per minute, making it efficient even on longer hairs. The innovative 360 Blade flexes in all directions to adapt to the contours of your face, maintaining constant skin contact and control for effortless trimming and shaving of hard-to-reach areas with fewer strokes.

Unique OneBlade technology



**Fast moving cutter
moves 12000x
per minute**

**Glide coating
and rounded tips
protect skin**

Image: Unique OneBlade technology with fast-moving cutter and protective glide coating.

Innovative 360 blade

moves in
all directions
and adjusts
to every curve
of your face

Image: Innovative 360 blade designed to flex in all directions for constant skin contact.

WHAT'S IN THE BOX

Your Philips Norelco OneBlade 360 package includes the following components:

- 1 Trimmer Handle
- 3 Stainless Steel 360 Blades
- 1 5-in-1 Adjustable Comb
- 1 USB-A Charging Cable (wall power adapter not included)

Stainless steel blades stay sharp for up to 4 months*



*Based on 2 full shaves on face per week. Actual results may vary.

Image: The Philips Norelco OneBlade 360 bundle, showing the trimmer, blades, comb, and charging cable.

SETUP

Charging the Device

Before first use, fully charge your OneBlade 360. Connect the USB-A charging cable to the device and a compatible USB wall adapter (not included). A full charge takes approximately 8 hours and provides 45 minutes of continuous shaving power.

Rechargeable power



**Rechargeable
battery**



**45 minutes
run time**



Image: The OneBlade 360 being charged via its USB cable.

Attaching and Changing Blades

To attach a blade, align the blade with the handle and push until it clicks into place. To remove, simply push the blade away from the handle. An eject icon will appear on the blade when it's time to consider changing it for optimal performance, typically every 4 months with average use.

Attaching the Adjustable Comb

The 5-in-1 adjustable comb can be easily attached to the blade for trimming different hair lengths. Simply slide the comb over the blade until it securely clicks. Adjust the desired length using the integrated mechanism on the comb.

5-length Adjustable comb



Image: Attaching the 5-length adjustable comb to the OneBlade 360.

OPERATING INSTRUCTIONS

The Philips Norelco OneBlade 360 is versatile for trimming, edging, and shaving any length of hair on your face.

Trimming

Attach the 5-in-1 adjustable comb to trim your beard to your preferred length. The open comb design prevents clogging, even with long and thick hair. Move the OneBlade against the direction of hair growth for an even trim.

Edging

Use the dual-sided blade without the comb to create precise edges and sharp lines. You can shave in either direction to achieve great visibility and ensure every hair is cut, allowing you to line up your style in seconds.

Shaving

For a clean shave, use the blade directly on your skin. The OneBlade 360 is designed not to shave as close as a traditional blade, which helps keep your skin comfortable and prevents irritation. Move the blade against the grain for effective hair removal.

For Face: Trim, edge or shave any length of hair



Image: Demonstrating trimming, edging, and shaving techniques with the OneBlade 360.

Wet or Dry Use

The OneBlade 360 is fully waterproof, allowing for convenient wet or dry shaving. You can use it with or without shaving foam, and it's safe for use in the shower.



**100%
waterproof and
easy to clean:**



Just rinse under the tap



**Shave dry, with foam,
or in the shower**

Image: The OneBlade 360 is 100% waterproof and easy to clean under running water.

MAINTENANCE

Cleaning

After each use, rinse the OneBlade 360 under running water to remove hair and debris. Its waterproof design makes cleaning simple and hygienic.

Blade Replacement

For optimal performance and hygiene, replace the Stainless Steel 360 Blade every 4 months. An eject icon will appear on the blade itself to indicate when it's time for a replacement.

TROUBLESHOOTING

Reduced Performance or Pulling Hair

If you notice the device is pulling hair or not providing a clean shave, it's likely time to replace the blade. Check for the eject icon on the blade as an indicator. Ensure the device is fully charged before use.

Charging Issues

If the device is not charging, ensure the USB-A cable is securely connected to both the OneBlade and a functioning USB wall adapter. Verify the power outlet is active.

SPECIFICATIONS

Manufacturer	Philips Norelco
Model Name	Philips Norelco OneBlade Face
Recommended Uses	Beard, Face, Mustache, Sideburns
Included Components	Trimmer Handle, 3 Stainless Steel 360 Blades, 5-in-1 Comb, USB-A Charging Cable
Additional Features	Waterproof
Power Source	Battery Powered
Battery Average Life	45 minutes
Head Type	Hybrid
Number of Blades	1 (dual-sided)
Color	Black & Lime Green
Blade Material	Stainless Steel

SAFETY INFORMATION

Please observe the following safety guidelines to ensure safe and effective use of your Philips Norelco OneBlade 360:

- Always keep the device away from water while charging.
- Change the blade every 4 months for optimal safety and performance.
- Be cautious when using the dual-sided blade to avoid cuts.

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts and accessories, please visit the official Philips Norelco website or contact customer service. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CB9HMXV4>

More documents and user manuals: **<https://manuals.plus/>**