



Manuals.plus /

› Homemate /

› Homemate Heated Blanket Electric Throw - 50"x60" Heating Blanket User Manual

Homemate YZH-5060T

Homemate Heated Blanket Electric Throw User Manual

Model: YZH-5060T

INTRODUCTION

Welcome to your new Homemate Heated Blanket Electric Throw. This manual provides essential information for safe and effective use, setup, operation, and maintenance of your blanket. Please read it thoroughly before first use and keep it for future reference.



The Homemate Heated Blanket Electric Throw, featuring a grey geometric pattern, draped over a chair in a cozy setting.

IMPORTANT SAFETY INFORMATION

Your safety is paramount. The Homemate Heated Blanket is designed with multiple safety features to ensure a secure and comfortable experience.

- Homemate Electric blankets have passed the American safety UL964 Test and hold ETL Certification.
- Features lower Electro Magnetic Radiation for user well-being.
- The heating wire is designed and produced by a Japanese company, ensuring advanced technology, stronger insulation, and flame resistance.
- Utilizes NTC overheating protection technology to prevent overheating and potential burning.
- Equipped with a 10-hour auto shut-off feature for enhanced safety.



Visual representation of safety certifications including UL964 Test Authentication, ETL Certification, and NTC Over-Heated Protection.

FULLY AND SOFT HEATED BLANKET WARM YOUR BODY



WORKING



BED



SOFA



Diagram illustrating the internal layers of the heating wire, including heating wire, resin detection layer, double temperature detection line, plastic film layer, and PVC folding protective layer, ensuring safety and durability.

SETUP

Follow these steps to set up your heated blanket for first use:

1. Unroll the blanket and lay it flat on your desired surface (bed, sofa, etc.).
2. Locate the connection port on the blanket and the detachable controller cord.
3. Securely connect the controller cord to the blanket's connection port.
4. Plug the power cord into a standard electrical outlet. Ensure the blanket is completely dry before plugging it in.



Close-up of the detachable controller cord connecting to the Homemate Heated Blanket.

OPERATING INSTRUCTIONS

Learn how to control the warmth and timing of your Homemate Heated Blanket.

Power On/Off

- To turn on the blanket, press the power button on the controller. The display will illuminate.
- To turn off, press the power button again.

Adjusting Heat Levels

- The blanket offers 10 fast heat levels, ranging from 86°F to 122°F.
- Use the "TEMP" buttons on the controller to increase or decrease the heat level to your desired warmth.


Setting the Auto-Off Timer

- The blanket features an 8-hour auto-off function for safety and energy saving.
- Use the "TIME" button to cycle through available timer settings (e.g., 1, 2, 3 hours). The blanket will automatically turn off after the selected duration.



Detailed view of the Homemate blanket controller, showing the digital display for heat levels and timer settings, along with temperature and time control buttons.

Choose Homemate SAFE & RELIABLE



The Homemate Heated Blanket laid out on a bed, with the controller visible, ready for use.

Official product video demonstrating the features and use of the Homemate Heated Electric Blanket Throw, including its soft material and controller functions.

MAINTENANCE

Proper care will extend the life of your heated blanket.

Washing Instructions


- Always ensure the controller cord is detached from the blanket before washing.
- Machine wash the blanket on a gentle cycle with cold water.
- For drying, air-dry the blanket or tumble dry on a low temperature setting.
- Do not plug in the blanket until it is completely dry to prevent damage.

200GSM Soft Flannel Surface

Non-Woven Fabric

Fast Heating Wires

180GSM Cozy Sherpa Back



UL964 TEST AUTHENTICATION



ETL CERTIFICATION



5-YEAR WARRANTY



NTC OVER-HEATED PROTECTION

The Homemate Heated Blanket being placed into a washing machine, illustrating its machine-washable feature.

TROUBLESHOOTING

If you encounter any issues with your Homemate Heated Blanket, please refer to the following common solutions:

- **Blanket not heating:** Ensure the controller is securely connected to the blanket and the power cord is properly plugged into a working electrical outlet. Check the selected heat level setting on the controller.
- **Automatic shut-off:** The blanket has an 8-hour auto-off safety feature. If it turns off unexpectedly, verify the timer setting on the controller.
- **Unusual odors:** A slight smell may be present upon initial unboxing, which should dissipate quickly. If persistent or strong odors occur, discontinue use and contact customer support.
- **Power issues:** If the blanket stops working, ensure all connections are secure and the power source is active. If issues persist after checking these points, refer to the warranty information for further assistance.

SPECIFICATIONS

Material	220gsm Double-sided Flannel
Color	Grey Geometry
Product Dimensions	50"L x 60"W
Item Model Number	YZH-5060T
Item Weight	3.25 pounds
Heat Levels	10
Auto-Off Timer	8 hours
Temperature Range	86-122°F
Certifications	ETL, UL964

WARRANTY AND SUPPORT

The Homemate Heated Blanket Electric Throw comes with a 1-year warranty. For any product inquiries, technical support, or warranty claims, please contact Homemate customer service through the official channels provided at the time of purchase.

10 Heating Levels

116°F

83°F

FAST HEATING

We are really happy to warm you in this cold winter

Time	homemate (°F)	others (°F)
0	50	50
10min	106	65
20min	113	75
30min	113	80
40min	113	80

A woman comfortably sleeping under the Homemate Heated Blanket on a bed, highlighting its cozy and warm features for restful sleep.