

## EDISHINE B0CBC2VYLK

# EDISHINE 120V LED Outdoor Spotlight Instruction Manual

Model: B0CBC2VYLK

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your EDISHINE 120V LED Outdoor Spotlight. This versatile landscape light is designed to enhance outdoor spaces with bright, adjustable illumination and includes five interchangeable color lenses for various decorative applications. Please read these instructions thoroughly before installation and operation.



Image 1: EDISHINE 120V LED Outdoor Spotlight with included color lenses.

## 2. SAFETY INSTRUCTIONS

- **Electrical Safety:** Ensure the power source is 120V AC. Always plug the spotlight into a Ground Fault Circuit Interrupter (GFCI) protected outlet to prevent electrical shock. Do not modify the plug or power cord.
- **Outdoor Use:** This product is rated IP65 waterproof, suitable for outdoor use in various weather conditions. However, avoid submerging the unit in water.
- **Installation:** Install the spotlight securely in the ground using the provided stake. Ensure the power

cord is routed safely to prevent tripping hazards or damage.

- **Maintenance:** Disconnect power before performing any maintenance or changing lenses. Do not attempt to open or repair the unit yourself; contact qualified personnel.
- **Heat:** The LED light may become warm during operation. Avoid touching the light source directly when in use.
- **Children and Pets:** Keep the spotlight and its components out of reach of children and pets.

### 3. PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- EDISHINE 120V LED Outdoor Spotlight (Green)
- Ground Stake
- 5 Extra Color Lenses (Red, Green, Yellow, Blue, Purple)
- 5ft Power Cord (attached)

## 5 Extra Lenses for All Holiday Scenes



Image 2: Included color lenses for the spotlight.

### 4. SETUP INSTRUCTIONS

#### 1. Attach the Ground Stake:

Align the ground stake with the base of the spotlight. Use the provided screw and nut to securely connect the ground stake to the spotlight. Ensure it is tightened firmly.



Image 3: Attaching the ground stake.

## 2. Insert into Ground:

Once assembled, firmly insert the ground stake into the desired outdoor location. Use the footrest on the stake to apply pressure and push it into the soil until stable.



Image 4: Inserting the spotlight into the ground.

## 3. Adjust Lighting Angle:

The spotlight features a 180° adjustable head. Loosen the nut on the side of the spotlight, adjust the light to your preferred angle, and then tighten the nut to secure it in place.



Image 5: Adjusting the spotlight angle.

## 4. Connect to Power:

Plug the 5ft power cord into a 120V AC GFCI-protected outdoor electrical outlet. Ensure the connection is secure and protected from moisture.

# Heavy Duty Longer Cord

5ft SJTW 16/2C heavy duty extension cord gives more choices to place it



Image 6: Spotlight with its 5ft power cord.

## 5. OPERATING INSTRUCTIONS

### 5.1 Changing Color Lenses

The EDISHINE spotlight comes with five interchangeable color lenses to customize your lighting effects. To change a lens:

1. Ensure the spotlight is unplugged from the power source.
2. Gently twist the front shell of the spotlight counter-clockwise to open it.
3. Remove the existing lens (if any) and insert your desired color lens (Red, Green, Yellow, Blue, or Purple).
4. Twist the front shell clockwise to securely close it.
5. Plug the spotlight back into the GFCI-protected outlet.

## 5 Extra Lenses for All Holiday Scenes



Image 7: Available color lenses for customization.

### 5.2 General Operation

- The spotlight provides a 5000K bright white light by default without any color lens.
- Use the 180° adjustable head to direct the light precisely where needed for optimal landscape or decorative illumination.
- The unit is designed for continuous outdoor operation once plugged in.

## 6. MAINTENANCE

- **Cleaning:** Periodically clean the lens and exterior casing with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the unit is unplugged before cleaning.

- **Inspection:** Regularly inspect the power cord for any signs of damage, fraying, or wear. Check the plug for corrosion. If any damage is found, discontinue use and replace the unit.
- **Secure Installation:** Ensure the ground stake remains firmly planted and the spotlight is securely attached to prevent accidental dislodgement.
- **Storage:** If storing the spotlight for an extended period, unplug it, clean it, and store it in a cool, dry place away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Spotlight does not turn on.	No power to the outlet; loose connection; damaged cord/plug.	Check if the outlet is working (test with another device). Ensure the plug is fully inserted. Inspect the cord for damage. Reset GFCI if tripped.
Light is dim or flickers.	Unstable power supply; internal component issue.	Ensure stable power. If problem persists, discontinue use and contact customer support.
Color lens not sitting correctly.	Lens improperly inserted; front shell not fully closed.	Unplug, reopen the front shell, re-seat the color lens, and twist the shell clockwise until secure.
Spotlight falls over easily.	Stake not fully inserted; loose connection between stake and spotlight.	Push the stake deeper into the ground. Ensure the screw connecting the stake and spotlight is tightened.

## 8. SPECIFICATIONS

Feature	Detail
Brand	EDISHINE
Model	B0CBC2VYLK
Voltage	120 Volts
Wattage	4.8 Watts
Light Source Type	LED
Color Temperature	5000 Kelvin
Beam Angle	180 Degrees (Adjustable)
Material	Plastic
Finish Type	Brushed
Waterproof Rating	IP65

<b>Feature</b>	<b>Detail</b>
Power Source	Corded Electric
Product Dimensions	7.28"L x 4.41"W x 3.5"H
Item Weight	11.3 ounces
Included Components	Spotlight, Ground Stake, 5 Color Lenses

## **9. WARRANTY AND SUPPORT**

---

For warranty information or technical support, please refer to the product packaging or contact EDISHINE customer service directly. Keep your purchase receipt for warranty claims.