

TIMBER RIDGE 2b85f926-c98b-42e8-91b3-35646597e8b6

TIMBER RIDGE Outdoor Reclining Patio and Zero Gravity Lounge Chairs Instruction Manual

Model: 2b85f926-c98b-42e8-91b3-35646597e8b6

1. INTRODUCTION

Thank you for choosing the TIMBER RIDGE Outdoor Reclining Patio Chair XL and the 33-inch Wide XXL Zero Gravity Reclining Lounge Chair. This manual provides essential information for the safe and effective use, setup, and maintenance of your new outdoor chairs. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

WARNING: Do not exceed the maximum weight capacity of 350 lbs for the patio chair and 500 lbs for the XXL lounge chair. Always use the adjustable reclining mechanism carefully and follow the instructions provided to ensure safe operation.

- Ensure the chair is placed on a stable, level surface before use.
- Keep hands and fingers clear of moving parts during adjustment to prevent pinching.
- Do not allow children to play on or around the chairs unsupervised.
- Inspect the chair regularly for any signs of wear or damage. Discontinue use if damage is found.
- Avoid exposing the chairs to extreme weather conditions for prolonged periods to extend product life.

3. PRODUCT OVERVIEW

The TIMBER RIDGE Reclining Patio and Zero Gravity Lounge Chairs are designed for outdoor relaxation, offering comfort and durability. Key features include:

- **Spacious Dimensions:** The patio chair measures 43.25(H) x 24(W) x 22(D) inches with a 20.5-inch seat height. The XXL lounge chair measures 43.5 x 28.5 x 30.5 inches with a 28.5-inch seat width.
- **High Weight Capacity:** Patio chair supports up to 350 lbs; XXL lounge chair supports up to 500 lbs.

- **Adjustable Reclining:** Lockable systems allow adjustment between 0-170 degrees for personalized comfort.
- **Convenience Features:** Includes a side tray with cup holder. The XXL lounge chair also features an adjustable headrest.
- **Durable Build:** Constructed with heavy-duty alloy steel frames and high-quality materials.
- **Material:** Polyester or Polyurethane Foam for padding.



Image 1: Dimensions of the TIMBER RIDGE Patio Chair. The chair measures 43.25 inches in height, 24 inches in width, and 22 inches in depth.

OURS-OVERSIZED



28IN



OTHERS-Regular



22-24IN




Image 2: Comparison highlighting the 28-inch width of the oversized chair versus regular chairs (22-24 inches).

DESIGNED FOR COMFORT



Image 3: Diagram illustrating the comfortable construction with 600D fabric and foam padding for extra comfort.



Image 4: Comparison highlighting the 33-inch width of the XXL chair versus regular chairs (22-24 inches).

4. SETUP

Both the TIMBER RIDGE Reclining Patio Chair XL and the XXL Zero Gravity Reclining Lounge Chair require no assembly. They are designed to be ready for use straight out of the packaging.

1. Remove the chair from its packaging.
2. Unfold the chair carefully, ensuring all frame components are fully extended and locked into place.
3. Place the chair on a flat, stable surface.

5. OPERATING INSTRUCTIONS

5.1 Reclining Mechanism

To adjust the reclining position:

1. Sit comfortably in the chair.
2. Lean back gently to the desired reclining angle (between 0 and 170 degrees).
3. Once at the desired angle, locate the locking levers on both sides of the chair, beneath the armrests.

4. Push the levers down to lock the chair securely in position.

5. To return to an upright position, lift the locking levers and gently push forward with your body weight.

Enjoy the outdoor more

REAL ZERO GRAVITY



Image 5: A person demonstrating the reclining feature of the zero gravity chair, enjoying outdoor relaxation.

5.2 Side Tray with Cup Holder

The side tray provides convenient storage for drinks and small items.

1. To deploy the side tray, locate the tray attached to the side of the chair.
2. Gently pull the tray outwards until it clicks into its open position.
3. The tray includes a built-in cup holder for beverages.
4. To retract the side tray, lift it slightly and push it back towards the chair frame until it is flush.



Image 6: The TIMBER RIDGE Patio Chair shown with its convenient side tray extended, featuring a cup holder.



Image 7: The TIMBER RIDGE XXL Lounge Chair with its retractable side tray and built-in cup holder.

5.3 Adjustable Headrest (XXL Lounge Chair)

The XXL lounge chair features an adjustable headrest for enhanced comfort. Simply slide the headrest up or down along the back of the chair to find your preferred position.

6. MAINTENANCE

- **Cleaning:** Wipe down the fabric and frame with a damp cloth and mild soap. Rinse thoroughly and allow to air dry completely before folding or storing.
- **Storage:** When not in use, especially during inclement weather or off-season, store the chairs in a dry, protected area to prevent rust and fabric degradation. The chairs are foldable for compact storage.
- **Inspection:** Periodically check all bolts, screws, and elastic cords to ensure they are tight and secure. Replace any worn or damaged parts immediately.

7. TROUBLESHOOTING

- **Chair does not recline smoothly:** Check for any obstructions in the reclining mechanism. Ensure the locking levers are fully disengaged.
- **Chair feels unstable:** Verify that the chair is fully unfolded and all frame parts are securely locked. Ensure it is on a flat surface.

- **Side tray does not extend/retract:** Check for any debris or obstructions preventing smooth movement. Apply a small amount of silicone lubricant if necessary.

8. SPECIFICATIONS

Feature	Detail
Brand	TIMBER RIDGE
Model Number	2b85f926-c98b-42e8-91b3-35646597e8b6
Color	Brown
Material	Alloy Steel (Frame), Polyester or Polyurethane Foam (Fill)
Patio Chair Dimensions (H x W x D)	43.25" x 24" x 22"
XXL Lounge Chair Dimensions (H x W x D)	43.5" x 28.5" x 30.5"
Patio Chair Weight Capacity	Up to 350 lbs
XXL Lounge Chair Weight Capacity	Up to 500 lbs
Reclining Positions	Multiple (0-170 degrees), Lockable
Features	Foldable, Adjustable Headrest (XXL), Side Tray with Cup Holder
Indoor/Outdoor Usage	Outdoor

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's website or contact customer service using the details provided with your purchase. Keep your proof of purchase for warranty claims.