



Proscenic P11/P11 Combo/P10 PRO/U11 Replacement Kit

Instruction Manual for Proscenic Vacuum Cleaner Replacement Parts

Original Mop Pads and HEPA Filters

INTRODUCTION

This manual provides essential information for the installation and maintenance of original replacement mop pads and HEPA filters designed for select Proscenic wireless vacuum cleaners. Proper installation and regular maintenance ensure optimal performance and longevity of your vacuum cleaner.



Image: Overview of the replacement kit, showing two mop pads and two HEPA filters.

COMPATIBILITY

These replacement parts are specifically designed for the following Proscenic wireless vacuum cleaner models:

- Proscenic P11
- Proscenic P11 Combo
- Proscenic P10 PRO
- Proscenic U11

Using these parts with incompatible models may result in improper fit or reduced performance.

PACKAGE CONTENTS

Each package contains the following original Proscenic replacement parts:

- **2 x Mop Pads:** Designed for effective floor cleaning.
- **2 x HEPA Filters:** Essential for trapping fine dust and allergens.

Please verify all contents upon opening the package.

INSTALLATION GUIDE

1. Mop Pad Installation

1. Ensure the vacuum cleaner is powered off and unplugged before beginning installation.
2. Locate the mop attachment area on your Proscenic vacuum cleaner. This is typically on the underside of the water tank or main cleaning head.
3. Align the new mop pad with the attachment points (e.g., Velcro strips or clips) on the vacuum's mop module.
4. Press firmly to secure the mop pad in place, ensuring it is flat and evenly attached.
5. Verify that the mop pad is securely fastened and will not detach during operation.



Image: A close-up view of the textured surface of a mop pad.



Image: The reverse side of a mop pad, showing the attachment surface.



Image: A mop pad with a measuring tape indicating its approximate diameter.

2. HEPA Filter Installation

1. Before handling, ensure the vacuum cleaner is turned off and unplugged.
2. Locate the dustbin or filter compartment on your Proscenic vacuum cleaner. Refer to your vacuum's specific user manual for exact location and access instructions.
3. Open the dustbin or filter compartment.
4. Remove the old HEPA filter. Dispose of it properly.
5. Insert the new HEPA filter into the designated slot. Ensure the "UP" indicator (if present) on the filter faces the correct direction as indicated by your vacuum's design.
6. Gently press the filter until it clicks into place or is securely seated.
7. Close the dustbin or filter compartment firmly.



Image: A close-up view of the HEPA filter, showing the pleated filter material and the "UP" marking.



Image: The reverse side of the HEPA filter, showing the solid backing.

MAINTENANCE & CARE

Mop Pads

- **Cleaning:** After each use, remove the mop pad and rinse it thoroughly under running water to remove dirt and debris. For deeper cleaning, the mop pads can be machine washed with mild detergent.
- **Drying:** Allow mop pads to air dry completely before reattaching them to the vacuum or storing them. Do not tumble dry.
- **Replacement:** Mop pads should be replaced every 3-6 months, or more frequently depending on usage and wear, to maintain optimal cleaning performance.

HEPA Filters

- **Cleaning:** Tap the HEPA filter gently over a trash can to dislodge accumulated dust and debris. Do not wash HEPA filters with water, as this can damage the filter material and reduce its effectiveness.
- **Replacement:** HEPA filters should be replaced every 6-12 months, or more frequently if you notice a decrease in suction power or an increase in dust escaping the vacuum. Regular replacement ensures efficient air filtration.

SPECIFICATIONS

Product Type	Vacuum Cleaner Replacement Parts
Compatible Models	Proscenic P11, P11 Combo, P10 PRO, U11
Material (HEPA Filters)	HEPA (High-Efficiency Particulate Air) material
Quantity	2 Mop Pads, 2 HEPA Filters
Origin	Mainland China

TROUBLESHOOTING

If you encounter issues after installing the replacement parts, consider the following:

- **Mop Pad Not Attaching Securely:** Ensure the attachment area on the vacuum is clean and free of debris. Verify the mop pad is correctly aligned.
- **Reduced Suction Power (after filter replacement):** Check that the new HEPA filter is installed correctly and seated firmly. Ensure the dustbin is empty and properly closed.
- **Unusual Noises:** Re-check both the mop pad and HEPA filter installation to ensure no parts are loose or obstructing moving components.

For persistent issues, refer to your specific Proscenic vacuum cleaner's user manual or contact Proscenic customer support.

SUPPORT & WARRANTY

Specific warranty information for these replacement parts is not provided within this manual. For details regarding product warranty, returns, or technical support, please refer to the seller's policy or contact the manufacturer, Proscenic, directly through their official website or customer service channels.

