

[Manuals.plus](#) /

› [enya](#) /

› Enya NEXG 2 Acoustic-Electric Guitar User Manual

enya NEXG 2 BL

Enya NEXG 2 Acoustic-Electric Guitar User Manual

Model: NEXG 2 BL

Brand: Enya

INTRODUCTION

The Enya NEXG 2 Acoustic-Electric Guitar is a carbon fiber travel smart audio guitar designed for versatility and portability. It integrates a 50W wireless speaker, wireless microphone, Hi-Fi monitor earphones, footswitch, and charging stand, offering a comprehensive musical experience.



This manual provides essential information for setting up, operating, maintaining, and troubleshooting your NEXG 2 guitar.

WHAT'S IN THE BOX

Your Enya NEXG 2 package includes the following items:

- Enya NEXG 2 Acoustic-Electric Guitar
- Wireless Microphone

- Hi-Fi Monitor Earphones
- USB Type-C Charging Cable
- FC Charger
- Charging Stand
- Footswitch
- Gig Bag
- Companion App (downloadable)
- Enya ES3 Smart Audio System (integrated)



Please ensure all items are present before proceeding with setup.

SETUP

Initial Charging

Before first use, fully charge your NEXG 2 guitar using the provided USB Type-C charging cable and FC charger. You can also place the guitar on the charging stand for convenient charging.



Sing It Out

NEXG 2 comes with a wireless mic. Combined with the onboard speaker, you've basically got a Karaoke machine. The Vocal Removal is built in for sing-alongs. Sing it out, anytime, anywhere.



Connecting to the App

Download the Enya Music companion app from your device's app store. The app allows for deeper customization of sounds and functionalities. Connect via Bluetooth for wireless control or USB-C for data transfer and recording.



NEXG 2

**The Ultimate
Smart Audio
Guitar
Experience**

Unleash your musical potential with the NEXG 2, a smart audio guitar that redefines modern music creation. With its innovative features and intuitive design, it's the ultimate companion for musicians and enthusiasts.



Footswitch Connection

The included footswitch connects wirelessly to the guitar, providing hands-free control over features like the looper and drum machine. Refer to the app for footswitch pairing instructions.



Wireless Microphone and Earphones

Connect the wireless microphone for vocal performance and the Hi-Fi monitor earphones for silent practice. The microphone pairs automatically with the guitar.



Attaching the Strap

The gig bag strap can be removed and attached to the guitar as a shoulder strap. Note that the strap may be too short for some adults, and attaching it can interfere with placing the guitar on the charging stand. It is recommended to remove the strap when using the charging stand.

OPERATING YOUR NEXG 2

DSP Chip and Presets

The NEXG 2 features an upgraded DSP chip with triple the computing power, allowing for sophisticated audio algorithms and functionalities. Navigate through 20 fine-tuned presets directly on the color touch screen or customize further via the

app.



Looper and Drum Machine

A significant upgrade, the onboard looper and drum machine allow you to create multi-layered performances. Select drum beats, record guitar parts, and even add vocals with the wireless microphone to create a

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question