Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO CS17-BRN

VECELO Small Corner Computer Desk (Model: CS17-BRN) Instruction Manual

Your guide to assembly, operation, and maintenance of your VECELO Corner Desk.

Overview **Setup** **Operating** **Maintenance** **Troubleshooting** **Specifications** **Warranty & Support** **Safety Information**

1. Product Overview

The VECELO Small Corner Computer Desk (Model: CS17-BRN) is designed to optimize space in smaller areas. Its triangular shape allows it to fit snugly into corners, providing a functional workstation without occupying excessive floor space. Constructed with a tough, durable frame and engineered wood surfaces, this desk is built for stability and longevity. It features integrated storage shelves and a convenient pull-out keyboard tray, enhancing its utility for various tasks.



VECELO Small Corner Computer Desk in a home office setting, showcasing its compact triangular design and integrated storage shelves. A laptop is placed on the main surface, with decorative items on the lower shelves.

2. Setup and Assembly

Assembly of the VECELO Corner Computer Desk is designed to be straightforward, typically completed within 15 minutes with two people. All necessary hardware and a basic screwdriver are included. Please follow the steps below carefully.

2.1 Unpacking and Component Identification

- Carefully open the packaging and remove all components.
- Verify that all parts listed in the instruction manual are present and undamaged.
- Identify the main tabletop, side shelves, metal frame components, and hardware packs.

2.2 Attaching the Keyboard Tray Rails

1. Place the main tabletop upside down on a soft, clean surface to prevent scratches.
2. Attach the metal rails for the keyboard tray to the designated pre-drilled holes on the underside of the tabletop using

the provided screws. Ensure they are securely fastened.

2.3 Assembling the Desk Legs and Frame

3. Connect the vertical metal leg frames to the tabletop using the appropriate screws. Pay close attention to the orientation of the holes as indicated in the manual.
4. Secure the horizontal support beams between the vertical leg frames to create a stable base.

2.4 Installing the Side Shelves

5. Attach the side shelves to the metal frame, aligning them with the pre-drilled holes. Fasten them securely with screws.

2.5 Finalizing the Keyboard Tray

6. Slide the keyboard tray into the installed rails. Ensure it moves smoothly.

2.6 Installing the Power Outlet (if applicable)

7. If your model includes a built-in power outlet, carefully insert it into the designated cutout on the tabletop and secure it with the provided screws.

2.7 Positioning the Desk

- Once fully assembled, carefully flip the desk upright and place it in your desired corner.
- Ensure the desk is stable and level before placing any items on it.



Rear view of the VECELO Corner Computer Desk, showing the sturdy alloy steel frame and the open-back design for potential cable management.

3. Operating Your Desk

The VECELO Corner Computer Desk is designed for versatile use in various settings, including home offices, bedrooms, or as a crafting station. Its features are straightforward to use.

3.1 Using the Main Desktop Surface

The spacious triangular desktop provides ample room for a laptop, monitor, or other work essentials. Its design allows for efficient use of corner space.

3.2 Utilizing the Pull-Out Keyboard Tray

The desk includes a smooth-gliding pull-out keyboard tray. This feature helps maintain a clean desktop by storing your keyboard and mouse when not in use, or provides an ergonomic typing position.

3.3 Accessing Storage Shelves

The integrated open shelves on the side offer convenient storage for books, office supplies, or decorative items, keeping your workspace organized.



The VECELO Corner Computer Desk repurposed as a dressing table in a bedroom, demonstrating its versatility for various uses beyond a computer desk.



The VECELO Corner Computer Desk accommodating a printer and other office supplies, highlighting its functionality as a small office workstation.

4. Maintenance and Care

To ensure the longevity and appearance of your VECELO Corner Computer Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a damp cloth or a dry cloth. The waterproof and anti-dust design makes cleaning easy. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the engineered wood surface.
- **Stability:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves. Avoid placing excessively heavy items on one spot.



A hand wiping the surface of the VECELO Corner Computer Desk, illustrating its easy-to-clean, waterproof, and anti-dust design.

5. Troubleshooting

If you encounter any issues with your VECELO Corner Computer Desk, please refer to the following general advice:

- **Instability/Wobbling:** Ensure all screws are tightened. Check that the desk is placed on a flat, even surface. Adjust the leveling feet if present.
- **Keyboard Tray Sticking:** Check the rails for any obstructions or debris. Ensure the tray is properly aligned within the tracks.
- **Missing Parts:** If any parts were missing upon delivery, please contact VECELO customer support immediately.

For further assistance, please refer to the "Warranty & Support" section.

6. Product Specifications

Feature	Detail
Brand	VECELO
Model Number	CS17-BRN

Feature	Detail
Shape	Triangular
Product Dimensions (D x W x H)	33.1"D x 23.4"W x 30"H
Item Weight	15 Pounds
Color	Brown
Top Material Type	Engineered Wood
Base Material	Alloy Steel
Special Feature	Compact, Rust Resistant
Number Of Shelves	1 (open shelf)
Maximum Weight Recommendation	200 Pounds
Required Assembly	Yes
Recommended Number of People for Assembly	2



Detailed dimensions of the VECELO Corner Computer Desk, illustrating its 33.1-inch width, 23.4-inch depth, and 30-inch height, along with shelf spacing.

7. Warranty and Professional Support

The VECELO Corner Computer Desk comes with a**2-year limited warranty**. This warranty covers manufacturing defects and issues arising from normal use.

VECELO is committed to providing professional support. If you have any questions regarding the quality, assembly, or installation of your desk, please do not hesitate to contact our customer service team. We will assist you in resolving any problems.

For support, please visit the official VECELO website or refer to the contact information provided in your product packaging.

8. Safety Information

To ensure safe use of your VECELO Corner Computer Desk, please adhere to the following safety guidelines:

- **Stable Assembly:** Always ensure the desk is assembled correctly and all fasteners are securely tightened before use.
- **Weight Limit:** Do not exceed the recommended maximum weight limit of 200 pounds for the desktop. Overloading can compromise the desk's stability and lead to damage or injury.
- **Placement:** Place the desk on a flat, stable surface. Avoid placing it on uneven ground or in high-traffic areas where it could be easily bumped.
- **Children:** Keep small children away from the desk during assembly. Do not allow children to climb on or play with the desk.
- **Electrical Safety:** If your desk includes a power outlet, ensure it is properly connected to a grounded electrical source. Do not overload the outlets.

© 2026 VECELO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBJJQWX5

More documents and user manuals: **https://manuals.plus/**